REMOVAL/INSTALLATION Page 1 of 1

## **REMOVAL/INSTALLATION**

Remove the right rear engine cover bolts [1], collars [2] and right rear engine cover [3]. Installation is in the reverse order of removal.

## **TORQUE:**

Right rear engine cover socket bolt:

10 N·m (1.0 kgf·m, 7 lbf·ft)

