REMOVAL/INSTALLATION Page 1 of 2

REMOVAL/INSTALLATION

Remove the following:

- Middle cowl
- Rear side cowlSocket bolt [1]
- Trim clips [2]

Release the bosses [3] from the grommets [4]. Remove the side cover [5]. Installation is in the reverse order of removal.

Right side shown:

