REMOVAL/INSTALLATION Page 1 of 1

## **REMOVAL/INSTALLATION**

## Remove the windscreen

Loosen the windscreen stay bolts [1] until the windscreen stay [2] is removable.

Remove the windscreen stay.

Installation is in the reverse order of removal.

TORQUE:
Windscreen stay socket bolt:
12 N·m (1.2 kgf·m, 9 lbf·ft)

## NOTE:

 Apply the soap water to the contact surface [3] between the windscreen stay bolts and rubber washers [4] when assembling.

