REMOVAL/INSTALLATION Page 1 of 1

## REMOVAL/INSTALLATION

Remove the following:

- Middle cowl socket bolt A [1]
  Middle cowl socket bolt B [2]
  Well nut [3]

- Trim clips A [4]
- Trim clip B [5]

Release the bosses [6] from the grommets [7].
Disconnect the front turn signal light 2P (Light blue) connector [8].
Remove the middle cowl [9] by releasing the tabs [10] from the side cover and front lower cowl.
Installation is in the reverse order of removal.

TORQUE:

Middle cowl socket bolt A:

0.54 N·m (0.06 kgf·m, 0.4 lbf·ft)

