REMOVAL/INSTALLATION Page 1 of 1

REMOVAL/INSTALLATION

Remove the following:

- Socket bolts [1]
- Deflector cover [2]

Installation is in the reverse order of removal.

