Zenith X-Series Router Manual

This manual covers the Zenith X1, X2, X3 and X4 home routers. Read the safety notes before installation.

Safety: use the router only indoors at temperatures between 0 and 40 degrees Celsius. Do not open the housing. Use only the power adapter supplied with the device. Keep at least 10 cm of free space around the router for ventilation.

X1 Specifications

The Zenith X1 is a home router. It has 4 LAN ports and supports Wi-Fi 5 wireless networking. The maximum wireless throughput of the X1 is 867 Mbps. Power consumption is 12 W under full load. The X1 is covered by a limited warranty of 2 years. The X1 has no USB port.

X2 Specifications

The Zenith X2 is a home router. It has 4 LAN ports and supports Wi-Fi 6 wireless networking. The maximum wireless throughput of the X2 is 1800 Mbps. Power consumption is 15 W under full load. The X2 is covered by a limited warranty of 2 years. The X2 has one USB 2.0 port for printer sharing.

X3 Specifications

The Zenith X3 is a home router. It has 8 LAN ports and supports Wi-Fi 6 wireless networking. The maximum wireless throughput of the X3 is 3000 Mbps. Power consumption is 24 W under full load. The X3 is covered by a limited warranty of 3 years. The X3 adds a 2.5 Gbps WAN port and one USB 3.0 port for network storage.

X4 Specifications

The Zenith X4 is a home router. It has 8 LAN ports and supports Wi-Fi 6E wireless networking. The maximum wireless throughput of the X4 is 5400 Mbps. Power consumption is 30 W under full load. The X4 is covered by a limited warranty of 3 years. The X4 adds two 10 Gbps SFP+ ports and one USB 3.0 port for network storage.

Setup

Connect the WAN cable to the blue port and power on the router. Open http://192.168.50.1 in a browser to reach the admin page; the default admin username is admin and the password is printed on the label on the bottom of the device. You are asked to change the password on first login.

Firmware updates are published every quarter. Install them from the admin page under System > Update. A solid amber LED means a firmware update is in progress: do not switch the router off.

Troubleshooting

LED codes: a green LED means the router is online. If the LED blinks red 3 times, the router has no WAN connection; check the cable to your modem. A solid red LED indicates a hardware fault and the device should be returned.

Factory reset: press and hold the reset button for 10 seconds until the LED blinks white. All settings, including the admin password, return to factory defaults.

If Wi-Fi speed is low, change the wireless channel and move the router away from microwave ovens.

Warranty and Support

To make a warranty claim you need the proof of purchase, and the claim must be reported within 30 days after the defect was discovered. Damage caused by liquids or by opening the housing is not covered.

Support is available Monday to Friday from 9:00 to 17:00 CET at support@zenith.example. Replacement devices are shipped within 5 business days after the claim is approved.