1.0 PURPOSE: To provide instructions for servicing of the 130KVA, 500KVA, 800KVA and 1000KVA generator.

2.0 SCOPE: To provide written guidelines for servicing the 130KVA, 500KVA, 800KVA and 1000KVA generator.

3.0 RESPONSIBILITY:

- It is the responsibility of any qualified personnel
- It is the responsibility of Biomedical Limited to provide the PPE for the qualified employee performing the task
- It is the responsibility of contactors to provide the PPE for their qualified staff
- It is the responsibility of the Engineering head to ensure that the SOP is strictly followed

4.0 POTENTIAL RISK: Shock, burn, fall

5.0 PROCEDURE

130KVA

- Loose the wires connected to the battery terminal, starting with the Negative terminal.
- Drain all the used oil from the oil sump.

- Unscrew oil filters and fuel filters, both primary and secondary fuel filters.
- After draining all the used oil.
- Collect new oil filters and fuel filters from the company technical store. This generator uses Primary fuel filter: fleetguard 5207, Secondary fuel filter: fleetguard 5206, oil lubricant filter: LF 670.
- Replace the oil filter and also the rubber oil filter rings at the top of the filter. Make sure the filters are filled to the brim with new engine oil before screwing it back to its position.
- Replace the fuel filters and also the rubber rings at the top of the filter. Make sure the filters are filled to the brim with diesel before screwing it back to its position.
- Fill new engine oil into the generator oil sump. Approximately 25 liters of TOTAL RUBIA XT 15W-40 oil are to be filled into the oil sump. After which u can measure the amount of oil in the sump using the oil gauge. The generator sump has dip stick with letter L and H inscribed on it. The oil is said to be gauged when the oil is on the letter H or slightly below and not gauged while the oil is around Letter L which indicates that the oil level is low.
- In case of spillage during oil filling, addition of oil to the oil sump will be based on the measurement the oil gauge gives you. Note: don't overfill the sump. Strictly follow the gauge.
- Reconnect the wire loosened from the battery terminal, starting with the negative terminal first
- Clean and inspect the generator air filter.
- Run the generator for five (5) minutes and observe.
- Calculate and document the next servicing readings of 150 hours on the provided area on generator body and on the generator usage log book with document number: BML-ENG-NG-002-F01)

500KVA

- Loose the wires connected to the battery terminal, starting with the Negative terminal.
- Drain all the used oil from the oil sump.
- Unscrew oil filters and the fuel filters both primary and secondary fuel filters.
- After draining all the used oil.
- Collect new oil filters and fuel filters from the company store. This generator uses oil filter 10929, primary fuel filters 10930, Secondary fuel filter 10931.
- Replace the oil filter and also the rubber oil filter rings at the top of the filter. Make sure the filters are filled to the brim with new engine oil before screwing it back to its position.
- Replace the fuel filters and also the rubber rings at the top of the filter. Make sure the filters are filled to the brim with diesel before screwing it back to its position.
- Fill new engine oil into the generator oil sump. Approximately 90 liters of TOTAL RUBIA XT 15W-40 oil are to be filled into the oil sump. After which u can measure the amount of oil in the sump using the oil gauge. The generator sump has dip stick with letter L and H inscribed on it. The oil is said to be gauged when the oil is on the letter H or slightly below and not gauged while the oil is around Letter L which indicates that the oil level is low.
- In case of spillage during oil filling, addition of oil to the oil sump will be based on the measurement the oil gauge gives you. Note: don't overfill the sump. Strictly follow the gauge.
- Reconnect the wire loosened from the battery terminal, starting with the negative terminal first
- Clean and inspect the generator air filter.

- Run the generator for five (5) minutes and observe.
- Calculate and document the next servicing readings of 150 hours on the provided area on generator body and on the generator usage log book with document number: BML-ENG-NG-002-F01)

800KVA

- Loose the wires connected to the battery terminal, starting with the Negative terminal.
- Drain all the used oil from the oil sump.
- Unscrew oil filters and the fuel filters both primary and secondary fuel filters.
- After draining all the used oil.
- Collect new oil filters and fuel filters from the company store. This generator uses q . Replace the oil filter and also the rubber oil filter rings at the top of the filter. Make sure the filters are filled to the brim with new engine oil before screwing it back to its position.
- Replace the fuel filters and also the rubber rings at the top of the filter. Make sure the filters are filled to the brim with diesel before screwing it back to its position.
- Fill new engine oil into the generator oil sump. Approximately 100 liters of oil are to be filled into the oil sump. After which u can measure the amount of oil in the sump using the oil gauge. The generator sump has dip stick with letter L and H inscribed on it. The oil is said to be gauged

when the oil is on the letter H or slightly below and not gauged while the oil is around Letter L which indicates that the oil level is low.

- In case of spillage during oil filling, addition of oil to the oil sump will be based on the measurement the oil gauge gives you. Note: don't overfill the sump. Strictly follow the gauge.
- Reconnect the wire loosened from the battery terminal, starting with the negative terminal first.
- Clean and inspect the generator air filter.
- Run the generator for five (5) minutes and observe.
- Calculate and document the next servicing readings of 150 hours on the provided area on generator body and on the generator usage log book with document number: BML-ENG-NG-002-F01)

1000KVA

- Loose the wires connected to the battery terminal, starting with the Negative terminal.
- Drain all the used oil from the oil sump.
- Unscrew oil filters and the fuel filters both primary and secondary fuel filters.
- After draining all the used oil.
- Collect new oil filters and fuel filters from the company store. This generator uses 3 Perkins 2473 oil filters and 2 Perkins 19596 fuel filters.
- Replace the oil filter and also the rubber oil filter rings at the top of the filter. Make sure the filters are filled to the brim with new engine oil before screwing it back to its position.

- Replace the fuel filters and also the rubber rings at the top of the filter. Make sure the filters are filled to the brim with diesel before screwing it back to its position.
- Fill new engine oil into the generator oil sump. Approximately 120 liters of oil are to be filled into the oil sump. After which u can measure the amount of oil in the sump using the oil gauge. The generator sump has dip stick with letter L and H inscribed on it. The oil is said to be gauged when the oil is on the letter H or slightly above and not gauged while the oil is around Letter L which indicates that the oil level is low.
- The addition of oil to the oil sump will be based on the measurement the oil gauge gives you. Note don't overfill the sump. Strictly follow the gauge.
- Reconnect the wire loosened from the battery terminal, starting with the negative terminal first.
- Clean and inspect the generator air filter.
- Run the generator for five (5) minutes and observe.
- Calculate and document the next servicing readings of 150 hours on the provided area on generator body and on the generator usage log book with document number: BML-ENG-NG-002-F01).

6.0 REFERENCES AND ENCLOSURE:

- generator usage log book with document number: BML-ENG-NG-002-F01).

7.0 TRAINING INVOLVEMENT:

All Engineering staff
All machine Operators

8.0 DISTRIBUTION AND COPY CONTROL:

- This is the various department/section where the SOP copies will be utilized.

MASTER COPY	QUALITY
CONTROLLED COPY	QUALITY, ENGINEERING, PRODUCTION

9.0 CHANGE HISTORY:

CURRENT REVISION	SUPERSEDE	REASON FOR REVIEW
00	Nil	First issue
01	00	• Change in sop format. Inclusion of traceability of enclosures to parent SOP