

Power Outage Dome Check

Elevators • Freight elevator moves to first floor (usually) and opens. Go close it from ESB. • Dome elevator breakers located on Obs floor Opt side chiller room – Panel Z bottom row (Opt – right side, IR – left side) – Turn both OFF, wait 30s, turn ON	Hydrostatic Bearing • Check panel in ESB • On the left side of the panel, a monitor shows some Japanese message ("Ika no Error ga..." in Japanese characters) with yellow background. • Draw the keyboard and hit ESC key to have the PC continue to boot up. After the system boot up, LabView program starts and finally blue windows show up. • Push "Alarm Reset" button on the right bottom corner of the panel.
Panel Z • One circuit breaker is to be reset in the chiller room on Optical side of the observation floor [when you enter the room where CP-1 is located, this chiller room is on your left]. • The chiller room should be unlocked but if not, get a key labeled "D 21" from a key box in the walkway to the elevator on the optical side [11/25/04, no such key found in box, and panel was unlocked, DS]. • All the way to the right direction in the room, there is PP#1 panel (Panels Z & Y): Open it and find a larger breaker (C/W Shunt Trip Breaker) at the bottom of the left hand side. • The breaker should be at between on and off, called the neutral position. Move the breaker switch off and then on.	CP-1 • On CP1, dome boggy amp should show the alarm. You can recognize it by looking at the red indicator at the top of the panel. • Just cycle the key switch OFF then to REMOTE. Then boggy should be back. • If it failed to recover, open right hand side door of DP-1 and check if all the breakers at the top of the cabinet are on. – If breakers are on, then cycle them off and on.
CP-2 • Reset the Circuit Breaker #12 in the lower cabinet of CP2 • In CP2, there is a cabinet with PC monitor. The breaker is located on Panel D inside the cabinet under the monitor. • Both dome and top screen encoders are powered through the breaker. – After resetting Circuit Breaker #12, you may need to also clear the Top Screen Alarms. To do this go to CP1 where you'll see the red indicators at the top of the Top Screen panel. Cycle its key switch from Remote to OFF to Remote. This should clear the alarms and allow you to turn the Drive on.	Heat Exhaust (FATS #2749) • Go to observation floor IR and/or OPT cooling unit. Get a ladder to reach display control panel. • Open display control panel by removing black knobs. • Reset FAN breaker. • At TWS Heat Exhaust Window, turn FAN: "On," Fan Speed: "High," Coolant: "Auto," Defrost Heater: "Auto" and confirm Defrost: "Auto."

Chillers (Dome Check only)

- Check if the He compressors are working. Go to the IR & Opt compressor rooms and check the panels of each compressor.
- If the He compressors are not working, please call instrument group
- Follow FATS #4295 for Chiller recovery from Control Building