TITLE DISPLAY FUNCTION

*FOR FS 0i-F

Title display Function on Initial Screen

- We can display a word/string of upto 10 character max. on the initial screen when CNC starts booting.

- Most of the MTBs/End users encrypt their name on this screen, which can be modified to any other name by changing respective character value in parameter

- We can display name as shown in the space below(White box) with asterisk border. It is always shown at the center of the screen(for 8.4 and 10.4” display).

- For 15” display unit, it is displayed slightly towards the left of center as shown below.

- The color of the character/string displayed is white by default and it is always displayed in Upper Case.
- It is possible to display upto 10 characters maximum.
- It is always displayed in an asterisk(*) frame. The frame becomes small in proportion of character which is displayed.
- Following characters are possible to display :

  I. Alphabets from **A to Z**

  II. Number from **0 to 9**

  III. Negative sign **"-"**

  IV. Space " "

  V. Dot "."

Setting Procedure

- For displaying string we need to set parameter from 8940 to 8949.

Parameters

8940	Initial screen title character code 1
8941	Initial screen title character code 2
to	to
8949	Initial screen title character code 10

[Input type] Parameter input
[Data type] Byte
[Valid data range] 0,32,45,46,48 to 57,65 to 90

- This parameter sets the character codes of character/string to be displayed on initial screen immediately after power ON.
- If the number of characters to be displayed is less than 10,the parameters corresponding to the space exceeding the character length is set to be 0.

A : 65	N : 78	0 : 48	
B : 66	O : 79	1 : 49	
C : 67	P : 80	2 : 50	
D : 68	Q : 81	3 : 51	
E : 69	R : 82	4 : 52	
F : 70	S : 83	5 : 53	
G : 71	T : 84	6 : 54	
H : 72	U : 85	7 : 55	
I : 73	V : 86	8 : 56	
J : 74	W : 87	9 : 57	
K : 75	X : 88	: 32	(Space)
L : 76	Y : 89	- : 45	(Negative sign)
M : 77	Z : 90	. : 46	(Period)
		: 0	(Null character)

- When the value in P8940 to P8949 is set other than the codes mentioned above, then space is displayed on screen.
- EG. If we wants to set string as FANUC, then following values we have to enter in parameter P8940 to P8949

Character	Parameter	Code
F	8940	70
A	8941	65
N	8942	78
U	8943	85
C	8944	67
	8945	0
	8946	0
	8947	0
	8948	0
	8949	0

THANK YOU..!

Prepared By : Kalpesh Marathe
Service, WZ