

General Notes:

- All 3.3V pins connect to 3.3V on NUCLEO board
- All GND pins connect to GND on NUCLEO board
- Out 1 & 5 are in //
- Out 2 & 4 are in //
- In 1 & 3 are in //
- In 2 & 4 are in //
- make sure you hook battery power to a separate row, not to Vcc directly!

