

StoneAge® WARTHOG® Rotary Sewer Nozzle (WHP-3/4)

Description:

The **Warthog Maximum Pull** Rotary Sewer Nozzle was designed for waterjet cleaning of pipes and sewer lines. Jet thrust powers rotation of the head and pulls the tool thru the line. The Warthog WHP has a 3/4" NPT threaded inlet nut. It is also available with a 3/4" BSPP threaded inlet nut. The WHP is capable of working pressures up to 8000 psi (550 bar) and flow rates of 10 to 45 gpm. The unit is filled with a thick viscous fluid that controls the rotation speed. The nozzle orifice sizes should match the operating conditions of pressure and flow desired. Hose length and size must be known to correctly determine the proper orifice sizes. Contact your distributor or www.sewernozzles.com to help in nozzle selection.

The most important item in maintaining the Warthog is keeping the tool full of viscous fluid. The tool also has a high pressure seal and seat that will need to be replaced if the tool begins to leak water from under the Weep Seal. The tool may leak water at low pressure intermittently, but if it leaks at operating pressure, it is time to change the seal.


Operation:

A 15-25 foot long section of leader hose of a different color than the jetter hose is recommended to indicate how close the tool is to exiting the pipe during cleaning. Flush the jetter hose to remove debris. Pass hose end through the hose guard or Tiger Tail. If the **Warthog WHP** is being used in pipe diameters less than 8 inches it can be attached directly to the hose end; if being used in larger pipes it needs to have a straight rigid pipe or centralizer placed behind the tool so that the rigid length is greater than the pipe diameter so the tool cannot turn around in the pipe.

Risk of serious injury or death: Do not attempt to clean the manhole with the Warthog hanging on the hose. The tool can turn around and hit the operator.

Position the Warthog and tiger tail so it is within the pipe to be cleaned. Recommended cleaning direction is upstream from the manhole. Slowly bring the pump up to pressure, making certain that the Warthog begins to pull its way in the proper direction up the pipe; allow it to advance a few feet and note the location of the leader hose or other hose marker being used. Once the pump is up to operating pressure, feed out the reel at a reasonable rate to allow the jets time to clean the pipe. If roots are present, feeding at a slower rate will improve the cleaning results. Depending on the amount of debris present in the pipe, it may be necessary to occasionally pull the Warthog back toward the manhole to prevent large buildups of debris behind the tool.

When finished cleaning, withdraw tool back to initial starting point noted by the location of the leader or hose marker. Shut down and secure pump before removing Warthog from line. Secure the hose reel and Warthog to keep it from dragging on the ground. If the Warthog will be removed from the line and stored for more than several days, blow out water with compressed air to prolong the life of the internal components.



Troubleshooting:

Head will not rotate: First try rotating head by hand and see if it feels rough or gritty to turn. If it does, the tool must be disassembled and repaired; it likely has bad bearings, seals and fluid. If the tool feels okay, check to see if any nozzles are plugged; even if a nozzle is only partially blocked it can keep the head from rotating. Nozzles must be removed from the head to properly clean them; it does not do any good to poke the material plugging the nozzle back into the head, as it will just replug a nozzle.

Head spins too fast: It is likely that the swivel is low on viscous fluid, or the viscous fluid has water in it. The best thing to do is drain all the fluid, wipe the parts clean and refill with the proper fluid. Check that the shaft seals are still good and will keep the fluid from leaking out.

Seal Leak: The seal may leak initially at low pressure, but should pop closed as pressure is increased. If operating pressure is reached and the seal is leaking continuously, the high pressure seal may need to be replaced. Refer to the maintenance below.

Seals wear out quickly: The tool must be disassembled and inspected. The brass seat should be checked for being installed in the right direction, and it should be replaced any time the high pressure seal is replaced. The bore of the shaft where the high pressure seal is located should be checked for grooving. If it is worn larger than .633", the shaft will need to be replaced.

Maintenance: See the StoneAge website video gallery for details about the WGP Centralizer & Retaining Ring removal and installation.

To service the viscous fluid and high pressure seal:


1. It is not necessary to remove the Centralizer from the Inlet Nut for service, but it may be disassembled if desired. See disassembly & assembly details for procedure.

2. Hold the Body by the flats near the head and unscrew the Inlet Nut (WH 102) from the Body. Slide the Inlet Nut and Centralizer subassembly off of the Body.

3. Check the fluid condition and level. If the fluid appears to have water contamination or is very dirty, we recommend further disassembly of the tool to clean out the old fluid. Otherwise, drain out as much of the old fluid as possible and add new viscous fluid to cover the top bearing and wave spring.




4. Remove the Seat (TJ 011) and Seal (WH 012) from the bore of the Shaft. Apply grease to a new High Pressure Seal and install in the bore. Install a new Seat on top of the Seal, with the flat face of the Seat facing toward the Seal, as shown.

5. Apply anti-seize to the threads of the Body and thread the Inlet Nut and Centralizer subassembly into the Body. Make sure that the Seat stays centered in the bore of the Shaft. Tighten to 40 ft-lb torque.



If the high pressure seal is leaking, you will see water spraying from under the Weep Seal (RJ 021-S)



Detailed View:



StoneAge® WARTHOG® Rotary Sewer Nozzle (WHP-3/4)

Disassembly:

- To remove the Retaining Ring (WHP 032) from the Inlet Nut (WH 102), pry one end of the ring out of the groove in the Nut and spiral wind the remainder of the Ring out of the groove.
- Remove the Centralizer (WHP 080) from the body. The Retaining Ring will remain captured between the Centralizer fins. If the Retaining Ring is damaged it may be removed by spiral winding the Ring past the Centralizer fins.
- Unscrew the Head (WHP 040) from the Shaft.
- Unscrew the Inlet Nut (WH 102) from the Body (WH 003).



- Remove the O-Ring (RJ 008) and Weep Seal (RJ 021-S) from the Inlet Nut.

- Remove the Shaft Seal (WH 010) from the Inlet Nut if it appears damaged.


- Remove the Seat (TJ 011) and Seal (WH 012) from the Shaft bore.

- Remove the Wave Spring (RJ 014).

- Push the Shaft (WH 001) out of the Body.

- Remove the Shaft Seal (WH 010) from the Body if it is damaged.


- Carefully pry the Bearings (TJ 007) off of the Shaft. Make sure not to raise any burrs on the large diameter portion of the Shaft with the groove.




Assembly:

- Install Shaft Seals (WH 010) in the Body (WH 003) and the Inlet Nut (WH 102). Both seals are installed so the lip with the spring faces up when installing. Apply grease to the lips of the seals.

- Install O-Ring (RJ 008) and Weep Seal (RJ 021-S) on Inlet Nut.



- Press the Bearings (TJ 007) onto the Shaft (WH 001).



- Place the Wave Spring (RJ 014) on top of the Bearing. Add more viscous fluid until the Wave Spring is covered.

- Apply grease to the H.P. Seal (WH 012). Insert in bore of Shaft.

- Place the Seat (TJ 011) on top of the Seal, with the chamfered end up. (See the Maintenance Section)

- Apply anti-seize to the threads of the Inlet Nut; thread into Body and tighten to 40 ft-lb.

- Apply teflon tape to the shaft threads and install Head.

- Spiral wind the Retaining Ring (WHP 032) past the Centralizer fins until it is captured against the rear of the Centralizer tube.

- Slide the Centralizer (WHP 080) and Retaining Ring over the Inlet Nut until the front of the Centralizer tube seats against the Body shoulder.

- Install Retaining Ring (WHP 032) by spiral winding it into groove on Inlet Nut.

