



ANX4

Command Strings

Shure ANX4 command string documentation for third-party control systems, such as AMX, Crestron, or Extron.
Version: 0.3 (2026-G)

Table of Contents

ANX4 Command Strings	3	Channel Commands	9
Using a Third-Party Control System	3	Meter Rate Commands	16
Device Information	4	Side Channel Command Strings	22
		Transmitter Slots Command Strings	32

ANX4

Command Strings

Using a Third-Party Control System

The device is connected via Ethernet to a control system, such as:

- AMX, Crestron, or Extron
- Symetrix, Biamp, other digital signal processors (DSP)
- Specialized custom programs

Connection: Ethernet (TCP/IP; select “Client” in the AMX/Crestron program)

Port: 2202

To enable third party control for an ANX4, turn command strings on in the Network Services menu: Device Configuration > Network Services.

Conventions

There are 4 types of strings:

GET	Finds the status of a property. After the AMX/Crestron sends a GET command, the system responds with a REPORT string.
SET	Changes the status of a property. After the AMX/Crestron sends a SET command, the system responds with a REPORT string to indicate the new value of the property.
REP	When the system receives a GET or SET command, it replies with a REPORT command to indicate the status of the property. Important: With the exception of the metered properties, the device sends a REPORT when a value changes. Thus, it is not necessary to constantly query most device properties.
SAMPLE	Used for metering audio levels.

All messages sent and received are ASCII. Note that the level indicators and gain indicators are also in ASCII.

The character “x” in all of the following strings represents the channel and can be ASCII numbers 0 through 16 (ULX-D transmission mode) or 24 (Axient Digital transmission mode) as in the following table.

0	All channels
1 through 16	Individual channels, ULX-D transmission mode
1 through 24	Individual channels, Axient Digital transmission mode

Model Names in Command Strings

Because command strings are shared across multiple guides, example model names may differ from the product covered in this guide. Substitute the appropriate model name as needed.

Device Information

Use these commands to get information about the device, reboot, and restore default settings.

ALL

Description	Discovery of device properties.
Commands	<pre>< GET x ALL > < REP ... ></pre>
Variables	When x is zero, the device responds with REP for all device-specific properties and ALL channel-related properties including all metered properties. When x is a channel number, the device responds with REP for all device-specific properties and ALL channel x-related properties including all metered properties.
Notes	None.

FLASH

Description	Controls the flash to identify a device or channel.
Commands	<pre>< SET FLASH ON > < REP FLASH ON ></pre> Device initiates an identify then stops flashing: <pre>< REP FLASH OFF ></pre> <pre>< SET FLASH OFF > < REP FLASH OFF ></pre> Note: When used with no channel index the command initiates a Device Identify. When used with a channel index the command initiates a Channel Identify. <pre>< SET x FLASH ON > < REP x FLASH ON ></pre>
Variables	When used, x is the channel number.
Notes	None.

MODEL

Description	Discovery of the model name of the device.
Commands	<pre>< GET MODEL > < REP MODEL {AD4Q-Ayyyyyyyyyyyyyyyyyyyy} ></pre>
Variables	Where the repeating y represents the spaces returned by the device to pad the model name to 32 characters.
Notes	The device always responds with a 32-character model name.

DEVICE_ID

Description	Controls the Device ID.
Commands	<pre>< GET DEVICE_ID > < REP DEVICE_ID {AD4Q-Ayyyyyyyyyyyyyyyyyyyy} > < SET DEVICE_ID {Name1} > < REP DEVICE_ID {Name1yyyyyyyyyyyyyyyyyyyy} ></pre>
Variables	Where the repeating y represents the spaces returned by the device to pad the Device ID to 31 characters.
Notes	The device always responds with 31-character ID. SET accepts 1-31 Characters from the set: A-Z,a-z,0-9,!"#\$%&'()*+,-./:;<=>?@[\\]^_`~ and space.

FW_VER

Description	Discovery of the firmware version.
Commands	Self test passed: <pre>< GET FW_VER > < REP FW_VER {2.0.15.2yyyyyyyyyyyyyyyy} ></pre> Self test failed: <pre>< GET FW_VER > < REP FW_VER {2.0.15.2*yyyyyyyyyyyyyyyy} ></pre>
Variables	Where the repeating y represents the spaces returned by the device to pad the response to 24 characters.
Notes	Package version number reported as Maj.Min.Pack.Build.

NET_SETTINGS

Description	Control for the network settings.
Commands	< GET NET_SETTINGS interface > < REP NET_SETTINGS interface ipMode ipAddr subnetMask gwAddr macAddr > < SET NET_SETTINGS interface ipMode ipAddr subnetMask gwAddr >
Variables	<i>interface</i>: SC, D1, D2 (Where SC = Shure Control, D1 = Dante Primary, D2 = Dante Secondary) <i>ipMode</i>: AUTO, MANUAL <i>ipAddr</i>: aaa.aaa.aaa.aaa <i>subnetMask</i>: bbb.bbb.bbb.bbb <i>gwAddr</i>: ccc.ccc.ccc.ccc (where 000.000.000.000 means no gateway is used) <i>macAddr</i>: xx:xx:xx:xx:xx:xx (in REP only)
Notes	When setting new Shure Control network settings you must reconnect to the device via its new IP address. When setting Dante network settings the device reboots on its own to apply the new settings. You must reconnect to the device. When setting network settings to "AUTO" mode you must use "na" for the IP address, Subnet Mask and Gateway address. Dante Secondary settings are only applicable when the device is operating with switch configuration: Split/Redundant. There are no asynchronous REPorts for the NET_SETTINGS. Use GET to retrieve the most up to date values. For non-Dante enabled devices, only "SC" is applicable.
Examples	Example of getting the current network settings for the Shure Control interface: <pre>< GET NET_SETTINGS SC ></pre> <pre>< REP NET_SETTINGS SC AUTO 192.168.001.025 255.255.255.000 000.000.000.000 00:0E:DD:45:60:EB ></pre> Example of setting the Shure Control network settings to MANUAL settings: <pre>< SET NET_SETTINGS SC MANUAL 192.168.1.123 255.255.255.0 192.168.1.1 ></pre> After you change the Shure Control network settings you must reconnect at the new IP address. Then you can get/confirm the new settings. <pre>< GET NET_SETTINGS SC ></pre>

```
< REP NET_SETTINGS SC MANUAL 192.168.001.123 255.255.255.000 192.168.001.001
00:0E:DD:45:60:EB
>
```

Example of setting the Shure Control network settings to AUTO settings:

```
< SET NET_SETTINGS SC AUTO na na na >
```

After you change the Shure Control network settings you must reconnect at the new IP address.

Then you can get/confirm the new settings.

```
< GET
NET_SETTINGS SC >
```

```
< REP NET_SETTINGS SC AUTO 192.168.001.021 255.255.255.000 000.000.000.000
00:0E:DD:45:60:EB
>
```

Example of setting the Dante Primary interface to manual network settings:

```
< SET NET_SETTINGS D1 MANUAL 10.10.1.15 255.255.255.0
10.10.1.1 >
```

After the reboot you must reconnect, then you can get/confirm the new settings.

```
< GET NET_SETTINGS D1 >
```

```
< REP NET_SETTINGS D1 MANUAL 010.010.001.015
255.255.255.000 010.010.001.001 00:0E:DD:FC:B9:6F >
```

NA_DEVICE_NAME

Description	Discovers the Dante device name on dual and quad devices.
Commands	<pre>< GET NA_DEVICE_NAME > < REP NA_DEVICE_NAME {string} ></pre>
Variables	None.
Notes	The device always responds with 31-character ID. In these examples, the repeating y pads these strings, representing white space. Getting the Dante Device Name from a ULXD4Q that uses Yamaha naming conventions: <pre>< GET NA_DEVICE_NAME > < REP NA_DEVICE_NAME {Y001-Shure-ULXD4Q-435577yyyyyyy} ></pre> Getting the name from a device changed by Dante Controller to "GuitarRig3:" <pre>< GET NA_DEVICE_NAME {GuitarRig3} > < REP NA_DEVICE_NAME {GuitarRig3yyyyyyyyyyyyyyyyyyyy} ></pre>

TRANSMISSION_MODE

Description	Discovery of the transmission mode.
Commands	<pre>< GET TRANSMISSION_MODE > < REP TRANSMISSION_MODE STANDARD > or < REP TRANSMISSION_MODE HIGH_DENSITY ></pre>
Variables	None.
Notes	Values for transmission mode are: AD_STANDARD AD_HIGH_DENSITY ULXD_STANDARD ULXD_HIGH_DENSITY

AVAILABLE_CHANNELS

Description	Discovery of list of available channels on a device.
Commands	Example of a factory default ANX4: <pre>< GET AVAILABLE_CHANNELS > < REP AVAILABLE_CHANNELS {1,2,3,4,5,6,7,8...} ></pre> Example of a fully enabled ANX4 in ULXD mode: <pre>< GET AVAILABLE_CHANNELS > < REP AVAILABLE_CHANNELS {1,2,3,4,5,6,7,8,9,10,11,12,13,14,15,16,17,18,19,20,21,22,23,24} ></pre> Example of ANX4 in AD mode with various channels eclipsed due to usage of FD-C and/or Quadversity: <pre>< GET AVAILABLE_CHANNELS > < REP AVAILABLE_CHANNELS {1, 2, 3, 4, 5, 6, 7, 9...} ></pre>
Variables	None.
Notes	The device always responds with 62-character list of available ANX4 channels.

NUMBER_CHANNELS_LICENSED

Description	Discovery of number of licensed channels on a device.
Commands	Example of a factory default ANX4 with no license installed: <pre>< GET NUMBER_CHANNELS_LICENSED > < REP NUMBER_CHANNELS_LICENSED 00 ></pre> Example of a fully licensed ANX4:

	<code>< GET NUMBER_CHANNELS_LICENSED ></code> <code>< REP NUMBER_CHANNELS_LICENSED 24 ></code>
Variables	None.
Notes	Numeric 2 Characters 00 to 24

Channel Commands

Use these commands to adjust gain and mute channels.

CHAN_NAME

Description	Control for the channel name.
Commands	<code>< GET x CHAN_NAME ></code> <code>< REP x CHAN_NAME {yyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyy} ></code> <code>< SET x CHAN_NAME {Lead Vox} ></code> <code>< REP x CHAN_NAME {Lead Voxyyyyyyyyyyyyyyyyyyyyyyyyyy} ></code>
Variables	Where x is the channel number. Where the repeating y represents or pads the 31-character string from the set: A-Z,a-z, 0-9,!,"#\$%&'()*+,-./:;<=>?@[\\]^_`~ and space, that is, {1234567890123456789012345678901}.
Notes	SET only supports 8 characters. The device always responds with a 31-character name.

NA_CHAN_NAME

Description	Discovers Network Audio (Dante) channel name for dual and quad devices.
Commands	<code>< GET x NA_CHAN_NAME ></code> <code>< REP x NA_CHAN_NAME {yyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyy} ></code>
Variables	Where x is the channel number. Where the repeating y pads the 31-character channel name with spaces.

Notes	None.
--------------	-------

FLASH

Description	Controls the flash to identify a device or channel.
Commands	< SET FLASH ON > < REP FLASH ON > Device initiates an identify then stops flashing: < REP FLASH OFF > < SET FLASH OFF > < REP FLASH OFF > Note: When used with no channel index the command initiates a Device Identify. When used with a channel index the command initiates a Channel Identify. < SET x FLASH ON > < REP x FLASH ON >
Variables	When used, x is the channel number.
Notes	None.

AUDIO_GAIN

Description	Control for the channel audio gain.
Commands	< GET x AUDIO_GAIN > < REP x AUDIO_GAIN 030 > There is an offset of 18 so the actual value = 30 - 18 = 12 dB. To set to 22 dB: < SET x AUDIO_GAIN 40 > < REP x AUDIO_GAIN 040 > To decrement the value down 5 dB: < SET x AUDIO_GAIN DEC 5 > < REP x AUDIO_GAIN 035 > To increment the value up 10 dB: < SET x AUDIO_GAIN INC 10 > < REP x AUDIO_GAIN 045 >
Variables	Where x is the channel number.
Notes	Numeric

	3 Characters 000 to 060 in increments of 1 The values REPorted and SET are offset by 18 Actual range: -18 to 42 dB in 1 dB steps
--	---

AUDIO_MUTE

Description	Controls the channel audio mute output.
Commands	<pre>< GET x AUDIO_MUTE > < REP x AUDIO_MUTE OFF > < SET x AUDIO_MUTE ON > < REP x AUDIO_MUTE ON > < SET x AUDIO_MUTE OFF > < REP x AUDIO_MUTE OFF > < SET x AUDIO_MUTE TOGGLE > < REP x AUDIO_MUTE ON ></pre>
Variables	Where x is the channel number.
Notes	TOGGLE switches between ON and OFF.

ENCRYPTION_MODE

Description	Discovery of the Encryption Mode.
Commands	Axient Digital channel example: <pre>< GET x ENCRYPTION_MODE > < REP x ENCRYPTION_MODE ON ></pre> ULX-D channel example: <pre>< GET 1 ENCRYPTION_MODE > < REP 1 ENCRYPTION_MODE AUTO ></pre>
Variables	Where x is the channel number.
Notes	Values - Axient Digital: ON OFF

	Values - ULX-D: OFF AUTO MANUAL
--	--

ENCRYPTION_STATUS

Description	Discovery of the encryption status.
Commands	< GET x ENCRYPTION_STATUS > < REP x ENCRYPTION_STATUS OK > When a mismatched transmitter is detected: < REP x ENCRYPTION_STATUS ERROR >
Variables	Where x is the channel number.
Notes	It is unnecessary to continuously query this parameter. The receiver automatically sends a REPort when interference is detected.

RF_BAND

Description	Discovery of the RF band.
Commands	< GET x RF_BAND > < REP x RF_BAND {G55yyyyy} >
Variables	Where x is the channel number. Where the repeating y represents the spaces returned by the device to pad the response to 8 characters.
Notes	None.

ANTENNA_CONFIGURATION

Description	Discovery of the antenna configuration.
Commands	< GET x ANTENNA_CONFIGURATION > < REP x ANTENNA_CONFIGURATION AUTOMATIC >
Variables	Where x is the channel number.
Notes	Values for antenna configuration are: AB CD

AUTOMATIC
QUADVERSITY (Axient Digital mode only)

FD_MODE

Description	Discovery of the type of frequency diversity.
Commands	<pre>< GET x FD_MODE > < REP x FD_MODE OFF > < GET x FD_MODE > < REP x FD_MODE FD-C > < GET x FD_MODE > < REP x FD_MODE FD-S ></pre>
Variables	Where x is the channel number.
Notes	FD-C : Combining mode FD-S : Selection mode

FREQUENCY

Description	Controls frequency settings.
Commands	<pre>< GET x FREQUENCY > < REP x FREQUENCY 0578350 > < SET x FREQUENCY 602125 > < REP x GROUP_CHANNEL {--,--yyyy} > (Note 1) < REP x FREQUENCY 0602125 ></pre>
Variables	Where x is the channel number. Where the repeating y represents the spaces returned by the device to pad the response to 7 characters.
Notes	Frequency and Group Channel FREQUENCY - Device always returns a 7-character, numeric string GROUP_CHANNEL - Device always returns a 10-character string Range and Step per the RF Band 1. GROUP_CHANNEL and FREQUENCY are related: 1. Setting FREQUENCY results in the GROUP_CHANNEL value reverting to "--,--" if not already indicating "--,--" in addition to the FREQUENCY value. 2. Setting GROUP_CHAN results in the corresponding FREQUENCY value being reported in addition to the GROUP_CHAN value.

	Commands: Starting from a default condition: <pre>< GET x GROUP_CHANNEL > < REP x GROUP_CHANNEL {1,1yyyyyyy} > < GET x FREQUENCY > < REP x FREQUENCY 0606025 ></pre> SET the FREQUENCY to some new value: <pre>< SET x FREQUENCY 620000 > < REP x GROUP_CHANNEL {--,--yyyyy} > < REP x FREQUENCY 0620000 ></pre> Similarly, when setting GROUP_CHANNEL, the corresponding FREQUENCY is reported: <pre>< SET x GROUP_CHANNEL {6,6} > < REP x FREQUENCY 0614650 > < REP x GROUP_CHANNEL {6,6yyyyyyy} ></pre> 2. For channels operating in FD-C mode, there is a second FREQUENCY2 and GROUP_CHANNEL2 that behave in the same manner as FREQUENCY. <pre>< GET x FD_MODE > < REP x FD_MODE FD-C ></pre> <pre>< GET x FREQUENCY > < REP x FREQUENCY 0578350 ></pre> <pre>< GET x FREQUENCY2 > < REP x FREQUENCY2 0578850 ></pre>
--	--

GROUP_CHANNEL

Description	Controls the group channel mappings.
Commands	<pre>< GET x GROUP_CHANNEL > < REP x GROUP_CHANNEL {1,1yyyyyyy} ></pre> <pre>< SET x GROUP_CHANNEL {6,100} > < REP x FREQUENCY 0652875 > < REP x GROUP_CHANNEL {6,100yyyyy} ></pre>
Variables	Where x is the channel number. Where the repeating y represents the spaces returned by the device to pad the response to 10 characters.

Notes	For channels operating in FD-C mode, GROUP_CHANNEL2 corresponds to the second Group Channel value Device always returns a 10-character string Refer to the Group/Channel mappings corresponding to the RF Band and Transmission Mode of the device You must parse the "," from within the reported value Characters before the "," are the Group ID Characters after the "," are the Channel ID The value: "--,--" is the wildcard indicating no GROUP_CHANNEL value is set You cannot SET to "--,--" Note: GROUP_CHANNEL and FREQUENCY are related as described in FREQUENCY.
--------------	---

INTERFERENCE_STATUS

Description	Discovery of interference.
Commands	< GET x INTERFERENCE_STATUS > < REP x INTERFERENCE_STATUS NONE > When interference is detected: < REP x INTERFERENCE_STATUS DETECTED > For FD-C channels only: < GET x INTERFERENCE_STATUS2 > < REP x INTERFERENCE_STATUS2 NONE > When interference is detected: < REP x INTERFERENCE_STATUS2 DETECTED >
Variables	Where x is the channel number.
Notes	It is unnecessary to continuously query this parameter. The receiver automatically sends a REPort when interference is detected.

UNREGISTERED_TX_STATUS

Description	Discovery of an unregistered transmitter. Axient Digital channels only.
Commands	< GET x UNREGISTERED_TX_STATUS > < REP x UNREGISTERED_TX_STATUS OK > For FD-C channels only: < GET x UNREGISTERED_TX_STATUS2 > < REP x UNREGISTERED_TX_STATUS2 OK > A REP when the condition is occurring: < REP x UNREGISTERED_TX_STATUS ERROR >

	A REP when the condition is occurring on an FD-C channel: < REP x UNREGISTERED_TX_STATUS2 ERROR >
Variables	Where x is the channel number.
Notes	It is unnecessary to continuously query this parameter. The receiver automatically sends a REPort when an unregistered transmitter is detected.

Meter Rate Commands

Adjust different meter rates using these commands.

METER_RATE

Description	Controls the meter rate.
Commands	< GET x METER_RATE > < REP x METER_RATE 00000 > < SET x METER_RATE 01000 > < REP x METER_RATE 01000 > Note: This results in one SAMPLE every second.
Variables	Where x is the channel number.
Notes	Numeric, 5-character fixed output. 00000 - Metering OFF (default) 00100 to 65535 - The interval of each SAMPLE report in milliseconds. For example, 00100 - Sample every 100 millisecond (10 samples per sec) 01000 - Sample every second 05000 - Sample every 5 seconds

SAMPLE

Description	Specifies which of the Metering Commands you want to sample.
Commands	Standard Channel: Quadversity = OFF, FD = OFF or FD-S: < SAMPLE chNum ALL qual audBitmap audPeak audRms rfAntStats rfBitmapA rfRssiA rf- BitmapB rfRssiB > < SAMPLE 1 ALL 005 031 102 102 BB 31 086 31 065 >

Quadversity Channel: Quadversity = ON, FD = OFF

```
< SAMPLE chNum ALL qual audBitmap audPeak audRms rfAntStats rfBitmapA rfRssiA rf-
BitmapB rfRssiB rfBitmapC rfRssiC rfBitmapD rfRssiD >
```

```
< SAMPLE 1 ALL 005 031 102 102 BBBB 31 083 31 068 31 069 31 072 >
```

FD-C Channel: Quadversity = OFF, FD = FD-C

```
< SAMPLE chNum ALL qual audBitmap audPeak audRms rfAntStatsF1 rfBitmapF1A
rfRssiF1A rfBitmapF1B rfRssiF1B rfAntStatsF2 rfBitmapF2A rfRssiF2A rfBitmapF2B rfRssiF2B
>
```

```
< SAMPLE 1 ALL 005 031 102 102 BB 31 082 31 060 BB 31 082 31 060 >
```

Quadversity and FD-C Channel: Quadversity = ON, FD = FD-C

Sample input:

Note: The sample input that follows is actually 1 line of input spaced to show correlation.

```
< SAMPLE chNum ALL qual audBitmap audPeak audRms
rfAntStatsF1 rfBitmapF1A rfRssiF1A rfBitmapF1B rfRssiF1B rfBitmapF1C rfRssiF1C
rfBitmapF1D rfRssiF1D
rfAntStatsF2 rfBitmapF2A rfRssiF2A rfBitmapF2B rfRssiF2B rfBitmapF2C rfRssiF2C
rfBitmapF2D rfRssiF2D >
```

Sample response:

```
< SAMPLE 1 ALL 005 031 102 102 BBBB 31 084 31 065 31 070 31 070 BBBB 31 084 31
065 31 070 31 070 >
```

Variables

Key mapping:

Key	Corresponding command string for value format	Num Char	Notes
qual	CHANNEL_QUALITY	3	
aud- Bitmap	AUDIO_LED_BITMAP	3	Use for simple UIs as this is a direct mirror of the front panel LEDs.
audPeak	AUDIO_LEVEL_PEAK	3	
audRms	AUDIO_LEVEL_RMS	3	
rfAntStats	ANTENNA_STATUS	2	Quadversity: XX for Quad = OFF XXXX for Quad = ON FD-C: Append F2's set of RF
rfBitmap	RSSI_LED_BITMAP	2	Use for simple UIs as this is a direct mirror of the front panel LEDs. See the command example for how this scales to antenna A-D.

	Key	Corresponding command string for value format	Num Char	Notes
	rfRssi	RSSI	3	See the command example for how this scales to antenna A-D.
Notes	None.			

CHAN_QUALITY

Description	Discovery of the channel quality. Axient Digital channels only.
Commands	<pre>< GET x CHAN_QUALITY > < REP x CHAN_QUALITY 005 ></pre>
Variables	Where x is the channel number.
Notes	This is a metered property using SAMPLE; it does not generate a report on a value change. Numeric, 3-character fixed output 000 - 005 255 = Unknown

AUDIO_LED_BITMAP

Description	Discovery of the Audio LED bitmap.
Commands	<pre>< GET x AUDIO_LED_BITMAP > < REP x AUDIO_LED_BITMAP 031 ></pre>
Variables	Where x is the channel number.
Notes	This is a metered property using SAMPLE; it does not generate a report on a value change. Numeric, 3-character fixed output Each bit corresponds to an LED from bottom to top. LEDs 1-4 - Green LEDs 5-7 - Amber LED 8 - Red Example values: 0 = b00000000 - all off 1 = b00000001 - first LED on

	... 131 = b10000011 - after OL that is held, and the 2 bottom green LEDs are on ... 255 = b11111111 - all LEDs on
--	---

AUDIO_LEVEL_PEAK

Description	Discovery of peak audio level.
Commands	< GET x AUDIO_LEVEL_PEAK > < REP x AUDIO_LEVEL_PEAK 102 >
Variables	Where x is the channel number
Notes	This is a metered property using SAMPLE; it does not generate a report on a value change. Numeric, 3-character fixed output Units: dBFS The actual value = the reported value - 120 Value range as reported over command strings: 000 - 120 Value range after conversion to the actual value: -120 - 0 dBFS The AD4 values fall in the range of about -100 to 0 dBFS.

AUDIO_LEVEL_RMS

Description	Discovery of the RMS audio level.
Commands	< GET x AUDIO_LEVEL_RMS > < REP x AUDIO_LEVEL_RMS 102 >
Variables	Where x is the channel number.
Notes	This is a metered property using SAMPLE; it does not generate a report on a value change. Format: Numeric, 3-character fixed output Units: dBFS The actual value = the reported value - 120 Value range as reported over command strings: 000 - 120 Value range after conversion to the actual value: -120 - 0 dBFS The AD4 values fall in the range of about -100 to 0 dBFS.

ANTENNA_STATUS

Description	Discovery of antenna status.
--------------------	------------------------------

Commands	Normal channel, both AB LEDs lit blue: <pre>< GET x ANTENNA_STATUS > < REP x ANTENNA_STATUS BBNN ></pre> Normal channel, both CD LEDs lit red: <pre>< GET 1 ANTENNA_STATUS > < REP 1 ANTENNA_STATUS NNRR ></pre> Quadversity example where antenna A-Blue, B-Red, C-Off, D-Blue: <pre>< GET x ANTENNA_STATUS > < REP x ANTENNA_STATUS BRXB ></pre>
Variables	Where x is the channel number.
Notes	This is a metered property using SAMPLE; it does not generate a report on a value change. Each character represents an antenna ABCD, where the value for each can be: X - Off R - Red B - Blue N - Not applicable, not to be shown Example of ANTENNA_STATUS with QUADVERSITY_MODE=OFF, Antenna AB selected and blue: BBNN Example of ANTENNA_STATUS with QUADVERSITY_MODE=ON: BBBB

RSSI_LED_BITMAP

Description	Discovery of the RSSI LED bitmap.
Commands	Antenna A, 5 LEDs on <pre>< GET x RSSI_LED_BITMAP 1 > < REP x RSSI_LED_BITMAP 1 31 ></pre> Example of all for a Quad=OFF <pre>< GET x RSSI_LED_BITMAP 0 > < REP x RSSI_LED_BITMAP 1 63 > < REP x RSSI_LED_BITMAP 2 63 ></pre> Example of all for a Quad=ON <pre>< GET x RSSI_LED_BITMAP 0 > < REP x RSSI_LED_BITMAP 1 63 > < REP x RSSI_LED_BITMAP 2 63 ></pre>

	< REP x RSSI_LED_BITMAP 3 63 > < REP x RSSI_LED_BITMAP 4 63 >
Variables	Where x is the channel number.
Notes	This is a metered property using SAMPLE; it does not generate a report on a value change. Numeric, 2-character fixed output per antenna: Represents a bitmap of which of the RSSI LEDs are ON from bottom to top. LEDs 1-5 : Amber LED 6 : Red (for Overload and RF Pad engaged indications) Example Variables 00 = b0000000 = All LEDs off 01 = b0000001 = LED1 ON (bottom) ... 31 = b0111111 = LEDs 1-5 ON 32 = b1000000 = LED6 ON (top, OL, all others OFF) ... 63 = b1111111 = All LEDs on 01 = b0000001 = LED1 ON (bottom) Channel Number, Antenna Index 1 : A 2 : B 3 : C 4 : D

RSSI

Description	Discovery of the RSSI.
Commands	For a normal channel (Quadversity = OFF) < GET x RSSI 0 > < REP x RSSI 1 083 > < REP x RSSI 2 064 > For a Quadversity channel (Quadversity = ON) < GET x RSSI 0 > < REP x RSSI 1 083 > < REP x RSSI 2 064 >

	< REP x RSSI 3 082 > < REP x RSSI 4 071 >
Variables	Where x is the channel number.
Notes	This is a metered property using SAMPLE; it does not generate a report on a value change. Numeric, 3-character fixed output per antenna Units: dBm The actual value = the reported value - 120 Value range as reported over command strings: 000 - 120 Value range after conversion to the actual value: -120 - 0 dBm Channel Number, Antenna Index 1 : A 2 : B 3 : C 4 : D

Side Channel Command Strings

TX_MODEL

Description	Discovery of the transmitter model.
Commands	< GET x TX_MODEL > < REP x TX_MODEL UNKNOWN > Report of a transmitter being received: < REP x TX_MODEL AD2 >
Variables	Where x is the channel number.
Notes	Report responses: AD1 AD2 AD3 ADTD ADTQ ADX1 ADX1M ADX2 ADX2FD ADX3 Q5X

	UNKNOWN
--	---------

TX_FW_VER

Description	Discovers the transmitter firmware version.
Commands	<pre>< GET x TX_FW_VER > < REP x TX_FW_VER {ver} ></pre>
Variables	Where x is the channel.
Notes	Package version number reported as Maj.Min.Pack.Build. If the version is followed by an * the previous firmware update was incomplete. Please use Shure Update Utility to re-update the device. The REP returns a blank, padded string if the firmware version is unknown or if there is no transmitter.

TX_DEVICE_ID

Description	Discovery of the transmitter's Device ID.
Commands	<pre>< GET x TX_DEVICE_ID > < REP x TX_DEVICE_ID {yyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyy} ></pre> Report of a transmitter being received: <pre>< REP x TX_DEVICE_ID {LeadVoxyyyyyyyyyyyyyyyyyyyyyyyyyy} ></pre>
Variables	Where x is the channel number. Where the repeating y represents or pads the 31-character string
Notes	31-character string - Device ID of the transmitter being received Unknown - blank, all spaces

TX_BATT_TYPE

Description	Discovery of the transmitter's battery type.
Commands	<pre>< GET x TX_BATT_TYPE > < REP x TX_BATT_TYPE UNKN ></pre> Report when data becomes known:

	< REP x TX_BATT_TYPE LION >
Variables	Where x is the channel number.
Notes	Report responses: LION ALKA NIMH LITH WARN - Tx is charging, either on dock or via USB. Applies only if battery is not LION. UNKN - Either no transmitter or not supported by transmitter

TX_BATT_BARS

Description	Discovery of the transmitter Battery Bars.
Commands	< GET x TX_BATT_BARS > < REP x TX_BATT_BARS 255 > Report when data becomes known: < REP x TX_BATT_BARS 004 >
Variables	Where x is the channel number.
Notes	Numeric, 3-character fixed output 000 to 005 255 - Unknown

TX_BATT_MINS

Description	Discovery of the transmitter battery runtime minutes.
Commands	< GET x TX_BATT_MINS > < REP x TX_BATT_MINS 65535 > Report when data becomes known (example is 2 hours 5 minutes): < REP x TX_BATT_MINS 00125 >
Variables	Where x is the channel number.
Notes	Numeric, 5-character fixed output 00000 to 65532 - Number of minutes of runtime 65533 - Battery communication warning

	65534 - Battery time calculating
	65535 - Unknown, or not applicable

TX_BATT_CHARGE_PERCENT

Description	Discovery of the transmitter battery charge.
Commands	< GET x TX_BATT_CHARGE_PERCENT > < REP x TX_BATT_CHARGE_PERCENT 255 > Report when data becomes known: < REP x TX_BATT_CHARGE_PERCENT 088 >
Variables	Where x is the channel number.
Notes	Numeric, 3-character fixed output 000 to 100 - Percent 255 - Unknown

TX_BATT_CYCLE_COUNT

Description	Discovery of the transmitter Battery Cycle Count.
Commands	< GET x TX_BATT_CYCLE_COUNT > < REP x TX_BATT_CYCLE_COUNT 65535 > Report when data becomes known: < REP x TX_BATT_CYCLE_COUNT 00019 >
Variables	Where x is the channel number.
Notes	Numeric, 5-character fixed output 00000 to 65534 - Number of cycles 65535 - Unknown

TX_BATT_HEALTH_PERCENT

Description	Discovery of the transmitter Battery Health.
Commands	< GET x TX_BATT_HEALTH_PERCENT > < REP x TX_BATT_HEALTH_PERCENT 255 > Report when data becomes known:

	< REP x TX_BATT_HEALTH_PERCENT 088 >
Variables	Where x is the channel number.
Notes	Numeric, 3-character fixed output 000 to 100 - Percent 255 - Unknown

TX_BATT_TEMP_C

Description	Discovery of the transmitter battery temperature in Celsius.
Commands	< GET x TX_BATT_TEMP_C > < REP x TX_BATT_TEMP_C 255 > Report as data becomes known or changes: < REP x TX_BATT_TEMP_C 062 >
Variables	Where x is the channel number.
Notes	Numeric, 3-character fixed output 000 to 254 - Temperature 255 - Unknown, or not applicable The actual value = the reported value - 40.

TX_BATT_TEMP_F

Description	Discovery of the transmitter battery temperature in Fahrenheit.
Commands	< GET x TX_BATT_TEMP_F > < REP x TX_BATT_TEMP_F 255 > Report as data becomes known or changes: < REP x TX_BATT_TEMP_F 062 >
Variables	Where x is the channel number.
Notes	Numeric, 3-character fixed output 000 to 254 - Temperature 255 - Unknown, or not applicable The actual value = the reported value - 40.

TX_INPUT_PAD

Description	Discovery of the transmitter Input Pad.
Commands	< GET x TX_INPUT_PAD > < REP x TX_INPUT_PAD 255 > Report when data becomes known: < REP x TX_INPUT_PAD 000 >
Variables	Where x is the channel number.
Notes	Numeric, 3-character fixed output 000 - Input Pad is ON (-12 dB) 012 - Input Pad is OFF (0 dB) 024 - Input Boost is ON (+12 dB) 255 - Unknown, or Input Pad is not applicable to the transmitter variant The actual value = the reported value - 12. Input Pad is applicable to AD1, ADX1, AD3, and ADX3. All others indicate unknown.

TX_OFFSET

Description	Discovery of the transmitter offset.
Commands	< GET x TX_OFFSET > < REP x TX_OFFSET 255 > Report when data becomes known: < REP x TX_OFFSET 012 >
Variables	Where x is the channel number.
Notes	Numeric, 3-character fixed Range - 000 to 033 255 - Unknown The actual value = the reported value - 12. This means that the actual range is -12 to +21 dB in 1 dB increments.

TX_LOCK

Description	Discovery of the transmitter Lock.
--------------------	------------------------------------

Commands	< GET x TX_LOCK > < REP x TX_LOCK UNKNOWN > Report when data becomes known: < REP x TX_LOCK MENU >
Variables	Where x is the channel number.
Notes	Report responses: NONE POWER MENU ALL UNKNOWN

TX_MUTE_MODE_STATUS

Description	Discovery of the transmitter Mute Mode Status.
Commands	< GET x TX_MUTE_MODE_STATUS > < REP x TX_MUTE_MODE_STATUS UNKNOWN > Report when data becomes known: < REP x TX_MUTE_MODE_STATUS MUTE >
Variables	Where x is the channel number.
Notes	ON - Audio is being transmitted (power switch in "ON" position) MUTE - Audio is being locally muted, but still transmitting RF (power switch is in "OFF" position) UNKNOWN - Either no transmitter or not supported by transmitter

TX_MUTE_BUTTON_STATUS

Description	Discovers the transmitter mute button status of ULXD6 and ULXD8 transmitters.
Commands	< GET x TX_MUTE_BUTTON_STATUS > < REP x TX_MUTE_BUTTON_STATUS status >
Variables	Where x is the channel index.
Notes	Values for status are: PRESSED - Mute button is on, audio is muted RELEASED - Mute button is off, audio is unmuted

	UNKN - Button status is unknown, not applicable, or there is no transmitter
--	---

TX_POLARITY

Description	Discovery of the transmitter Polarity.
Commands	< GET x TX_POLARITY > < REP x TX_POLARITY UNKNOWN > Report when data becomes known: < REP x TX_POLARITY POSITIVE >
Variables	Where x is the channel number.
Notes	Report responses: POSITIVE NEGATIVE UNKNOWN - Either no transmitter or not supported by transmitter

TX_POWER_LEVEL

Description	Discovery of the transmitter power level.
Commands	Axient Digital Tx: < GET x TX_POWER_LEVEL > < REP x TX_POWER_LEVEL 255 > < REP 1 TX_POWER_LEVEL UNKNOWN > AD Report when normal power level is decoded: < REP x TX_POWER_LEVEL 010 > ULXD Tx: < GET x TX_POWER_LEVEL > < REP 1 TX_POWER_LEVEL UNKNOWN > ULXD Report when normal power level is decoded: < REP 1 TX_POWER_LEVEL NORMAL >
Variables	Where x is the channel number.
Notes	Axient Digital Tx: Numeric, 3-character fixed length Transmit power level in mW (for example, 002, 010, or 020)

	255 - Unknown ULXD TxS: LOW NORMAL HIGH UNKNOWN
--	--

TX_POWER_SOURCE

Description	Discovery of the transmitter power source.
Commands	< GET x TX_POWER_SOURCE > < REP x TX_POWER_SOURCE UNKNOWN > Asynchronous report when data becomes known: < REP x TX_POWER_SOURCE BATTERY >
Variables	Where x is the channel number.
Notes	BATTERY EXTERNAL - For example, when powered by external USB UNKNOWN - Either no transmitter or not applicable

TX_TALK_SWITCH

Description	Discovery of the transmitter Talk Switch activity.
Commands	Before a Talk Switch has been pressed, or no transmitter has been decoded: < GET x TX_TALK_SWITCH > < REP x TX_TALK_SWITCH UNKNOWN > User presses Talk Switch, there is a report: < REP x TX_TALK_SWITCH ON > User releases the Talk Switch, there is a report: < REP x TX_TALK_SWITCH OFF > Now that the AD4 has knowledge that a Talk Switch is being used on this session: < GET x TX_TALK_SWITCH > < REP x TX_TALK_SWITCH OFF >

	When the Transmitter goes out of range, that session is lost and the state of the Talk Switch becomes unknown. There is a report (along with the reports for battery level unknown, model unknown, and so on): < REP x TX_TALK_SWITCH UNKNOWN >
Variables	Where x is the channel number.
Notes	ON - Talk Switch button press has been detected OFF - Talk Switch button has been released UNKNOWN - No transmitter detected and/or no Talk Switch button press has been detected up to this point in the transmitter's current connection. Note: OFF and UNKNOWN are treated the same by the AD4 algorithms with respect to Talk Switch routing.

TX_PHANTOM_POWER

Description	Discovery of the transmitter phantom power.
Commands	< GET x TX_PHANTOM_POWER > < REP x TX_PHANTOM_POWER 012 > Report when transmitter's phantom power is off: < REP x TX_PHANTOM_POWER 0000 > Report when phantom power is not applicable or transmitter is out of range: < GET 1 TX_PHANTOM_POWER > < REP 1 TX_PHANTOM_POWER 255 >
Variables	Where x is the channel number.
Notes	Numeric, 3-character fixed 0000 - Off 012 - +12V 048 - +48V 255 - Unknown, or property is not applicable to the transmitter model

TX_HIGH_PASS_FILTER

Description	Discovery of the transmitter high pass filter.
Commands	< GET 1 TX_HIGH_PASS_FILTER > < REP 1 TX_HIGH_PASS_FILTER 080 >

	Report when high pass filter is not applicable or TX is out of range: < GET x TX_HIGH_PASS_FILTER > < REP x TX_HIGH_PASS_FILTER 255 > Report when high pass filter is off: < GET x TX_HIGH_PASS_FILTER > < REP x TX_HIGH_PASS_FILTER 000 >
Variables	Where x is the channel number.
Notes	Numeric, 3-character fixed output. 040 to 240 - Hz 000 - HPF is off 255 - Unknown, or property is not applicable to the Tx variant High pass filter is applicable to AD3 and ADX3. All others indicate unknown.

Transmitter Slots Command Strings

Transmitter slot general description

These commands are only applicable to Axient Digital channels. More details:

- Each channel of AD4 has 8 slots where a transmitter can be registered
 - Specify Channel number 0 to interact with ALL 8 slots on a channel
 - Specify Channel number 1 through 8 to interact with that specific slot on a channel
- The SLOT_STATUS lets you know the status and what to expect from further operations
 - EMPTY - No transmitter exists in the SLOT.
GET - You can GET the other properties but those report as "Unknown" values
SET - Not supported and results in **REP ERR**
 - STANDARD - An AD (standard) transmitter is registered in the slot
 - LINKED.INACTIVE - An ADX (enhanced) transmitter is registered in the slot, but is not currently online
 - STANDARD & LINKED.INACTIVE:
GET - You can GET more useful data for the SLOT_DEVICE_ID and SLOT_TX_MODEL but the other properties report as "Unknown" values
SET - Not supported and results in **REP ERR**
 - LINKED.ACTIVE - An ADX (enhanced) transmitter is registered in the slot and is online.
GET - You can GET more useful data for all SLOT properties
SET - You can SET properties where it is applicable to do so. See the specific command details

Note: As transmitters get linked, unlinked, and moved around there will be corresponding REP events for all of the slot attributes that change. This is a great deal of data, but a control system can readily parse and use the data that it requires.

SLOT_STATUS

Description	Discovery of the slot status.
--------------------	-------------------------------

Commands	An empty slot: <pre>< GET x SLOT_STATUS z > < REP x SLOT_STATUS z EMPTY ></pre> Slot 1 with an AD transmitter: <pre>< GET x SLOT_STATUS 1 > < REP x SLOT_STATUS 1 STANDARD ></pre> Slot 2 with an ADX transmitter that is online: <pre>< GET x SLOT_STATUS 2 > < REP x SLOT_STATUS 2 LINKED.ACTIVE ></pre> The transmitter goes offline: (among others) <pre>< REP x SLOT_STATUS 2 LINKED.INACTIVE ></pre> The user registers an AD1 to Slot 2: <pre>< REP x SLOT_STATUS 2 STANDARD ></pre> The user unlinks or cleans up Slot 2 or moves the transmitter: <pre>< REP x SLOT_STATUS 2 EMPTY ></pre>
Variables	Where x is the channel number and z is the slot number.
Notes	Report responses: EMPTY - No transmitter is registered in the slot STANDARD - An AD (standard) transmitter is registered in the slot LINKED.INACTIVE - An ADX (enhanced) transmitter is registered, linked, but the receiver is not connected to the live transmitter at this time LINKED.ACTIVE - An ADX (enhanced) transmitter is registered, linked, and the receiver is connected. You can remotely adjust the transmitter now.

SLOT_TX_MODEL

Description	Discovery of the transmitter slot's model.
Commands	An empty slot: <pre>< GET x SLOT_TX_MODEL z > < REP x SLOT_TX_MODEL z UNKNOWN ></pre> An occupied slot: <pre>< GET x SLOT_TX_MODEL z > < REP x SLOT_TX_MODEL z ADX1 ></pre>
Variables	Where x is the channel number and z is the slot number.

Notes	Report responses: AD1 AD2 AD3 ADX1 ADX1M ADX2 ADX2FD ADX3 Q5X UNKNOWN
--------------	--

SLOT_TX_DEVICE_ID

Description	Controls the device ID of the transmitter by slot.
Commands	An empty, unregistered slot: <pre>< GET x SLOT_TX_DEVICE_ID z > < REP x SLOT_TX_DEVICE_ID z {yyyyyyyyyyyyyyyyyyyyyyyyyyyyyy} ></pre> A slot with an AD (standard) transmitter: <pre>< GET x SLOT_TX_DEVICE_ID z > < REP x SLOT_TX_DEVICE_ID z {AD1yyyyyyyyyyyyyyyyyyyyyyyyyy} ></pre> An attempt to set the Device ID of an AD transmitter that is not supported: <pre>< SET x SLOT_TX_DEVICE_ID z {Name_1} > < REP ERR ></pre> An attempt to set the Device ID of a Linked.Active ADX transmitter: <pre>< SET x SLOT_TX_DEVICE_ID z {Name_1} > < REP x SLOT_TX_DEVICE_ID z {Name_1yyyyyyyyyyyyyyyyyyyyyyyyyy} ></pre>
Variables	Where x is the channel number and z is the slot number. Where the repeating y represents the spaces returned by the device to pad the response to 31 characters.
Notes	SET only accepts 1 to 8 characters from the set: A-Z,a-z,0-9,!"#\$\$%&'()*+,-./:;<=>?@[\\]^_`~ and space

	The device always responds with a 31-character string Empty slot - blank, all spaces
--	--

SLOT_BATT_BARS

Description	Discovery of the transmitter's battery bars by slot.
Commands	Transmitter is LINKED.ACTIVE: < GET x SLOT_BATT_BARS z > < REP x SLOT_BATT_BARS z 004 > Reports occur as the battery depletes: < REP x SLOT_BATT_BARS z 003 > ... < REP x SLOT_BATT_BARS z 002 > Transmitter is out of range: < GET x SLOT_BATT_BARS z > < REP x SLOT_BATT_BARS z 255 >
Variables	Where x is the channel number and z is the slot number.
Notes	Numeric, 3-character fixed output 000 to 005 - Number of bars 255 - Unknown

SLOT_BATT_MINS

Description	Discovery of the battery runtime by slot.
Commands	Transmitter is LINKED.ACTIVE: < GET x SLOT_BATT_MINS z > < REP x SLOT_BATT_MINS z 00360 > Reports occur as the battery is first calculating, then depletes: < REP x SLOT_BATT_MINS z 65534 > < REP x SLOT_BATT_MINS z 00300 > ... < REP x SLOT_BATT_MINS z 00299 > Transmitter is out of range: < GET x SLOT_BATT_MINS z > < REP x SLOT_BATT_MINS z 65535 >
Variables	Where x is the channel number and z is the slot number.

Notes	Numeric, 5-character fixed output 00000 to 65532 - Number of minutes of runtime 65533 - Battery communication warning. (Check contacts) 65534 - Battery time calculating 65535 - Unknown, or not applicable
--------------	--

SLOT_BATT_CHARGE_PERCENT

Description	Discovery of the battery charge percent by slot.
Commands	Transmitter is LINKED.ACTIVE: < GET x SLOT_BATT_CHARGE_PERCENT z > < REP x SLOT_BATT_CHARGE_PERCENT z 087 > Reports occur as the battery is first calculating, then depletes: < REP x SLOT_BATT_CHARGE_PERCENT z 087 > ... < REP x SLOT_BATT_CHARGE_PERCENT z 086 > ... < REP x SLOT_BATT_CHARGE_PERCENT z 085 > Transmitter is out of range, or not applicable < REP x SLOT_BATT_CHARGE_PERCENT z 255 >
Variables	Where x is the channel number and z is the slot number.
Notes	Numeric, 3-character fixed output 000 to 100 - Percent 255 - Unknown

SLOT_BATT_HEALTH_PERCENT

Description	Discovery of the battery health by slot.
Commands	Transmitter is LINKED.ACTIVE: < GET x SLOT_BATT_HEALTH_PERCENT z > < REP x SLOT_BATT_HEALTH_PERCENT z 097 > Reports as the Transmitter is ON/OFF: < REP x SLOT_BATT_HEALTH_PERCENT z 097 > ... < REP x SLOT_BATT_HEALTH_PERCENT z 255 >

	... < REP x SLOT_BATT_HEALTH_PERCENT z 096 >
Variables	Where x is the channel number and z is the slot number.
Notes	Numeric, 3-character fixed output 000 to 100 - Percent 255 - Unknown

SLOT_BATT_CYCLE_COUNT

Description	Discovery of the battery cycle count by slot.
Commands	Transmitter is LINKED.ACTIVE: < GET x SLOT_BATT_CYCLE_COUNT z > < REP x SLOT_BATT_CYCLE_COUNT z 00013 > Transmitter is out of range, or not applicable: < REP x SLOT_BATT_CYCLE_COUNT z 65535 >
Variables	Where x is the channel number and z is the slot number.
Notes	Numeric, 5-character fixed output 00000 to 65534 - Number of cycles 65535 - Unknown

SLOT_BATT_TYPE

Description	Controls the transmitter slot's battery type.
Commands	Transmitter is LINKED.ACTIVE: < GET x SLOT_BATT_TYPE z > < REP x SLOT_BATT_TYPE z LION > Transmitter is out of range, or a not-supported by Transmitter: < GET x SLOT_POLARITY z > < REP x SLOT_POLARITY z UNKN > < SET x SLOT_POLARITY z ALKA > < REP ERR >
Variables	Where x is the channel number and z is the slot number.
Notes	Report responses:

	LION
	ALKA
	NIMH
	LITH
	UNKN - Either no transmitter or not supported by transmitter

SLOT_INPUT_PAD

Description	Controls the transmitter's slot input pad.
Commands	Transmitter is LINKED.ACTIVE, input pad not engaged: <pre>< GET x SLOT_INPUT_PAD z > < REP x SLOT_INPUT_PAD z 012 ></pre> To engage the input pad: <pre>< SET x SLOT_INPUT_PAD z 0 > < REP x SLOT_INPUT_PAD z 000 ></pre> Transmitter is out of range, or property not supported by the transmitter variant: <pre>< GET x SLOT_INPUT_PAD z > < REP x SLOT_RF_OUTPUT z 255 ></pre> <pre>< SET x SLOT_RF_OUTPUT z 0 > < REP ERR ></pre>
Variables	Where x is the channel number and z is the slot number.
Notes	Numeric, 3-character fixed output 000 - Input Pad is ON (-12 dB) 012 - Input Pad is OFF (0 dB) 024: Input Boost is ON (+12 dB) 255 - Unknown, or Input Pad is not applicable to the transmitter variant The actual value = the reported value - 12. Note: A remotely controllable Input Pad is applicable to ADX1 and ADX3. All others indicate unknown.

SLOT_OFFSET

Description	Controls the transmitter's slot offset.
Commands	Get for Linked.Active transmitter: (default)

	<pre> < GET x SLOT_OFFSET z > < REP x SLOT_OFFSET z 012 > SET for Linked.Active transmitter: to min value: < SET x SLOT_OFFSET z 0 > < REP x SLOT_OFFSET z 000 > SET for Linked.Active transmitter: (demonstrating INC and DEC) < SET x SLOT_OFFSET z INC 5 > < REP x SLOT_OFFSET z 005 > < SET x SLOT_OFFSET z INC 5 > < REP x SLOT_OFFSET z 010 > < SET x SLOT_OFFSET z DEC 2 > < REP x SLOT_OFFSET z 008 > Attempt to GET/SET for an unsupported or out of range transmitter: < GET x SLOT_OFFSET z > < REP x SLOT_OFFSET z 255 > < SET x SLOT_OFFSET z 012 > < REP ERR > </pre>
Variables	Where x is the channel number and z is the slot number.
Notes	Numeric, 3-character fixed Range - 000 to 033 255 - Unknown The actual value = the reported value - 12. The Actual Range is -12 to +21 dB in 1 dB increments.

SLOT_POLARITY

Description	Controls the transmitter's slot polarity.
Commands	Transmitter is LINKED.ACTIVE: <pre> < GET x SLOT_POLARITY z > < REP x SLOT_POLARITY z POSITIVE > < SET x SLOT_POLARITY z NEGATIVE > < REP x SLOT_POLARITY z NEGATIVE > </pre> Transmitter is out of range, or a not-supported transmitter such as ADX2:

	<pre>< GET x SLOT_POLARITY z > < REP x SLOT_POLARITY z UNKNOWN > < SET x SLOT_POLARITY z POSITIVE > < REP ERR ></pre>
Variables	Where x is the channel number and z is the slot number.
Notes	Report responses: POSITIVE NEGATIVE UNKNOWN - Either no transmitter or not supported by transmitter Note: Polarity is only supported by ADX1, ADX1M, and ADX3.

SLOT_RF_OUTPUT

Description	Controls the transmitter's RF output.
Commands	Transmitter is LINKED.ACTIVE: <pre>< GET x SLOT_RF_OUTPUT z > < REP x SLOT_RF_OUTPUT z RF_ON > < SET x SLOT_RF_OUTPUT z RF_MUTE > < REP x SLOT_RF_OUTPUT z RF_MUTE ></pre> Transmitter is out of range: <pre>< GET x SLOT_RF_OUTPUT z > < REP x SLOT_RF_OUTPUT z UNKNOWN > < SET x SLOT_RF_OUTPUT z RF_MUTE > < REP ERR ></pre>
Variables	Where x is the channel number and z is the slot number.
Notes	Report responses: UNKNOWN RF_ON RF_MUTE

SLOT_RF_POWER

Description	REports the actual power level of the unit in mW. Note: Use SLOT_RF_POWER_MODE to set the power level
--------------------	--

Commands	Transmitter is LINKED.ACTIVE: < GET x SLOT_RF_POWER z > < REP x SLOT_RF_POWER z 002 > Transmitter is LINKED.INACTIVE or out of range: < GET x SLOT_RF_POWER z > < REP 255 > Reports as the level changes: < REP x SLOT_RF_POWER z 040 > < REP x SLOT_RF_POWER z 010 > < REP x SLOT_RF_POWER z 255 > Attempt to SET SLOT_RF_POWER reports an ERR: < SET x SLOT_RF_POWER z 10 > < REP ERR >
Variables	Where x is the channel number and z is the slot number.
Notes	Use SLOT_RF_POWER_MODE to SET the power level Numeric, 3-character fixed output 002, 010, 020, 035, 040, 050 - Typical values 255 - Unknown

SLOT_RF_POWER_MODE

Description	Controls the logical power level the unit is operating on.
Commands	Transmitter is LINKED.ACTIVE: < GET x SLOT_RF_POWER_MODE z > < REP x SLOT_RF_POWER_MODE z NORMAL > Transmitter is out of range: < REP ERR > Reports as the level changes: < REP x SLOT_RF_POWER_MODE z HIGH > < REP x SLOT_RF_POWER z 040 > Unit changes frequency to a more restrictive HIGH Power allowed value: < REP x SLOT_RF_POWER z 020 >
Variables	Where x is the channel number and z is the slot number.

Notes	Report responses: UNKNOWN LOW NORMAL HIGH Note: Some RF Bands or modes do not support HIGH and any attempt to use HIGH returns a REP ERR.
-------	---

SLOT_PHANTOM_POWER

Description	Discovery of the slot phantom power.
Commands	< GET x SLOT_PHANTOM_POWER z > < REP x SLOT_PHANTOM_POWER z 012 > Report when transmitter's phantom power is off: < REP x SLOT_PHANTOM_POWER z 0000 > Report when phantom power is not applicable or transmitter is out of range: < GET 1 SLOT_PHANTOM_POWER z > < REP 1 SLOT_PHANTOM_POWER z 255 >
Variables	Where x is the channel number and z is the slot number.
Notes	Numeric, 3-character fixed 0000 - Off 012 - +12V 048 - +48V 255 - Unknown, or property is not applicable to the transmitter model Note: Phantom power is supported by ADX3.

SLOT_HIGH_PASS_FILTER

Description	Discovery of the slot high pass filter.
Commands	< GET 1 SLOT_HIGH_PASS_FILTER z > < REP 1 SLOT_HIGH_PASS_FILTER z 080 > Report when high pass filter is not applicable or TX is out of range: < GET x SLOT_HIGH_PASS_FILTER z > < REP x SLOT_HIGH_PASS_FILTER z 255 >

	Report when high pass filter is off: < GET x SLOT_HIGH_PASS_FILTER z > < REP x SLOT_HIGH_PASS_FILTER z 000 >
Variables	Where x is the channel number and z is the slot number.
Notes	Numeric, 3-character fixed output. 040 to 240 - Hz 000 - HPF is off 255 - Unknown, or property is not applicable to the Tx variant High pass filter is applicable to ADX3. All others indicate unknown.

SLOT_SHOWLINK_STATUS

Description	Discovery of the slot showlink status.
Commands	Transmitter is LINKED.ACTIVE: < GET x SLOT_SHOWLINK_STATUS z > < REP x SLOT_SHOWLINK_STATUS z 005 > Transmitter is out of range: < GET x SLOT_SHOWLINK_STATUS z > < REP x SLOT_SHOWLINK_STATUS z 255 > Reports as the level changes: < REP x SLOT_SHOWLINK_STATUS z 003 > < REP x SLOT_SHOWLINK_STATUS z 004 > < REP x SLOT_SHOWLINK_STATUS z 005 >
Variables	Where x is the channel number and z is the slot number.
Notes	Numeric, 3-character fixed output 001 to 005 255 - Unknown