-20

Scale is to calibrate actual printed dimension. Check both X and Y. Measure between tick 0 and last tick

20 | 40 | 60 | 80 | 100 | 120 | 140 | 160 | 180