

glasstech, inc.

Service Bulletin

Customer Service Department

TELEPHONE: 419-661-9000 FAX: 419-661-9639

SCR Maintenance

Reference 010

To minimize potential failures of Glasstech supplied SCR heating controllers (part numbers E-RRL4CSSAAA481 and E-RRL4CSSAAA482) and fuses as used on your furnace, Glasstech makes the following additional recommendations.

POWER WIRE TERMINATIONS

1. Power wire connections to the SCR heating controller units are improved by installation of wire ferrules on power leads (Weidmuller part no. 36890).
2. After fitting power leads with ferrules, insert them into power terminals of SCR unit.
3. Torque terminals L1 and T1 on units to 50-60 in.-lb. (5.6-6.8 Newton-meters). Use a calibrated dial or digital type torque wrench.
4. Retorque power connections after 48 hours.
5. Retorque power connections at six month intervals after that.

REMOVE AND REPLACE FUSES ONLY

1. Remove both fuses from SCR units.
2. Install new Bussman 170N3437 fuses. Apply 40-50 in.-lbs. (4.5-5.6 Newton-meters) using a calibrated dial or digital type torque wrench.
3. Retorque fuse connections at six month intervals.

MAINTAIN COOLING OF SCR HEATING CONTROLLER UNITS

1. Each operating shift verify that all heating element controller panel fans are operating and freely flowing air. Make sure filters are not clogged, and that fan inlets and panel outlet louvers are unblocked, allowing free air flow.
2. Each week, after furnace has been in production for at least ½ shift, check panel internal temperature with a thermometer or digital temperature sensor to see that internal panel temperatures do not exceed 45 degrees C. This corresponds to maximum design current per element when on for 100% of the time. Refer to the de-rating curve shown on page 2 for more detail as to the enclosure temperature versus current draw characteristics of the unit.

