

glasstech, inc.

Service Bulletin

Customer Service Department

TELEPHONE: 419-661-9000 FAX: 419-661-9639

Glasstech SCR Heating Controllers Maintenance and Replacement

Reference 008

Glasstech supplied SCR heating controllers(part numbers E-RRL4CSSAAA481 and E-RRL4CSSAAA482) used on your furnace can develop problems if proper termination, testing, and element circuit repair procedures are not followed.

TERMINATION PROCEDURES

Heat buildup and dissipation problems can result from loose power wires connected to the termination lugs at the top and bottom of the SCR controller unit. These are the wires bringing the power to the SCR unit, and from the SCR unit to the heating element. **IMMEDIATELY** re-check the tightness of the existing connections by using a torque wrench to torque the terminals to 50-60 in.-lbs. (5.6-6.8 Newton-meters). A calibrated dial or digital type torque wrench is preferred. Hold 50-60 in.-lbs for a minimum of 30 seconds while the multi-strand wire shifts and settles. These termination lugs should then be re-torqued at 6 month intervals.

Whenever SCR controller units are replaced, initially torque them to the specifications above, then re-torque them after 48 hours. This will compensate for any shifting of the multi-strand wire. Re-torque termination lugs at 6 month intervals after that.

UNIT TESTING

1. Do not use a "megger" to test SCR integrity
2. Remove SCR connections if heater hipot is tested or tested with a "megger".
3. If troubleshooting fuse failures, look for line voltage across the fuses.

HEATER ELEMENT INSTALLATION & REPAIR

Remove SCR T1 wire (wire carrying power from SCR unit to the heater element) before welding ribbon sandwich blocks together to repair a break, or before welding termination blocks for a new heater element ribbon. Refer to your Maintenance and Service manual for recommended heater element termination and repair techniques.