

## **PIR SENSOR**

```
void setup()
                                           void loop() {
pinMode(3,INPUT);
                                            int r = digitalRead(3);
pinMode(13,OUTPUT);
                                            if(r == HIGH)
digitalWrite(3,LOW);
Serial.begin(9600);
                                              digitalWrite(13,HIGH);
Serial.print("Calibrating sensor..");
                                              delay(5000);
for(int i=0;i<30;i++)
                                            }
 Serial.print(".");
                                            else{
 delay(1000);
                                              digitalWrite(13,LOW);
                                            }
Serial.println("Calibrating done.");
Serial.println("Sensor Activated");
                                           }
}
```