CIRS BOOTH · CHINMAYA AMRIT MAHOTSAV

Video kiosk technician sheet

The kiosk is a full-screen web page that plays 19 videos and works without internet once set up. Use the first plan that works on this screen. The pen drive (`CIRS-KIOSK` folder) contains everything: the app, the videos, the showreel and these sheets.

Plan A · Windows screen or laptop (pen drive, no internet)

1. Plug in the pen drive, open `CIRS-KIOSK`, double-click `START-KIOSK.bat`. It opens full screen and reopens the browser if someone closes it. To stop: **Alt+Tab** → `STOP-KIOSK.bat`.
2. **Laptop for the whole event:** copy `CIRS-KIOSK` to `C:\CIRS-KIOSK` and run `INSTALL-AUTOSTART.bat` from there. The kiosk then starts at power-on, and sleep is switched off.
3. **Laptop + touch panel:** connect HDMI **and** the USB touch cable. Press **Win+P** → *Second screen only*. If touches land on the wrong display: Control Panel → *Tablet PC Settings* → *Setup* → *Touch input*, then tap the panel.

Plan B · Android with Chrome (link)

1. Open Chrome and go to the kiosk link: `https://me-shivamo.github.io/cirs/`
2. Tap **Download videos** (720p, about 400 MB). For full HD, or with no Wi-Fi, open the link once (phone hotspot is enough), tap **Load from USB stick** → pen drive → `CIRS-KIOSK/videos/hd` → ⋮ **Select all** → **Open**.
3. When it says all 19 are saved, tap **Add to Home screen** (if shown), then **Start**.
4. **Android settings:** display sleep timeout to the maximum (or Developer options → *Stay awake*), lock landscape, set media volume, Do Not Disturb on. Turn off the panel's own power-saving / OSD sleep timer.
5. **Optional lock:** Settings → Security → *App pinning*, then pin Chrome or the CIRS Videos app.

Android without Chrome, or to lock the screen fully: Fully Kiosk Browser

1. Install **Fully Kiosk Browser** from the Play Store, or the APK from fully-kiosk.com.
2. **Start URL:** the kiosk link above. Web Content Settings: *Autoplay videos* ON, JavaScript ON. Web Browsing Settings: *Pull to refresh* OFF. Device Management: *Keep screen on* ON, *Launch on boot* ON.
3. Then follow Plan B steps 2–3 inside Fully Kiosk. (Its Kiosk Mode needs a PLUS licence; without it, use App pinning.)

Touch not working: showreel

Play `CIRS-Showreel.mp4` (pen drive, inside `CIRS-KIOSK`) in the panel's or TV's media player and set **Repeat / Loop**. All 19 videos play with title cards, about 67 minutes.

Visitors' phones

The QR standee opens `…/?visitor`: the same topics, streamed to the phone.

Preparing a pen drive

Copy the whole `CIRS-KIOSK` folder (2.2 GB) onto a pen drive of 8 GB or more. Use **exFAT** or **FAT32** (Android screens often cannot read NTFS). Keep the folder name. Test once on a laptop with `START-KIOSK.bat`.

Staff screen (status, self-test, fixes)

Hold **"Keep Smiling"** (top right) for 5 seconds, or press **Ctrl+Shift+S** on a keyboard. PIN **2026**.

- **Run self-test:** plays 1 second of every video and shows ✓/✗ for each one.
- **Video quality → Lite:** use this if videos stutter on a slow screen. It needs the Lite copies, which are on the pen drive in `videos/lite`.
- **Mode → Loop only:** plays the videos one after another and ignores touches. Use it if touch is unreliable.
- **Volume**, **Download / repair videos**, **Load from USB stick**, **Check for updates**, **Restart app**.
- Send a photo of this screen to the developer. It shows the device, storage and which videos are saved.

Behaviour (normal)

- **When nobody touches the screen for 90 seconds:** a silent showreel starts. Any touch returns to the topics.
- **When a video is paused:** it returns to the topics after 45 seconds.
- **When a video can't load:** after about 8 seconds, it shows a message and goes back.
- **Every few hours, when idle:** the page refreshes itself.