RS-232C Command List

Command for Main Room 1/2

	Command		Reply from Slave
POWER ON /	TOGGLE(On/Off)	"PWR:0"	"PWR:1",
STAND BY	OFF	"PWR:1"	"PWR:2"
STAND BI	ON	"PWR:2"	
	VALUE (direct command)	"VOL:0xxx"	"VOL:xxx"
VOLUME	UP	"VOL:1"	xxx = vol. value as +18 ~-99
VOLUME	DOWN	"VOL:2"	(e.g.) 0dB="VOL:00"
	DOWN		-∞="VOL:-ZZ"
	TOGGLE(On/Off)	"AMT:0"	"AMT:1"
AUDIO MUTE	OFF	"AMT:1"	"AMT:2"
	ON	"AMT:2"	
		"TOB:0xxx"	"TOB:xxx"
TONE CONTROL	VALUE	(xxx = vol. value as	xxx = vol. value as
(BASS)		+6.~-6)	+6 ~-6
(BA33)	UP	"TOB:1"	
	DOWN	"TOB:2"	
		"TOT:0xxx"	"TOT:xxx"
TONE CONTROL	VALUE	(xxx = vol. value as	xxx=vol. value
(TREBLE)		<u>+6 ~-6)</u>	as +6 ~-6
(TREBLE)	UP	"TOT:1"	
	DOWN	"TOT:2"	
	TV	"SRC:1"	"SRC:va", (v ,a= '0' – 'F')
	DVD	"SRC:2"	(v = video, a = audio.)
	VCR1	"SRC:3"	
	DSS/VCR2	"SRC:4" "SRC:9"	(e.g) DVD="SRC:22"
	AUX1	"SRC:9"	
INPUT	AUX2	"SRC:A"	
SOURCE Select	CD	"SRC:C"	
	CD-R	"SRC:D"	
	TAPE	"SRC:E"	
	TUNER	"SRC:F"	
	FM	"SRC:G"	
	AM/MW	"SRC:H"	
	AWINW	51(0.11	
	TOGGLE	"71C:0"	OFF= "71C:1",
7.1Channel Input	OFF	"71C:1"	ON= "71C:1"
7. Tonariner input		"71C:2"	ON= 710.2
	ON		ANIAL OC - "INID:4"
	AUTO	"INP:0"	ANALOG= "INP:1",
INPUT (A/D)	ANALOG	"INP:1"	DIGITAL= "INP:2"
- ()	DIGITAL	"INP:2"	AUTO-ANA= "INP:3"
			AUTO-DIG= "INP:4"
	TOGGLE(On/Off)	"ATT:0"	ATT-OFF= "ATT:1"
AUDIO ATT	OFF	"ATT:1"	ATT-ON= "ATT:2"
	ON	"ATT:2"	"ATT:0" (not analog)
SURROUND MODE	AUTO	"SUR:00"	"SUR:xx"
	STEREO	"SUR:01",	(x = '0' ~'Z')
	DOLBY	"SUR:02",	
	PL2xMOVIE	"SUR:03",	
	PL2 MOVIE	"SUR:04",	
	PL2xMUSIC	"SUR:05",	
	PL2 MUSIC	"SUR:06",	1
	PL2xGAME	"SUR:07",	
	PL2 GAME	"SUR:08",	1
	EX/ES	"SUR:0A",	
	DTS ES	"SUR:0E"	1
	NEO6 CINEMA	"SUR:0F"	
	NEO6 MUSIC	"SUR:0G"	
	Multi Ch. STEREO	"SUR:0H"	
	CS2 CINEMA	"SUR:01"	
	CS2 MUSIC	"SUR:0J"	
	CS2 MONO	"SUR:0K"	
	VIRTUAL	"SUR:0L"	
			I
	DTS	"SUR:0M"	
	DD+PL2xMOVIE	"SUR:00"	
		"SUR:00"	
	DD+PL2xMOVIE	"SUR:00" "SUR:0P"	
	DD+PL2xMOVIE	"SUR:00"	
	DD+PL2xMOVIE DD+PL2xMOVIE	"SUR:00" "SUR:0P" "SUR:0T"	
	DD+PL2xMOVIE DD+PL2xMOVIE SOURCE(PURE) DIRECT	"SUR:00" "SUR:0P" "SUR:0T"	
	DD+PL2xMOVIE DD+PL2xMOVIE	"SUR:00" "SUR:0P"	

RS-232C Command List

Command for Main Room 2/2

	Command		Reply from Slave
SURROUND MODE	TOGGLE	"THX:0"	"THX:x"
(THX+)	OFF	"THX:1"	OFF= "THX:1"
	ON	"THX:2"	ON= "THX:2"
SPEAKER A/B	TOGGLE	"SPK:0"	"SPK:11"(A:OFF B:OFF)
	A-ON	"SPK:12"	"SPK:21"(A:ON B:OFF)
	A-OFF	"SPK:11"	"SPK:12"(A:OFF B:ON)
	B-ON	"SPK:22" "SPK:21"	"SPK:22"(A:ON B:ON)
Tuner Frequency	B-OFF VALUE(frequency direct)	"TFQ:0xxxxx"	
Tuner Frequency	UP	"TFQ:1"	
	DOWN	"TFQ:2"	else FM
		"TFQ:3"	(e.g.
	Auto-UP		"TFQ08750"
			=FM87.50MHz
	Auto-DOWN	"TFQ:4"	
Tuner Preset	VALUE(Preset Number)	"TPR:0ww"	"TPR:ww"
	UP	"TPR:1"	(ww = current preset nr.)
	DOWN	"TPR:2"	0 ~ 50
	PRESET-SCAN START	"TPR:3"	
	PRESET-SCAN STOP	"TPR:4"	
	TOGGLE	"TMD:0"	
FM tuning mode	OFF(Mono)	"TMD:1"	FM-MONO="TMD:1",
	ON(Stereo)	"TMD:2"	FM-AUTO="TMD:2"
	Key0,	"NUM:0",	
	Key1,	"NUM:1",	
	Key2, Key3,	"NUM:2" , "NUM:3" ,	
	Key3, Key4,	"NUM:4" .	
Tuner Numeric keys	Key5,	"NUM:5" ,	ACK
	Key6,	"NUM:6" .	
	Key7,	"NUM:7" ,	
	Key8,	"NUM:8" ,	
	Key9	"NUM:9"	
	Command		Reply from Slave
	TOGGLE	"MNU:0"	non-menu="MNU:1",
SET UP MENU	OFF(EXIT)	"MNU:1"	on menu="MNU:2"
62. G. ME.16	ON	"MNU:2"	
	ENTER	"MNU:3"	
	UP DOWN	"CUR:1" "CUR:2"	
	LEFT	"CUR:3"	ACK
	RIGHT	"CUR:4"	
Test Tone	On/Off (TOGGLE)	"TTO:0"	
rest rolle	OFF(Exit from Test tone)	"TTO:1"	"TTO:1xy" (OFF)
	ON(Generate Test tone)	"TTO:2"	"TTO:2xy" (ON)
	NEXT Channel	"TTO:3"	(x = auto'0'/manual'1',
	PREV Channel	"TTO:4"	y = ch.,)
	VALUE (Front L)	"CHL:02xxx"	"CHL:yxxx"
	VALUE (Front R)	"CHL:03xxx"	(y = channel,
	VALUE (Center)	"CHL:04xxx"	x = channel level)
	VALUE (Surr. L)	"CHL:06xxx"	
	VALUE (Surr. R)	"CHL:07xxx"	(y=2,3,4,6,7,8,9,A,B)
	VALUE (Deals L (mage)	"CHL:09xxx"	(x=+10 ~ -10)
Channel Level	VALUE (Back L /mono)	"CHL:09XXX	
	VALUE (Back R) VALUE (Sub W)	"CHL:0Bxxx"	
	VALUE (Sub W)	CLICODAXA	
		"CHL:1y" (y=channel)	
	Level Up	(v=2.3.4.6.7.8.9.A.B)	
	Leel Down	"CHL:2y" (y=channel	
		(y=2,3,4,6,7,8,9,A,B)	
Dolby Head Phone	BYPASS	"DHM:0"	
mode	DH1_(5.1ch)	"DHM:1" "DHM:2"	
	DH1_PL2movie_2ch) DH1_PL2music_2ch)		"DHM:x"
	DH1_PL2music_2cn) DH2_(5.1ch)	"DHM:3" "DHM:4"	x= dolby HP mode
	DH2_PL2movie_2ch)	"DHM:5"	A- dolby iti itildue
	DH2_PL2music_2ch)		
	DH3_(5.1ch)	"DHM:6" "DHM:7"	
	DH3_PL2movie_2ch)	"DHM:8"	
	DH3_PL2music_2ch)	"DHM:9"	
	TOGGLE	"NGT:0"	OFF= "NGT:1",
Night Mode			
Night Mode (Dynamic	OFF	"NGT:1"	ON= "NGT:2"
•	ON	"NGT:2"	
(Dynamic			ON= "NGT:2" "SPL:xx" OFF="SPL:00"

RS-232C Command List

Command for Multi Room 1/1

	Command		Reply from Slave
	TOGGLE	"MPW:0"	Multi Off= "MPW:1",
Multi Room	OFF	"MPW:1"	Multi On= "MPW:2"
	ON	"MPW:2"	
	VALUE	"MVL:0xxx"	"MVL:xxx"
Multi Room VOLUME	UP	"MVL:1"	xxx = vol. value as
	DOWN	"MVL:2"	0 ~-90
Multi Room	TOGGLE	"MAM:0"	MUTE OFF= "MAM:1"
AUDIO MUTE	OFF	"MAM:1"	MUTE ON= "MAM:2"
	ON	"MAM:2"	
	TOGGLE	"MSP:0"	"MSP:1"
Multi Room Speaker	OFF	"MSP:1"	"MSP:2"
	ON	"MSP:2"	
	VALUE	"MSV:0xxx"	"MSV:xxx"
Multi SPKR VOLUME	UP	"MSV:1"	xxx = vol. value as
viditi OF RIC VOLOME	DOWN	"MSV:2"	0 ~-90
Multi SPKR	TOGGLE	"MSM:0"	MUTE OFF= "MSM:1"
	OFF	"MSM:1"	MUTE ON= "MSM:1"
AUDIO MUTE		"MSM2"	MUTE ON= MSM:2
	ON	"IVISIVI2"	(1100) (01 (51)
Multi		(2400.4)	"MSC:va", (v ,a= '0' - 'F')
SOURCE Select	TV	"MSC:1"	(v = video, a = audio.)
	DVD	"MSC:2"	
	VCR1	"MSC:3"	
	DSS/VCR2	"MSC:4"	(e.g) DVD="MSC:22"
	AUX1	"MSC:9"	
	AUX2	"MSC:A"	
	CD	"MSC:C"	
	CD-R	"MSC:D"	
	TAPE	"MSC:E"	
	TUNER	"MSC:F"	
	FM	"MSC:G"	
	AM	"MSC:H"	
Multi	VALUE	"MTF:0xxxxx"	"MTF:xxxxx"
		(xxxxx = freq.)	
Tuner Frequency	UP	"MTF:1"	(xxxxx = Frequency)
	DOWN	"MTF:2"	if(xxxxx<02000) AM
	Auto-UP	"MTF:3"	else FM
	Auto-DOWN	"MTF:4"	
Multi	VALUE	"MTP:0ww" (ww = preset nr.)	"MTP:ww"
Tuner Preset	UP	"MTP:1"	(ww = current preset nr.)
	DOWN	"MTP:2"	ww=01~50
	SCAN Start	"MTP:3"	
	SCAN Stop	"MTP:4"	
Multi	TOGGLE	"MTM:0"	except FM = "MTM:0"
Tuner mode	OFF (MONO)	"MTM:1"	MONO= "MTM:1"
	ON (AUTO)	"MTM:2"	STEREO= "MTM:2"

RS-232C Command List

Status Request Command & Answer for Main Room 1/2

Status request		Status answer	and feedback
POWER	"PWR:?"	OFF	"PWR:1"
VOLUME	"VOL:?"	ON Volume value = xxx	"PWR:2" "VOL:xxx"
		OFF	"AMT:1"
AUDIO MUTE	"AMT:?"	ON	"AMT:2"
TONE BASS	"TOB:?"	Bass value = xxx	"TOB:xxx"
TONE TREBLE	"TOT:?"	Treble value = xxx Video+Audio source	"TOT:xxx"
INPUT SOURCE Select	"SRC:?"	(v ,a= '0' – 'F')	"SRC:va"
		(v = video, a = audio.)	
7.1ch Channel	"71C:?"	OFF	"71C:1"
		ON	"71C:2"
		ANALOG DIGITAL	"INP:1" "INP:2"
INPUT (A/D)	"INP:?"	AUTO(ANALOG)	"INP:3"
		AUTO(DIGITAL)	"INP:4"
AUDIO ATT	"ATT:?"	OFF	"ATT:1"
Surr. Mode	"SUR:?"	ON AUTO	"ATT:2" "SUR:0"
Surr. Mode	SUR.?	STEREO	
		DOLBY	"SUR:1", "SUR:2",
		PL2xMOVIE	"SUR:3",
		PL2 MOVIE	"SUR:4",
		PL2xMUSIC PL2 MUSIC	"SUR:5", "SUR:6",
		PL2xGAME	"SUR:7",
		PL2 GAME	"SUR:8",
		EVIEO	"OUD A"
		EX/ES DTS ES	"SUR:A", "SUR:E"
		NEO6 CINEMA	"SUR:F"
		NEO6 MUSIC	"SUR:G"
		Multi Ch. STEREO	"SUR:H" "SUR:I"
		CS2 CINEMA CS2 MUSIC	"SUR:I" "SUR:J"
		CS2 MONO	"SUR:K"
		VIRTUAL	"SUR:L"
		DTS	"SUR:M"
		DD+PL2x MOVIE	"SUR:O"
		DD+PL2x MUSIC	"SUR:P"
		SOURCE(PURE) DIRECT	"SUR:T"
		DOLBY HEAD PHONE	"SUR:U"
		THX AUTO	"THX:0"
		THX+DOLBY DIGITAL	"THX:2"
		THX+PL2x MOVIE THX+PL2 MOVIE	"THX:3" "THX:4"
		THX+EX/ES	
		THX EX+DD	"THX:A" "THX:C"
		THX+DTS ES THX+NEO6 CINEMA	"THX:E"
		THX+NEO6 CINEWA	"THX:F" "THX:M" "THX:O"
		THX+DTS THX+DD+PL2x	"THX:O"
THX. Mode	"THX:?"	THX AUTO	"THX:0" "THX:2"
		THX+DOLBY DIGITAL THX+PL2x MOVIE	"THX:3"
		THX+PL2 MOVIE	"THX:4"
		THX+EX/ES	"THX:A"
		THX EX+DD	"THX:C" "THX:E"
		THX+DTS ES THX+NEO6 CINEMA	"THX:E" "THX:F"
		THX+DTS	"THX:M"
		THX+DD+PL2x	"THX:O"
SPEAKER A/B	"SPK:?"	A:OEE B:OEE	"SPK:11"
OF CARER A/D	SPN:/	A:OFF B:OFF A:ON B-OFF	"SPK·21"
		A:OFF B-ON A:ON B-ON	"SPK:12" "SPK:22"

RS-232C Command List

Status Request Command & Answer for Main Room 2/2

Status request		Status answer and feedback	
Tuner Frequency	"TFQ:?"	xxxxx = frequency if(xxxxx<02000), band=AM else band=FM	"TFQ:xxxxx"
Tuner Preset	"TPR:?"	xx = preset number (01~50)	"TPR:xx"
		(except FM)	"TMD:0"
FM Tuning Mode	"TMD:?"	OFF (MONO)	"TMD:1"
		ON (AUTO)	"TMD:2"
SET UP MENU	"MNU:?"	OFF ON	"MNU:1" "MNU:2"
		OFF (x,y = don't care)	"TTO:1xy"
Test Tone	"TTO:?"	ON (x=auto/manual, y=ch.)	"TTO:2xy"
	"CHL:? y"	Front L	"CHL:2xxx"
	(y = channel)	Front R	"CHL:3xxx"
		Center	"CHL:4xxx"
Channel Level		Surr. L Surr. R	"CHL:6xxx" "CHL:7xxx"
		Back L, Back(mono)	"CHL:9xxx"
		Back R	"CHL:Axxx"
		Sub Woofer	"CHL:Bxxx"
Night Mode	"NGT:?"	OFF	"NGT:1"
Night Mode	NG1.	ON	"NGT:2"
HT-EQ	"REQ:?"	OFF	"REQ:1"
		ON	"REQ:2"
SLEEP TIMER	"SLP:?"	Sleep time (xx = 00 ~ 99) x = signal	"SLP:xx"
Signal Format	"SIG:?"	x = '0' :No detect '1' :D DIGITAL AC-3 '2' : D DIGITAL SURR. '3' : D DIGITAL SURR. EX '4' : DTS '5' : DTS ES DISCREATE '6' : DTS ES MATRIX '7' : AAC '8' : MPEG '9' : MLP 'A' : PCM 'B' : HDCD 'C' : DSD 'D' : reserved 'E' : reserved 'F' : OTHER x = Freq.	"SIG:x"
Sampling Frequency	"SFQ:?"	x = Fieq. '0' : Out of range '1' : 32kHz '2' : 44.1kHz '3' : 48kHz '4' : 88.2kHz '5' : 96kHz '6' : 176.4kHz '7' : 192kHz	"SFQ:x"
Encoded Channel Status	"CHS:?"	xy = Ch.Stat xy = "00": Not available 'x' = '8' ~ 'F' bit3 : 1 bit2 : LFE bit1 : Surr. L bit0 : Surr. R 'y' = '0' ~ 'F' bit3 : reserved(don't care) bit2 : Front L bit1 : Front R bit0 : Center	"CHS:xy"

Nov 24 2004 Marantz America, Inc.

Model: SR7500/8500 RS232C interface data

Status Request Command & Answer for Multi Room

Status request		Status answer and feedback	
Multi Room power	"MPW:?"	OFF	"MPW:1"
ON/Off	IVIT VV. ?	ON	"MPW:2"
Multi Room VOLUME	"MVL:?"	Volume value = xxx	"MVL:xxx"
Multi Room	"MAM:?"	OFF	"MAM:1"
AUDIO MUTE	IVIAIVI. ?	ON	"MAM:2"
Multi Room	"MVS:?"	VARIABLE	"MVS:1"
Volume Set	IVIV 5. ?	FIXED	"MVS:2"
Multi Room	"MSP:?"	OFF	"MVM:1"
SPEAKER ON/OFF	WISP.?	ON	"MVM:2"
Multi SPKR VOLUME	"MSV:?"	"MSV:0xxx"	"MSV:0xxx"
Multi SPKR	"MSM:?"	OFF	"MSM:1"
AUDIO MUTE		ON	"MSM:2"
Multi SPKR	"MST:?"	VARIABLE	"MST:1"
Volume Set	IVIO1.!	FIXED	"MST:2"
Multi Room		Video+Audio source	
SOURCE Select	"MSC:?"	(v ,a= '0' - 'F')	"MSC:va"
		(v = video, a = audio.)	
Multi Room		xxxxx = frequency	
IVIUILI ROOM	"MTF:?"	if(xxxxx<02000), band=AM	"MTF:xxxxx"
Tuner Frequency		else band=FM	
Multi Room	"MTP:?"	xx = preset number	"MTP:xx"
Tuner Preset	WITE.:	(01~50)	WIII .XX
Multi Room		(except FM)	"MTM:0"
Tuner Mode	"MTM:?"	OFF (MONO)	"MTM:1"
		ON (AUTO)	"MTM:2"

RS-232C Command List

Special Status request and Status answer list

	Command from Host	Reply from Slave
Auto status feedback	"AST:x" (x = '0' ~ 'F')	same as
(The product	bit 3 : Layer 4 (1 = Enable, 0 = Disable)	command define
default is disable all auto status feedback.)	bit 2 : Layer 3 (1 = Enable, 0 = Disable)	
	bit 1 : Layer 2 (1 = Enable, 0 = Disable)	
	bit 0 : Layer 1 (1 = Enable, 0 = Disable)	

Status request		Status answer and feedback
Auto status feedback	"AST:?"	see command list

Layer of the Auto statuses

Layer of the Auto statuses			
Status		Layer	
POWER	"PWR:"	1	
AUDIO MUTE	"AMT:"	1	
VIDEO MUTE	"VMT:"	1	
VOLUME	"VOL:"	1	
TONE BASS	"TOB:"	1	
TONE TREBLE	"TOT:"	1	
SOURCE Select	"SRC:"	1	
7.1 Channel Input	"MCH:"	1	
DISPLAY	"DIP:"	1	
OSD	"OSD:"	1	
Test Tone	"TTO:"	1	
Multi Room POWER	"MPW:"	1	
Multi Room Audio Mute	"MAM:"	1	
Multi Room VOLUME	"MVL:"	1	
Multi SPKR volume	"MSV:"	1	
Multi SPKR Mute	"MSM:"	1	
Multi Room Source Sel.	"MSC:"	1	
SPEAKER A/B	"SPK:"	1	
Status		Layer	
SLEEP	"SLP:"	2	
Surr. Mode	"SUR:"	2	
Tuner Preset	"TPR:"	2	
Tuner Mode	"TMD:"	2	
Multi Room Volume Set	"MVS:"	2	
Multi SPEAKER	"MSP:"	2	
Multi SPKR volume set	"MST:"	2	
Multi Room SLEEP	"MSL:"	2	
Multi Room Tuner Preset	"MTP:"	2	
Multi Room Tuner Mode	"MTM:"	2	
Status		Layer	
AUDIO ATT	"ATT:"	3	
INPUT (A/D)	"INP:"	3	
Dolby Head Phone mode	"DHM:"	3	
Night Mode	"NGT:"	3	
HT-EQ	"REQ:"	3	
Tuner Frequency	"TFQ:"	3	
Multi Room Tuner Freq.	"MTF:"	3	
Status		Layer	
SETUP MENU	"MNU:"	4	
Simple Setup	"SSU:"	4	
Lip Sync Delay	"LIP:"	4	
Channel Level	"CHL:"	4	
Signal Format	"SIG:"	4	
Sampling Frequency	"SFQ:"	4	
Channel Status	"CHS:"	4	