

mounts on the wearer's back:
both load paths end here, in the wearer

left SRL, 8.2 kg,
free in space

right SRL, 8.2 kg,
free in space

the wearer carries every reaction load
and does not issue the commands

work surface: not contacted,
nothing is braced against it

the operator commands both arms from across the room

