STEERING DRIVER CABLE LABELS

DUAL DC MOTOR DRIVER WITH CURRENT SERNSOR AND FEEDBACK

MOTOR B		MOTOR A				
A0 GND +5V D13 D12 A1	MB P -5V +5V MB MB MB C	A2 GND +5V D11 D10 A3 MA P -5V +5V MA MA MA C				
	R B tiometer	MOTOR A potentiometer MOTOR A	30 V	30 V	30 V	30 V
J.NAN.	NO 5V	USB HUB 5V		5 V		
J.NANO USB		WIFI USB	MEGA	USB	BMS L	JSB
			MEGA	USB		