

Xtruck OHW808 Support List - CUMMINS

Function		
Read ECU Information	√	
Read fault codes	√	
Freeze Frame Data	√	
Real Time Clock	√	
Read/Send Features and Parameters Template File	√	
ECM Password	√	
ECM Password Removal	√	
Unlock	√	
Audit Trail	√	
Demo Mode	√	
Display wiring diagram	√	
Expert Function	√	
Packet optimization	√	
Packet conversion	√	
Erase Fault Code	1	Erase Fault Code
	2	Erase OBD fault code
	3	Erase fault code(Expert Mode)
	4	Erase Aftertreatment Fault Code (2772,2773)
Trip Information	1	All Trips(Cumulative)
	2	Trip Since Last Reset
	3	Trip Since Last Reset Drive(Vehicle Speed > 0)
	4	Trip Information Reset
	1	Monitor
	2	Aftertreatment

Function	list	
Read data stream	3	Aftertreatment - Diesel Particulate Filter
	4	Aftertreatment - Diesel Particulate Filter Stationary Regeneration
	5	Aftertreatment - SCR
	6	Automatic Request Changelock Request
	7	Cooling and Lubrication
	8	Dataplate
	9	Date Time Stamp Parameters
	10	Driver Operation Interlock
	11	ECM Commanded Values
	12	ECM Information
	13	ECM internal datalogger
	14	EGR Turbocharger Performance
	15	EGR and Turbocharger Performance
	16	Electrical
	17	Engine Braking
	18	Engine Protection
	19	Feature Available
	20	Feature Label
Read data stream	21	Feature enable
	22	Fuel System
	23	Green House Gas Idle ShutDown Parameters
	24	Green House Gas Low Idle Parameters
	25	Green House Gas Powertrain Parameters
	26	Green House Gas Vehicle Speed Limiter Parameters
	27	Hard Start
	28	Ignition
	29	Ignition Voltages
	30	Knock Sensors

Function	list	
Read data stream	31	Lamps
	32	Low Power/Fuel Economy
	33	Mandatory SnR parameters
	34	Adjustable but non restorable parameters
	35	White Smoke/Engine Stumble
	36	No/Slow Start
	37	Non Template parameters
	38	Normal adjustable features
	39	Normal adjustable parameters
	40	OEM Domain 2 Parameters
	41	OEM Security
	42	Power Electronics
Read data stream	43	Real Time parameters
	44	Relays
	45	Reset Parameters
	46	Road Speed Governor Restriction
	47	SAE J1939 Source Address Parameters
	48	Save and Restore only
	49	Sea Trial Acceleration
	50	Sea Trial Steady State
	51	Sensors
	52	Stop Start
	53	Sub Feature Label
	54	Switches
	55	Transmission
	56	Trim Passwords
	57	Trip Fuel Report
	58	Trip Information

Function	list	
	59	Other
Actuation test Or Advanced ECM Data	1	Aftertreatment Close-Coupled Catalyst Outlet Temperature History Log
	2	Aftertreatment Current Based Particulate Matter Sensor Regeneration Test
	3	Aftertreatment DEF Contamination History
	4	Aftertreatment DEF Doser Air Valve Override Test
	5	Aftertreatment DEF Multi Dosing Rate Doser Override Test
	6	Aftertreatment DPF Ash Load History Log
	7	Aftertreatment DPF Missing Event Log
	8	Aftertreatment DPF Regeneration History
	9	Aftertreatment DPF Regeneration Trigger Type History
	10	Aftertreatment Diesel Exhaust Fluid Doser Accuracy Test
Actuation test Or Advanced ECM Data	11	Aftertreatment Diesel Exhaust Fluid Pump Heater Test
	12	Aftertreatment Diesel Exhaust Fluid System Leak Test
	13	Aftertreatment Diesel Particulate Filter Deep Clean Regeneration
	14	Aftertreatment Diesel Particulate Filter Regeneration
	15	Aftertreatment Diesel Particulate Filter Regeneration Analyzer
	16	Aftertreatment Diesel Particulate Filter Restriction Test
	17	Aftertreatment Dosing System Test Log
	18	Aftertreatment Electrical Heater Functionality Test
	19	Aftertreatment Engine Out NOx Sensor Test

Function	list	
	20	Aftertreatment Filter DeGreening
	21	Aftertreatment Forced Mission Regeneration
	22	Aftertreatment High NOx Reset
	23	Aftertreatment High Sulphur Fuel History
	24	Aftertreatment History
Actuation test Or Advanced ECM Data	25	Aftertreatment History Ver 2
	26	Aftertreatment Hydrocarbon Doser System Test
	27	Aftertreatment Inducement Witness Test
	28	Aftertreatment Maintenance
	29	Aftertreatment Maintenance Filter Installation
	30	Aftertreatment Max Soot Level Per Regen History Reset
	31	Aftertreatment Mileage Based DPF Ash Cleaning
	32	Aftertreatment Particulate Matter Sensor Regeneration
	33	Aftertreatment Reset Dosing Learn
	34	Aftertreatment SCR Catalyst Cold Soak Override
	35	Aftertreatment SCR Catalyst Desulphurization
	36	Aftertreatment SCR Maintenance
	37	Aftertreatment SCR Maintenance 2
	38	Aftertreatment SCR Performance Test
	39	Aftertreatment SCR Regeneration History

Function	list	
Actuation test Or Advanced ECM Data	40	Aftertreatment SCR System Cleaning
	41	Aftertreatment SCR System Cleaning Test
	42	Aftertreatment SCR System Health Monitor
	43	Aftertreatment SCR System Test
	44	Aftertreatment Shutoff Valve and Injector Override Test
	45	Aftertreatment System Out NOx Sensor Test
	46	Aftertreatment Temperature Sensor Test
	47	Aftertreatment Thermal Cycle Count Reset
Actuation test Or Advanced ECM Data	48	Aftertreatment Underfloor Catalyst Outlet Temperature History Log
	49	Aftertreatment Warmup DOC Regeneration Test
	50	Air Handling Performance Test
	51	Alternator Feedback Monitor
	52	Battery Pack Fan Control
	53	Boost Power History
	54	Centinel Operational Test
	55	Charge Throttle Actuator Test
	56	Compressor Bypass Control Valve Override Test
	57	Compressor Bypass Valve Test
	58	Cooling Fans Control Test
	59	Cylinder Bank Cutout Test

Function	list	
Actuation test Or Advanced ECM Data	60	Cylinder Cutout Test
	61	Cylinder Performance Test
	62	DEF Dual Doser Override Test
	63	DPF Ash Reset
	64	Diesel Exhaust Fluid Doser Air Supply Valve Click Test
	65	Diesel Exhaust Fluid Doser Pump Air Solenoid Click Test
	66	Diesel Exhaust Fluid Doser Pump Manual Override Test
	67	Diesel Exhaust Fluid Doser Pump Override Test
	68	Diesel Exhaust Fluid Doser Purge Counter
Actuation test Or Advanced ECM Data	69	Diesel Exhaust Fluid Doser System Heater Test
	70	Diesel Exhaust Fluid Metering Unit Click Test
	71	Diesel Exhaust Fluid Pump Filter Life Reset
	72	Diesel Exhaust Fluid Reverting Valve Test
	73	Dual Fan Clutch Control
	74	Dual Fueling Table Override
	75	Dual Snorkel Actuator Calibration
	76	Duty Cycle Monitor
	77	ECM Data Extraction
	78	EFC Actuator Override Test
	79	EGR Delta Pressure Auto Zero Test

Function	list	
	80	EGR Valve Test
Actuation test Or Advanced ECM Data	81	Electric Coolant Pump Test
	82	Electric Fan Control
	83	Electric Fuel Lift Pump Override Test
	84	Electronic Fuel Control Actuator Test
	85	Engine Compression And Air Handling System Test
	86	Engine Fuel Supply Pump Override Test
	87	Engine Priming Pump Override Test
	88	Engine Protection Auxiliary Discrete Input 1
	89	Engine Protection Auxiliary Pressure 1
	90	Engine Protection Auxiliary Temperature 1
	91	Engine Protection Bank Vacuum Detection
Actuation test Or Advanced ECM Data	92	Engine Protection Boost Pressure Differential
	93	Engine Protection Catalyst Outlet Temperature
	94	Engine Protection Witness Test
	95	Engine State Monitor
	96	Ether Injection Reset
	97	Ether Injection Test
	98	Exhaust Throttle Actuator Install and Calibration
	99	Exhaust Throttle Actuator Test

Function	list	
	100	Exhaust Throttle Auto Zero Test
	101	Exhaust Throttle Hysteresis Test
	102	Fan Override Test
	103	Fast Idle Warmup Test
	104	Fault Acknowledge
Actuation test Or Advanced ECM Data	105	Fuel Cell Engine Duty Cycle Monitor
	106	Fuel Cell Engine Stack Air Back Pressure Valve Override Test
	107	Fuel Cell Engine Stack Air Bypass Valve Override Test
	108	Fuel Cell Engine Stack Inlet Air Shutoff Valve Override Test
	109	Fuel Cell Fan Control
	110	Fuel Consumption Monitor
	111	Fuel Control Valve Test
	112	Fuel Filter Life Monitor
	113	Fuel Injector Control Reset
	114	Fuel Injector Life Reset
	115	Fuel Injector Performance Test
	116	Fuel Injector Power Control Reset
	117	Fuel Injector Reset
	118	Fuel Level Override Test
	119	Fuel Metering Valve Injector Override Test

Function	list	
Actuation test Or Advanced ECM Data	120	Fuel Pump Life Reset
	121	Fuel Pump Maintenance
	122	Fuel Purge Valve Click Test
	123	Fuel Shutoff Valve Click Test
	124	Fuel Shutoff Valve Override Test
	125	Fuel System Leakage Test
	126	Fuel System Performance Monitor
	127	Fuel System Table Reset
	128	Fuel Water Drain Valve Click Test
Actuation test Or Advanced ECM Data	129	Fuel or Timing System Table Reset
	130	Gas Throttle Control Test
	131	Glow Plug System Test
	132	HPCR Fuel Pump Performance Test
	133	HPCR Fuel System Supply Capacity Test
	134	HPCR Rapid Leak Test
	135	Heated Oxygen Sensor Test
	136	High Pressure Common Rail High Pressure Test
	137	High Pressure Common Rail Injector Setup
	138	High Pressure Fuel System Actuator Override Test
	139	Hybrid Engine Start Stop Override

Function	list	
	140	Hydrocarbon Air Shutoff Valve Override Test
	141	Hydrocarbon Fuel Shutoff Valve Override Test
Actuation test Or Advanced ECM Data	142	Hydrocarbon Injector Override Test
	143	Idle shutdown override
	144	Immobilizer Installation
	145	Injector Check Valve Diagnostics Test
	146	Injector Maintenance
	147	Intake Air Heater Override
	148	Intake Throttle Actuator Test
	149	LIN Error Counters Reset
	150	Lean Oxygen Mass Metric History Log
	151	Maintenance Monitor
	152	Nissan Pusher Fan Test
Actuation test Or Advanced ECM Data	153	OEM Factory Inducement Reset
	154	OEM Oil Change Monitor
	155	Oil Life Monitor
	156	Open Loop Mode Lock-In Test
	157	Piezo Fuel System Conditioning
	158	Prelube Control
	159	SAE J1939 Datalink Control Test

Function	list	
Data	160	Setup for Dynamometer
	161	Shut Off Valve Solenoid Actuator Test
	162	Single Bank Cutout Test
	163	Starter Intake Air Heater Override Test
	164	Starter Lockout Relay Driver Override Test
Actuation test Or Advanced ECM Data	165	Stop Start Active Inhibits Monitor
	166	Stop Start Service Inhibit
	167	Stop Start Ver2 History Logs
	168	Stop Start Ver2 Recent Restart Logs
	169	TMS eHeaters Control
	170	Thermal Management System Battery Refrigerant Compressor Override Test
	171	Thermal Management System Manual Deaeration
	172	Thermal Management System eHeaters Overheat Unlock
	173	Turbine Bypass Valve Test
	174	Turbo Bypass Valve Electronic Actuator Calibration
	175	Turbo Bypass Valve Electronic Actuator Install and Calibrate
	176	Turbo Bypass Valve Hysteresis Test
	177	Turbocharger Life Monitor
	178	VGT 2 Electronic Actuator Installation and Calibration
	179	VGT 2 Hysteresis Test

Function	list	
Actuation test Or Advanced ECM Data	180	VGT Electronic Actuator Installation and Calibration
	181	VGT Hysteresis Test
	182	VIN Security
	183	Variable Geometry Turbo 2 Actuator Test
	184	Variable Geometry Turbo Actuator Test
	185	xEV Battery Pack Isolation Reset
	186	xEV Derate Lamp Monitor
Features and Parameters	1	AEM Trend Log
	2	Acceleration Noise Control
	3	Accelerator Based Torque Selection
	4	Accelerator Interlock
	5	Accelerator Options
	6	Adjustable Auxiliary Pressure Sensor
	7	Adjustable Auxiliary Temperature Sensor
	8	Adjustable Low Idle Speed
	9	Aftertreatment
	10	Aftertreatment Diesel Particulate Filter
	11	Agility Average Fuel Utilization
	12	Agility Driver Feedback Info
	13	Agility Eco Mode Utilization
	14	Agility Fuel Cabinet Information

Function	list	
	15	Agility Fuel Level Configuration
	16	Agility High Pressure Shut Off Valve Status
	17	Agility High Pressure Tank Valve Status
Features and Parameters	18	Agility Low Fuel Warning Configuration
	19	Agility Performance Manager
	20	Agility Starter Lockout Status
	21	Agility System Information
	22	Agility Vehicle Range and Fuel Economy
	23	Air Conditioner Control
	24	Air Conditioner Switch
	25	Air Filter Differential Pressure
	26	Air Inlet Restriction Monitor
	27	Air Intake Restriction Monitor Diagnostics
	28	Air Processing Unit Control
	29	Air Shut Off Valve
	30	Alternate Torque
	31	Alternator Failure Warning
	32	Alternator Sensor Information
	33	Anti-Lock Brake (ABS) Controller
	34	Articulated System Status Based Torque Limit
	35	Automated Driving System Controller
	36	Automatic Boost Power

Function	list	
Features and Parameters	37	Auxiliary Governor Control
	38	Auxiliary OEM CAN Baud Rate Select
	39	BTMS Auxiliary Heater
	40	Battery Conservation
	41	Battery Fan Control
	42	Battery Power Required Lamp
	43	Boost Power
	44	Brake Air Pressure Sensor
	45	Broadcasted Percent Power
	46	Cabin Temperature Sensor
	47	Centinel Oil System
Features and Parameters	48	Charge Air Cooler Outlet Temperature Sensor
	49	Charge Air Cooler Water Temperature Sensor
	50	Charging Shutdown Inhibit Temperature
	51	Charging System Test
	52	Chrysler PTO Adjustment
	53	Clutch Pedal Position Switch
	54	Clutch Protection
	55	Coalescer Pressure Sensor
	56	Cold Idle Warmup
	57	Commissioning Start and Warmup Assist Lambda Adjustments
	58	Compressor Intake Density Torque Derate

Function	list	
	59	Constrained Operation
	60	Converter Control
	61	Crankcase Ventilation Heater
Features and Parameters	62	Cruise Control
	63	Cruise Control Switch Setup
	64	Cruise Control and Engine Brake Interaction
	65	Cumulative Continuous MIL On Time
	66	Customer Constrained Operation
	67	Cyclical Load Acceptance Gain Adjust
	68	DCDC LV Output Target Voltage
	69	DRIVELINE RETARDER
	70	Dedicated Fault Lamps
	71	Dedicated Pulse Width Modulation Output
	72	Delegated Assembly System Verification
	73	Door Open Switch
	74	Driver Operation Interlock
Features and Parameters	75	Driver Reward
	76	Driver Warning Engine Speed Limit
	77	Dual Fan Clutch Control
	78	Dual Outputs Based On Sensed Parameters
	79	Electric Cooling Pump Speed Command
	80	Electric Fan Control

Function	list	
	81	Electric Fuel Lift Pump
	82	Electrical System Voltage
	83	Emissions Broadcast
	84	Engine Auxiliary Shutdown Switch
	85	Engine Brake Control
Features and Parameters	86	Engine Combined Brake Type
	87	Engine Coolant Level Sensor
	88	Engine Cylinder Configuration
	89	Engine Oil Level
	90	Engine Oil Pressure Sensor
	91	Engine Overload Protection
	92	Engine Priming Pump
	93	Engine Protection
	94	Engine Rebuild Run Time
	95	Engine Speed Cruise Control
	96	Engine Start Stop Permit
	97	Engine Ventilation
	98	Engine Warmup Protection
	99	Enhanced Auxiliary Shutdown Switch
	100	Ether Injection
	101	Exhaust Stack Temperature Sensor
	102	Fan Control

Function	list	
Features and Parameters	103	Fast Idle Warmup
	104	Fault Acknowledge Switch
	105	Fault Code Flash Out
	106	Final Inducement Restart
	107	Frequency Accelerator Pedal or Lever
	108	Fuel Delivery System Information
	109	Fuel Economy Based Torque Selection
	110	Fuel Filter Differential Pressure Sensor
	111	Fuel Filter Life Monitor
	112	Fuel Filter Restriction Indicator Switch
	113	Fuel Injector Life Monitor
	114	Fuel Level Sensor 2
Features and Parameters	115	Fuel Pump Life Monitor
	116	Fuel Supply Pressure Sensor
	117	Fuel Supply Pump Filter Clog Level Warning Limit
	118	Fuel System Performance Monitor
	119	Fuel Tank Level
	120	Fuel Usage Adjustment
	121	Gas Commissioning Adjustments
	122	Gas Commissioning Control Settings
	123	Gas Commissioning Engine Performance Settings
	124	Gas Commissioning Fuel Dependency Adjustments

Function	list	
	125	Gas Commissioning Fuel Dependency Settings
	126	Gas Commissioning Fuel Dependency Variable Adjustments
	127	Gas Commissioning Start Assist Lambda Fuel Dependency Adjustments
Features and Parameters	128	Gas Commissioning Warm Up Assist Lambda Fuel Dependency Adjustments
	129	Gear Down Protection
	130	Generator Total Real Power
	131	Governor Type
	132	High NOx Reset
	133	High Soot Load Shutdown
	134	High Sulphur Protection Inhibit
	135	Hill Climb Assist
	136	Hill Roll Out
	137	Hydrocarbon Injector Override Test
	138	Idle Ramp Up
	139	Idle Rampdown
	140	Idle Shutdown
	141	Ignition Control Module Information
	142	Immobilizer
	143	Inducement Override Switch
	144	Intake Air Heater
	145	Intermediate Speed Control
	146	J1939 Controls

Function	list	
Features and Parameters	147	LIN_Sensor_Type_Selection
	148	LT Coolant Inlet Temperature Sensor
	149	Lift Pump Status
	150	Load Based Speed Control
	151	Load Management
	152	Low Load Monitor
	153	Low SOC Power Adjustment
	154	Machine Assembled Date
Features and Parameters	155	Maintenance Monitor
	156	Manufacturing Fueling Adjustment
	157	Marine Exhaust Stack Temperature
	158	Marine Rudder Position
	159	Metal Chip In Oil Detection
	160	Multiple Unit Synchronization
	161	Natural Gas Fuel Grade
	162	Neutral Gear Switch
	163	No Load Engine Speed Adjustment
	164	OEM Ambient Air Temperature Sensor
	165	OEM Auxiliary Pressure Sensor Fault Threshold
	166	OEM Auxiliary Switch Input
	167	OEM Auxiliary Temperature 2
	168	OEM Oil Change Monitor

Function	list	
	169	OEM Simple Lockout
	170	OEM Switch
	171	OEM Vehicle Acceleration Management Variable Rate
	172	Oil Filter Type
	173	Oil Filter Differential Pressure
	174	Oil Level Electronic Dipstick
	175	Oil Level Sensor Enhanced
	176	Oil Level Switch
Features and Parameters	177	Oil Life Monitor
	178	Oil Quality Sensor
	179	On Ramp Boost
	180	PTO
	181	PTP Torque And Speed Limit Brakes Engaged
	182	Parking Brake Switch
	183	Passenger Door Status Based Torque Limit
	184	Posted Speed Limit Control Management
	185	PowerSpec
	186	Powertrain CAN Message Configuration
	187	Powertrain Protection
	188	Powertrain Protection Engine Speed Limit
	189	Predictive Engine Brake
	190	Predictive Gear Shifting

Function	list	
Features and Parameters	191	Prelube Control
	192	Primary Accelerator Pedal Or Lever
	193	Push Button Start and Shutdown
	194	RS422 Communication
	195	Rated Overspeed Protection
	196	Rated Speed Adjust
	197	Real Time Clock
	198	Remote Accelerator Pedal or Lever
	199	Remote Engine Start
	200	Remote Start
	201	Response On Event
	202	Restricted Immobilizer
Features and Parameters	203	Retarder Coolant Bypass Valve Relay
	204	Reverse Gear Switch
	205	Road Speed Governor
	206	SAE J1939 Multiplexing
	207	SCR Aftertreatment
	208	Safe To Remove Power
	209	Sea Water Cooling Pressure
	210	Service Brake Switch
	211	Service Brake Switch Diagnostic
	212	Service Brake Validation Switch

Function	list	
	213	Single Bank Cutout
	214	Smart Charging
	215	Smart Fuel Economy
	216	Smart Launch
	217	Smart Manual Transmission
Features and Parameters	218	Smart Torque 2
	219	Speed Torque Options
	220	Standby Engine Usage Life Monitor
	221	Starter Control
	222	Starter Lockout
	223	Stop Start Battery Package Management
	224	Stop Start Active Inhibits Monitor
	225	Stop Start Battery Management
	226	Stop Start Information
	227	Sudden Deceleration Event Settings
	228	Switched Alternate Low Idle Speed
	229	Switched Droop
	230	Switched Maximum Engine Operating Speed
	231	System ID and Dataplate
	232	TPIA Gear Ratio Idle Adjustment
	233	Telematics Wireless Communication Configuration
	234	Tire Wear Adjustment

Function	list	
Features and Parameters	235	Torque Rate Limiter
	236	Transmission Accelerator Interlock
	237	Transmission Setup
	238	Trip Information
	239	Turbocharger Life Monitor
	240	User Adjustable Fuel Economy
	241	Variable Rate Vehicle Acceleration Management
	242	Vehicle Acceleration Management
	243	Vehicle Classification
	244	Vehicle Smart Accessories Management
Features and Parameters	245	Vehicle Speed Based Device Driver A
	246	Vehicle Speed Based Device Driver B
	247	Vehicle Speed Sensor Anti-Tampering
	248	Vehicle Speed Source
	249	Wait To Start Lamp2
	250	Waste Tank Oil Level Sensor
	251	Water In Fuel Sensor
	252	Wireless Adaptor Communication Configuration
	253	xEV Air Compressor Activated
	254	xEV Charge Consent
	255	xEV Charge Delay
	256	xEV Charging Control

Function	list	
Features and Parameters	257	xEV EVCC Serial Number
	258	xEV HBAT Number of Packs
	259	xEV HSC1 Message Configuration
	260	xEV Hill Start Aid
	261	xEV Maintenance Mode Disabled Count
	262	xEV Operation Time
	263	xEV Shutdown Command
History or Log	1	Aftertreatment Diesel Exhaust Fluid(DEF) Dosing Unit Allowable Calibration List
	2	Aftreatment Maintenance Log
	3	Aftertreatment Diesel Oxidation Catalyst Efficiency Log
	4	Aftertreatment NOx Inlet Outlet Dew Point Elapsed Times
	5	Aftertreatment NOx Inlet Outlet Dew Point Temperatures
	6	Aftertreatment Selective Catalytic Reduction(SCR) Conversion Efficiency Intrusive Capability
	7	Aftertreatment Selective Catalytic Reduction(SCR) Conversion Efficiency Non Intrusive Capability
	8	Aftertreatment Selective Catalytic Reduction(SCR) System Configuration Leg Number
	9	Aftertreatment Selective Catalytic Reduction(SCR) System Configuration Doser Number
	10	Aftertreatment Selective Catalytic Reduction(SCR) System Configuration Line Heater Relay Number
	11	Aftertreatment Selective Catalytic Reduction(SCR) System Configuration Pump Heater Relay Number
	12	Maximum Diesel Particulate Filter Soot Load Condition
	13	Maximum Diesel Particulate Filter Outlet Temperature Condition

Function	list	
History or Log	14	Aftertreatment History Regeneration Trigger State Log
	15	Application Specific Saved And Restored Table
	16	Aftertreatment Diesel Particulate Filter(DPF) Ash Load History Log
	17	Aftertreatment Diesel Particulate Filter(DPF) Missing Event Log
	18	Aftertreatment Diesel Particulate Filter(DPF) Passive Desoot Assist Time Log
	19	Aftertreatment Diesel Particulate Filter(DPF) Regeneration History Log
	20	Before Cleaning Delta Pressure Thresholds
	21	Diesel Particulate Filter Restriction Test Log
	22	Before Cleaning Exhaust Flow Rate Thresholds
	23	After Cleaning Delta Pressure Thresholds
	24	After Cleaning Exhaust Flow Rate Thresholds
History or Log	25	Aftertreatment Dosing System Test Log
	26	Aftertreatment Max Soot Level Per Regeneration History
	27	Aftertreatment Selective Catalytic Reduction(SCR) Catalyst Regeneration History Log
	28	Aftertreatment Selective Catalytic Reduction(SCR) Regeneration History Log
	29	Regeneration History Log
	30	Aftertreatment SCR System Cleaning History Log
	31	Maximum SCR Soot Load Condition
	32	Maximum SCR Outlet Temperature Condition
	33	Full Error Bucket Information Log

Function	list	
	34	Full Torque Bin Information Log
	35	Boost Power History Log
	36	EPD Coolant Level Torque Derate Log
History or Log	37	Datalink Control History Log
	38	Dosing Fuel Consumption Rate
	39	Emissions Broadcast Rolling Monthly SO2 Est Array
	40	Emissions Broadcast Rolling Monthly PM Est Array
	41	Emissions Broadcast Rolling Monthly NOx Est Array
	42	Emissions Broadcast Rolling Monthly Hydrocarbon Est Array
	43	Emissions Broadcast Rolling Monthly CO Est Array
	44	Driving Performance Analytics Duty Cycle and Top Gear Distribution
	45	Driving Performance Analytics Vehicle Speed Distribution
	46	Driving Performance Analytics APP Position Distribution
	47	Engine Compression And Air Handling System Test Log
	48	EPD Aux Discrete Input 1 Torque Derate Log
	49	EPD Aux Discrete Input 1 RPM Derate Log
	50	EPD AuxPres1 RPM Derate Log
	51	EPD AuxPres1 Torque Derate Log
	52	EPD Auxiliary Temperature 1 RPM Derate Log
	53	EPD Auxiliary Temperature 1 Torque Derate Log

Function	list	
History or Log	54	Engine Protection Bank Vacuum Detection Torque Derate Log
	55	Engine Protection Boost Pressure Differential Torque Derate Log
	56	EPD Compressor Outlet Temperature Torque Derate Log
	57	Engine Protection Catalyst Intake Temperature Moderate RPM Derate Log
	58	Engine Protection Catalyst Intake Temperature Moderate Torque Derate Log
	59	Engine Protection Catalyst Intake Temperature Severe RPM Derate Log
History or Log	60	Engine Protection Catalyst Intake Temperature Severe Torque Derate Log
	61	EPD Catalyst Outlet Temperature Moderate RPM Derate Log
	62	EPD Catalyst Outlet Temperature Moderate Torque Derate Log
	63	EPD Catalyst Outlet Temperature Severe RPM Derate Log
	64	EPD Catalyst Outlet Temperature Severe Torque Derate Log
	65	Engine Protection - Engine Coolant Temperature 2 Sensor RPM Derate Log
	66	Engine Protection - Engine Coolant Temperature 2 Sensor Torque Derate Log
	67	Engine Protection Compressor Intake Air Temperature Torque Derate Log
	68	Engine Protection(EPD) Compressor Outlet Pressure Torque Derate Log
	69	Engine Protection(EPD) Compressor Outlet Temperature(COT) Speed Derate Log
	70	Engine Protection(EPD) Continuous Light Knock Torque Derate Log
	71	Engine Protection(EPD) Continuous Light Knock RPM Derate Log
	72	Coolant Level Speed Derate Log
	73	EPD Coolant Pressure Torque Derate Log

Function	list	
History or Log	74	Engine Protection(EPD) CP Speed Derate Log
	75	EPD Coolant Temperature Torque Derate Log
	76	EPD Coolant Temperature RPM Derate Log
	77	EPD Crankcase Pressure Torque Derate Log
	78	Crankcase Pressure Speed Derate Log
	79	EPD DPF Soot Load RPM Derate Log
	80	EPD DPF Soot Load Torque Derate Log
	81	Engine Protection(EPD) Engine Control Module(ECM) Internal Temperature Torque Derate Log
	82	EPD EGR Orifice Temp Torque Derate Log
	83	EPD EGR Orifice Temp RPM Derate Log
History or Log	84	Engine Protection - Exhaust Gas Temperature Bank Differential RPM Derate Log
	85	Engine Protection - Exhaust Gas Temperature Bank Differential Torque Derate Log
	86	Engine Protection Exhaust Gas Temperature Cylinder Deviation Torque Derate Log
	87	Engine Protection(EPD) Exhaust Gas Temperature(EGT) Misfire Detection Torque Derate Log
	88	Engine Protection(EPD) Exhaust Gas Temperature(EGT) Misfire Detection RPM Derate Log
	89	Engine Protection(EPD) Excessive Mechanical Vibration Torque Derate Log
	90	Engine Protection(EPD) Excessive Mechanical Vibration RPM Derate Log

Function	list	
History or Log	91	Engine Protection - Exhaust Gas Temperature 1 RPM Derate Log
	92	Engine Protection - Exhaust Gas Temperature 2 RPM Derate Log
	93	Engine Protection - Exhaust Gas Temperature 3 RPM Derate Log
	94	Engine Protection - Exhaust Gas Temperature 4 RPM Derate Log
	95	Engine Protection - Exhaust Gas Temperature 5 RPM Derate Log
	96	Engine Protection - Exhaust Gas Temperature 6 RPM Derate Log
History or Log	97	Engine Protection - Exhaust Gas Temperature 7 RPM Derate Log
	98	Engine Protection - Exhaust Gas Temperature 8 RPM Derate Log
	99	Engine Protection - Exhaust Gas Temperature 9 RPM Derate Log
	100	Engine Protection - Exhaust Gas Temperature 10 RPM Derate Log
	101	Engine Protection - Exhaust Gas Temperature 11 RPM Derate Log
	102	Engine Protection - Exhaust Gas Temperature 12 RPM Derate Log
	103	Engine Protection - Exhaust Gas Temperature 13 RPM Derate Log
	104	Engine Protection - Exhaust Gas Temperature 14 RPM Derate Log
	105	Engine Protection - Exhaust gas Temperature 15 RPM Derate Log
	106	Engine Protection - Exhaust Gas Temperature 16 RPM Derate Log
	107	Engine Protection - Exhaust Gas Temperature 1 Torque Derate Log
	108	Engine Protection - Exhaust Gas Temperature 2 Torque Derate Log

Function	list	
History or Log	109	Engine Protection - Exhaust Gas Temperature 3 Torque Derate Log
	110	Engine Protection - Exhaust Gas Temperature 4 Torque Derate Log
	111	Engine Protection - Exhaust Gas Temperature 5 Torque Derate Log
	112	Engine Protection - Exhaust Gas Temperature 6 Torque Derate Log
	113	Engine Protection - Exhaust Gas Temperature 7 Torque Derate Log
	114	Engine Protection - Exhaust gas Temperature 8 Torque Derate Log
	115	Engine Protection - Exhaust Gas Temperature 9 Torque Derate Log
	116	Engine Protection - Exhaust Gas Temperature 10 Torque Derate Log
	117	Engine Protection - Exhaust Gas Temperature 11 Torque Derate Log
	118	Engine Protection - Exhaust Gas Temperature 12 Torque Derate Log
	119	Engine Protection - Exhaust Gas Temperature 13 Torque Derate Log
History or Log	120	Engine Protection - Exhaust Gas Temperature 14 Torque Derate Log
	121	Engine Protection - Exhaust Gas Temperature 15 Torque Derate Log
	122	Engine Protection - Exhaust Gas Temperature 16 Torque Derate Log
	123	Engine Protection(EPD) EMT Speed Derate Log
	124	Engine Protection Exhaust Pressure Derate Log
	125	EPD Exhaust Pressure RPM Derate Log
	126	EPD Exhaust Stack Temperature 1 RPM Derate Log
	127	EPD Exhaust Stack Temperature 2 RPM Derate Log

Function	list	
	128	EPD Exhaust Stack Temperature 1 Torque Derate Log
	129	EPD Exhaust Stack Temperature 2 Torque Derate Log
	130	EPD Exhaust Temperature Torque Derate Log
	131	EPD Fuel Outlet Pressure RPM Derate Log
	132	EPD Fuel Outlet Pressure Torque Derate Log
History or Log	133	Engine Protection(EPD) Fuel Pump Oil Pressure Torque Derate Log
	134	Engine Protection(EPD) Fuel Pump Oil Pressure RPM Derate Log
	135	EPD Fuel Temperature RPM Derate Log
	136	EPD Fuel Temperature Torque Derate Log
	137	Engine Protection(EPD) Gas Methane Percent Torque Derate Log
	138	Engine Protection(EPD) HT Coolant Outlet Temperature Low Torque Derate Log
	139	Engine Protection(EPD) Heavy Knock RPM Derate Log
	140	Engine Protection Low Temperature Coolant Intake Temperature Torque Derate Log
	141	Engine Protection(EPD) Heavy Knock Torque Derate Log
	142	Engine Protection(EPD) IMOP Intake Manifold Temperature Torque Derate Log
	143	Engine Protection(EPD) IMOP Intake Manifold Temperature RPM Derate Log
	144	EPD Intake Manifold Temperature(IMT) RPM Derate Log
	145	EPD Intake Manifold Temperature(IMT) 1 RPM Derate Log
	146	EPD Intake Manifold Temperature(IMT) 1 Torque Derate Log

Function	list	
History or Log	147	EPD Intake Manifold Temperature(IMT) Torque Derate Log
	148	EPD Intake Manifold Temperature(IMT) 2 RPM Derate Log
	149	EPD Intake Manifold Temperature(IMT) 2 Torque Derate Log
	150	EPD Intake Manifold Temperature(IMT) 3 RPM Derate Log
	151	EPD Intake Manifold Temperature(IMT) 3 Torque Derate Log
	152	EPD Intake Manifold Temperature(IMT) 4 RPM Derate Log
	153	EPD Intake Manifold Temperature(IMT) 4 Torque Derate Log
	154	EPD Intake Manifold Temperature(IMT) 5 RPM Derate Log
	155	EPD Intake Manifold Temperature(IMT) 5 Torque Derate Log
	156	EPD Intake Manifold Temperature(IMT) 6 RPM Derate Log
History or Log	157	EPD Intake Manifold Temperature(IMT) 6 Torque Derate Log
	158	Engine Protection Intake Manifold Over Pressure Torque Derate Log
	159	Engine Protection(EPD) Kilowatt Overload Torque Derate Log
	160	Engine Protection(EPD) Knock Signal Health Torque Derate Log
	161	Engine Protection(EPD) Knock Signal Health RPM Derate Log
	162	Engine Protection(EPD) LT Coolant Inlet Pressure Torque Derate Log
	163	Engine Protection(EPD) LT Coolant Level Low Torque Derate Log
	164	Engine Protection Auxiliary Temperature 3 Engine Speed Derate Log
	165	Engine Protection Auxiliary Temperature 3 Torque Derate Log

Function	list	
	166	Engine Protection Engine Overload Torque Derate Log
	167	Engine Protection - Marine Water In Fuel Torque Derate Log
	168	Engine Protection - Marine Water In Fuel RPM Derate Log
History or Log	169	Engine Protection - Marine Water In Fuel 2 RPM Derate Log
	170	Engine Protection - Marine Water In Fuel 2 Torque Derate Log
	171	Engine Protection Oil Filter Differential Pressure Torque Derate Log
	172	Engine Protection(EPD) Oil Level Low Torque Derate Log
	173	Engine Protection(EPD) Oil Level Switch Torque Derate Log
	174	EPD Oil Pressure RPM Derate Log
	175	Engine Protection(EPD) Oil Pressure High Torque Derate Log
	176	EPD Oil Pressure Torque Derate Log
	177	EPD Oil Temperature Torque Derate Log
	178	EPD Oil Temperature RPM Derate Log
	179	EPD Overspeed RPM Derate Log
	180	Engine Protection Speed Load Demand Torque Derate Log
	181	EPD Turbine Intake Temperature Torque Derate Log
	182	Engine Protection(EPD) Turbine Inlet Temperature RPM Derate Log
	183	Engine Protection(EPD) Turbocharger Overspeed Torque Derate Log
	184	Engine Protection - Water In Fuel RPM Derate Log

Function	list	
History or Log	185	Engine Protection - Water In Fuel Torque Derate Log
	186	Engine Protection - Water In Fuel 2 RPM Derate Log
	187	Engine Protection - Water In Fuel 2 Torque Derate Log
	188	Enhanced Fault Snapshot Faults
	189	Feature Exclusivity List
	190	Fuel Rate
	191	Barcode State
	192	Marine Water In Fuel Log
History or Log	193	Hardware Version Information
	194	Mercedes Active Diagnostic Information
	195	Diagnostic Specification Information
	196	Read Configuration Fingerprint
	197	Read Software Fingerprint
	198	Read Routine In Out Control Fingerprint
	199	Write Routine In Out Fingerprint
	200	Write Configuration Fingerprint
	201	Boot Software Version Information
	202	Software Version Information
	203	Multiplexed Timeout Fault Data Log
	204	Multiplexing Configuration Fault Data Log

Function	list	
History or Log	205	NEIMO OEM F2E2 Data
	206	NEIMO OEM F2E4 Data
	207	OCM Fuel Reset Log
	208	Time Reset Log
	209	Oil Change Monitor Distance Reset Log
	210	Overspeed Shutdown History Log
	211	Boot Software Identification Data Identifier
	212	Sudden Deceleration Event Log
	213	Sudden Deceleration Rate Threshold
	214	Torque History Log - Maximum Torque
	215	Torque History Log- Maximum Power
	216	Torque History Log - Record Data
History or Log	217	Torque History Log - Maximum Torque
	218	Torque History Log - Maximum Power
	219	Torque History Log - Record Data
	220	Torque History Log - Maximum Torque
	221	Torque History Log - Maximum Power
	222	Torque History Log - Record Data
	223	Turbocharger Actuator Calibration List
	224	Vehicle Distance Check GPS Distance

Function		list	
	225	Water In Fuel Time Stamp Since Last Detection	