C:/Users/Steve/Desktop/MERCS/SCAD/FTC/RobotParts.scad 120 100 80 60 40 20 0 -60 -80 -100 -120

-140
Scale is to calibrate actual printed dimension. Check both X and Y, Measure between tick 0 and last tick

)

0

80