

METAR GSM Lamp Setup Guide

Welcome, and thank you for purchasing your METAR Lightworks GSM Lamp. This guide will help you power on, connect, and configure your cellular enabled METAR lamp.

Step 1: Powering the Lamp

1. Plug the lamp into a USB power source.
2. The lamp will power on and begin startup.

Startup Indicator

- Blinking Yellow Light: Device is booting and connecting to network.
- Solid Yellow Light: Device has no weather data connection yet.
- Once connected, the lamp will display the airport's current METAR weather color.

Step 2: Connecting to Setup WiFi

1. Connect to WiFi network: METARLightworks_GSM
2. Password: metar123
3. Open browser to: <http://192.168.4.1>

Step 3: Configure Your Lamp

- Set your desired airport code
- Connect the lamp to local WiFi (optional)
- Adjust LED brightness
- Configure automatic on/off schedule
- Set timezone
- Enable Flight Pulse

Step 4: Cellular vs WiFi Operation

Cellular Mode: Updates weather every hour and is ideal for locations without WiFi.

WiFi Mode: Updates weather every 20 minutes and enables additional smart features.

Flight Pulse Feature

Flight Pulse makes the lamp pulse when your aircraft is detected flying.

Important: Flight Pulse only works while connected to WiFi.

Scheduling Notes

- Lamp illuminates only during selected hours if scheduling is enabled.
- Outside scheduled hours, LED turns off automatically.

Troubleshooting

- Blinking Yellow: Device is booting or attempting connection.
- Solid Yellow: Device has no weather or network connection yet.
- Reconnect to setup WiFi anytime to change settings.

Support

northjoe@gmail.com

Stay safe, and fly VFR!