

North METAR Lamp

Quick Start

Connect Wi-Fi, set your airport, and let the lamp handle the rest.

1 Power on

Plug the lamp into a USB-A power source rated 5V 1A or better. Yellow during startup means it is waiting on Wi-Fi or fresh data.

2 Join setup Wi-Fi

Open Wi-Fi settings and connect to the network that starts with METARLightworks. Some phones may say No Internet - stay connected.

3 Open setup page

The page may open automatically. If not, open a browser and go to 192.168.4.1.

4 Set airport + Wi-Fi

Enter your airport code, tap Refresh Networks, choose or manually enter your home Wi-Fi, enter the password, then tap Save Wi-Fi. The lamp reboots.

Airport code

Use a four-character ICAO airport code, such as KTIK, KMCO, KSFB, or KJFK. The airport code can be set during the first Wi-Fi setup session before you tap Save Wi-Fi.

Wi-Fi note

The lamp uses 2.4 GHz Wi-Fi. Most combined 2.4/5 GHz mesh networks work, but a 5 GHz-only network will not. If your network does not appear, tap Refresh Networks again or type the Wi-Fi name manually exactly as it appears on your router.

Color guide

VFR

MVFR

IFR

LIFR

Connecting / no data

Using your lamp

Once connected, the lamp automatically fetches a fresh METAR about every 20 minutes. If Wi-Fi drops and reconnects, it fetches again right away.

Flight category colors

Color	Category	Meaning
Green	VFR	VFR conditions. Always confirm official weather before flight.
Blue	MVFR	Marginal VFR conditions.
Red	IFR	Instrument flight rules conditions.
Purple	LIFR	Low IFR conditions.
Yellow	Connecting / unavailable	The lamp is waiting on Wi-Fi, data, or a valid METAR response.

Core settings

Airport / station	Enter a four-character ICAO code and tap Update Station. For most US airports, the code begins with K.
Brightness	Drag the slider to preview brightness. Tap Save to store it. Normal range is 5-80%.
Display mode	Leave on Auto for live METAR colors. Manual colors and Cycle are useful for demos or testing.
Schedule	Turn the lamp on and off automatically. Choose a time zone, then set Start and End. Overnight schedules are supported.
Finding the page later	On the lamp setup Wi-Fi, use 192.168.4.1. On your home Wi-Fi, try <code>http://airportcode.local</code> , such as <code>http://ktix.local</code> .

Schedule note

If schedule mode is ON and the current time is outside the set window, the lamp will be dark. If you disable schedule while it is off, it may take until the next normal refresh to light again.

IF CONFIGURED

Optional features

These sections only appear in the web UI if your unit was built or configured with the feature. If you do not see one of these cards, your lamp may not include that option.

Flight Pulse

Flight Pulse watches one aircraft using live ADS-B data. When the selected aircraft appears airborne, the lamp gently breathes/pulses.

Turn Enable on, enter either a US tail number or a 6-character ICAO hex code, then tap Save Flight Pulse. The lamp checks about every 45 seconds. ADS-B coverage varies by location and altitude.

Night Light

Night Light lets the lamp act as a soft bedside or desk light. While active, it temporarily overrides the METAR color.

Use Manual Night Light for immediate use, or enable its schedule. Adjust Warmth and Night Brightness separately. If Flight Pulse is configured, Pulse with Flight Pulse can make the night light breathe when the aircraft is airborne.

Runway Lights

Runway Lights drive a second LED output for a decorative runway accent.

Use Manual Runway Lights or its schedule, adjust brightness, and enable Subtle Flicker for a gentle vintage runway-light effect. Threshold color and LED layout are factory configured.

Firmware updates

Your lamp can update itself over Wi-Fi when an update is available.

- Manual update: open the web UI, scroll to Firmware Update, tap Check Now, then Install Update if available.
- Auto-update is off by default. If enabled, the lamp periodically checks for updates and installs them when available.
- Do not unplug the lamp while an update is installing. It will reboot automatically when finished.

Setup AP setting

By default, the setup Wi-Fi remains available so you can reach the lamp. If you enable Disable setup Wi-Fi 30 minutes after reboot, the setup AP turns off after about 30 minutes but comes back after the next power cycle.

QUICK FIXES

Troubleshooting

Issue	What to try
Lamp stays yellow	Give it 2-3 minutes after Wi-Fi connects. Check the airport code. If it still stays yellow, contact support.
Setup Wi-Fi not visible	Power-cycle the lamp and stay near it. Look for a network that starts with METARLightworks.
Can't reach 192.168.4.1	Make sure your phone is still connected to the lamp setup Wi-Fi, not your home Wi-Fi. Try disabling mobile data or Wi-Fi Assist temporarily.
Home Wi-Fi will not connect	Recheck the password. The lamp supports 2.4 GHz Wi-Fi only. For mesh networks, type the SSID manually.
Wrong color or stuck in one color	Check Display Mode. Set it back to Auto for live METAR updates.
airportcode.local does not work	Use 192.168.4.1 while connected to the lamp setup Wi-Fi, or check your router app for the lamp IP address. Some Android devices do not support .local well.
Flight Pulse never pulses	Confirm the tail/hex is saved and allow a minute after takeoff. ADS-B coverage can be delayed or limited.
Night Light color looks wrong	Warmth works best with RGBW LED strips. Standard RGB units may not show the warmth adjustment the same way.

Changing Wi-Fi or starting over

There is no customer factory-reset button. To change Wi-Fi, power-cycle the lamp, connect to the setup Wi-Fi, and save new Wi-Fi credentials. Other saved settings may remain unchanged.

Phone connection tips

- If your phone says the lamp Wi-Fi has no internet, choose Stay Connected, Keep Using, or Use Without Internet if prompted.
- If the setup page does not appear automatically, open a browser and type 192.168.4.1.
- If your phone jumps back to your home Wi-Fi, temporarily disable mobile data, Wi-Fi Assist, or Auto-Switch to Better Wi-Fi while completing setup.

Before contacting support

- Have your airport code ready.
- Know whether the lamp setup Wi-Fi appears in your Wi-Fi list.
- Note the lamp color after boot, especially if it remains yellow.
- For Wi-Fi problems, confirm whether your network is 2.4 GHz or combined 2.4/5 GHz.

Support

For setup help, warranty questions, or feature requests:

northjoe@gmail.com

Thank you for choosing METARLightworks. Stay safe, and fly VFR.