

POWER AMPLIFIER GZTA 4230X-B

Owner's Manual

Features

- 4-channel Mosfet high power amplifier
- 2-ohms stable / 4-ohms stable in bridged mode
- Adjustable Bass Boost (@ 45 Hz)
- Adjustable crossover (HPF or LPF/BPF)
- HPF: 5 500 Hz
- LPF: 40 4000 Hz
- High pass filter usable as subsonic filter
- Active BIAS control (automatic)
- 4x RCA low level input
- Adjustable input sensitivity
- Soft delayed remote turn-on
- Large dimensional power wire terminal
- Thermal / short circuit / overload protection
- Operation / protection circuit indicator

General mounting instructions

• As a precaution, it is recommended to disconnect the vehicles battery before mounting the amplifier.

Note: For new vehicles, disconnecting the battery might cause various errors in your vehicle's electric system that can be cleared only by authorized service partners of your vehicle's manufacturer! Please ask your service partner first before disconnecting the battery!

• The power supply wire (+12 V) has to be protected within max. 20 cm / 8" by a main fuse holder with a fuse value matching the recommendation for your amplifier

Note: If there is more than one amplifier connected using this power wire, the main fuse value must be equal to the sum of the recommended fuses of all connected devices. However, make sure the diameter of your power wire will be enough for the required current!

- If necessary, replace a defective fuse by a fuse with identical quality and value
- Never drill a hole to the vehicle's gas tank or brake lines, to wirings or any other important vehicle parts!
- Never pass wires over sharp edges or vehicle parts due avoid any kind of damage
- Keep the wiring away from the antenna and electronic devices contributing to radio reception
- Lay the power supply wiring always separated from speaker wiring to avoid disturbance
- The amplifier contains a temperature protection circuit that turns the device off in case of overheating. After
 a certain cooling time, it will turn on automatically. To avoid heat build-up, enough air supply for cooling
 must be provided. Never cover the surface of the amplifier's heatsink entirely
- The amplifier should **NEVER** be mounted onto a vibrating part or surface such as a subwoofer enclosure. This might lead to malfunction due to loosened electrical parts inside the amplifier.
- Some amplifiers offer a high-level input option, however if a pre-amplified output (RCA) is available (at the head unit), it is strongly recommended to make use of them.



GROUND ZERO products are engineered in Germany

GROUND ZERO - international sponsor of






yellow color side panels included


Specifications

Model	GZTA 4230X-B	
Amplifier type	4 channel class A/B high power amplifier	
Output power	$4 \times 140 \text{ W RMS}$ @ $4 \text{ Ohm} \le 1\% \text{ THD} + \text{N}$ $4 \times 230 \text{ W RMS}$ @ $2 \text{ Ohm} \le 1\% \text{ THD} + \text{N}$ $4 \times 275 \text{ W max}$ @ $2 \text{ Ohm} \le 10\% \text{ THD} + \text{N}$ $2 \times 460 \text{ W bridged}$ @ $4 \text{ Ohm} \le 1\% \text{ THD} + \text{N}$ $2 \times 550 \text{ W bridged}$ @ $4 \text{ Ohm} \le 10\% \text{ THD} + \text{N}$	
Damping factor	> 150	
High pass crossover	HPF: 5 Hz – 500 Hz	
Low pass crossover (BP)	LPF: 40 Hz – 4000 Hz (HPF active for band pass configuration)	
Frequency response	5 Hz – 38 kHz (± 1 dB)	
Bass Boost (on channel 3/4)	0 to 12 dB (@ 45 Hz)	
Input sensitivity	0.5 V – 9 V (± 5%)	
Fuse(s)	2x 40 A	
Dimensions w x h x l (mm/inch)	230 x 53 x 476 9.04" x 2.09" x 18.74"	




	Function		
1	Speaker terminal	Speaker connection	
2	Power supply terminal	GROUND -> ground terminal	
		REM -> remote wire	
		BATT+ -> +12 Volt wire from battery terminal	
3	CL LED	POW -> green -> ok (correct operation)	
٥	Status LEDs	PROT -> red -> error / protection	
		Input sockets to connect RCA wires - to avoid any malfunction, it is recommended to use	
		only high quality RCA cables	
4	Signal input (RCA)	Cable recommendation:	
	1 1 11 11	GCZZ X-TP series (available lengths 0.57 / 1.14 / 3.14 / 5.49 m)	
5	Input sensitivity	Controller to adjust the input sensitivity	
6	Bass Boost (on channel 3/4)	Controller to adjust the bass boost level ($0 \text{ to } + 12 \text{ dB}$ at 45 Hz)	
	Crossover / Mode switch	To setup the crossover for the required use of the amplifier	
		FULL – entire frequency range will be reproduced	
		HIGH (SUBS) — only mid/high frequencies are reproduced according the control (8)	
7		LOW (BP)* — only low frequencies are reproduced according the control (9)	
		, , , , , , , , , , , , , , , , , , , ,	
		*: Set to LOW filter, the high-pass filter (SUBSONIC) will be activated simultaneously	
		resulting in a band-pass filter (5 Hz 4000 Hz)	
	High pass (HPF) control	To adjust the required crossover point. Frequencies below the selected crossover point will	
8		be filtered (5 Hz to 500 Hz).	
	(Subsonic)	This control will also be activated at MODE switch set to LOW (7)	
	Low pass (LPF) control	To adjust the required crossover point. Frequencies above the selected crossover point will	
9	(Bandpass) be filtered (40 Hz to 4000 Hz)		

Stereo mode



Bridged mode



Trouble shooting guide

Symptoms	Check / Cause	Action
No audible sound	Does the POW LED turn to green?	Check protection fuse(s) of the amplifier Check remote wire connection (RCA input mode) Check +12 Volt power supply wire connection Check ground wire connection
	Did the PRO LED turned to red?	Check for speaker short or amplifier overheating
Device does not turn on	Power supply of the amplifier?	Check power wire or connections
Device does not turn on	Remote wire powered? (RCA input mode)	Check remote wire connection to the head unit
	Speaker wiring undamaged?	Check for short circuit or open connections
No sound on one channel	Input signal on both RCA leads?	Reverse left and right RCA inputs to check the audio input signal
Device turns off at medium / high volume	Load impedance of each speaker correct?	Check if each speaker load impedance matches the technical specifications of the amplifier
Status LED turned on red	Temperature protection circuit active	Decrease head units volume / wait for cooling
Sidios LLD formed on red	Speaker wires short / speaker damaged	Check speaker / wires and insulate if necessary

Terms of warranty

The limited warranty for this product is covered by GROUND ZERO's regional distribution partners and their terms and conditions. For further information contact your local retailer or distributor.



Listening to music can be emotional, impressive, relaxing or enjoyable. At that, it doesn't really matter what kind of music is the personal favorite, whether it's Instrumental, Jazz, Electro, Latin, Classic, Rock or any other music direction. However, audio reproduction quality at each desired volume is elementary. Some music styles require higher levels while others prefer the soft tones

GROUND ZERO considers all the different wishes of customers during the development of new products. Along with this, the target is to create the most realistic sound, to transfer the soul of the music and the intention of the performer. Summarized to one phrase: RESPECT THE MUSIC!

Ground Zero GmbH

Erlenweg 25 85658 Egmating Germany Tel. +49 (0)8095/873 830 www.ground-zero-audio.com







VERSTÄRKER GZTA 4230X-B

Bedienungsanleitung

Ausstattungsmerkmale

- 4-Kanal Mosfet-Hochleistungsverstärker
- 2-Ohm stabil / 4-Ohm stabil in Brückenschaltung
- Regelbare Bassanhebung (Bass Boost) bei 45 Hz
- Einstellbare Frequenzweiche (HPF oder LPF/BPF)
- HPF: 5 500 Hz (paarweise für Kanal 1/2 und 3/4)
- LPF: 40 4000 Hz (paarweise für Kanal 1/2 und 3/4)
- Hochpassfilter als Subsonic-Filter nutzbar
- Aktive BIAS Regelung (automatisch)
- 4x Cinch (RCA) Eingang
- Regelbare Eingangsempfindlichkeit
- Einschaltverzögerung
- Großdimensionierter Kabelanschluss
- Temperatur- / Kurzschluss- / Überlastschutzschaltung
- Betriebsanzeige / Anzeige der Schutzschaltung

Allgemeine Montagehinweise

- Als Vorsichtsmaßnahme wird empfohlen, die Fahrzeugbatterie vor der Installation zu trennen! (Hinweis:
 Bei einigen neueren Fahrzeugen kann das Trennen der Batterie zu Fehlermeldungen der Bordelektrik
 führen, welche ausschließlich durch eine autorisierte Fachwerkstatt gelöscht werden können. Bitte
 beachten Sie Hinweise in der Betriebsanleitung des Fahrzeuges oder fragen Sie einen Servicepartner für
 Ihr Fahrzeug, bevor Sie die Batterie trennen!)
- Das Hauptstromkabel muss innerhalb der ersten 20 cm nach dem Anschluss und der Batterie durch eine geeignete Sicherung mit dem in der Anleitung genannten Wert abgesichert werden.
 (Hinweis: Wenn das Hauptstromkabel mehrere Verbraucher versorgt, sollte der Wert der Summe aller empfohlenen Sicherungswerte entsprechen. Hierbei muss gewährleistet sein, dass der gewählte Kabelquerschnitt für eine entsprechende Stromhöhe geeignet ist.)
- Wenn notwendig, sollten defekte Sicherungen ausschließlich durch neue Sicherungen derselben Qualität und mit identischem Sicherungswert ersetzt werden
- Niemals Löcher in den Tank, die Bremsleitung, Kabel oder andere wichtige Fahrzeugteile bohren!
- Kabel niemals über scharfe Kanten führen, die zu Beschädigungen führen könnten
- Signal- und Lautsprecherkabel nicht in der N\u00e4he von Antennen-Elektronik oder Antennenkabel verlegen,
 die f\u00fcr den Radioempfang wichtig sind
- Signal- und Lautsprecherkabel weitestgehend getrennt von stromführenden Kabeln verlegen
- Der Verstärker verfügt über eine thermische Schutzschaltung, welche bei zu hoher Temperatur das Gerät abschaltet; nach der Abkühlung schaltet sich dieses wieder selbstständig ein. Um einen Wärmestau zu vermeiden, sollte für ausreichende Luftzufuhr zur Kühlung gesorgt werden. Die Oberfläche des Kühlkörpers darf nicht vollflächig abgedeckt werden
- Der Verstärker sollte NIEMALS auf stark vibrierenden Bauteilen oder Oberflächen montiert werden wie z.B. Subwoofer-Gehäusen. Dies könnte zu Fehlfunktionen aufgrund sich gelöster Bauteile führen



GROUND ZERO Produkte werden in Deutschland entwickelt

GROUND ZERO - internationaler Sponsor der






yellow color side panels included


Technische Daten

Modell	GZTA 4230X-B	
Verstärkerart	4-Kanal Mosfet Hochleistungsverstärker	
Ausgangsleistung	4 x 140 W RMS @ 4 Ohm ≤ 1% THD+N 4 x 230 W RMS @ 2 Ohm ≤ 1% THD+N 4 x 275 W max @ 2 Ohm ≤ 10% THD+N 2 x 460 W bridged @ 4 Ohm ≤ 1% THD+N 2 x 550 W bridged @ 4 Ohm ≤ 10% THD+N	
Dämpfungsfaktor	ktor > 150	
Hochpass Weiche	HPF: 5 – 500 Hz	
Tiefpass Weiche (BP)	LPF: 40 – 4000 Hz (HPF aktiv für Bandpass-Konfiguration)	
Frequenzgang	5 Hz – 38 kHz (± 1 dB)	
Bass Boost (für die Kanäle 3/4)	0 bis 12 dB (45 Hz)	
Eingangsempfindlichkeit	sempfindlichkeit 0.5 – 9 V (± 5%)	
Sicherung(en)	2x 40 A	
Abmessungen B x H x L (mm / Inch)	230 x 53 x 476 mm 9.04 x 2.09 x 18.74"	




	Funktion		
1	Lautsprecheranschluss	Zum Anschluss der Lautsprecherkabel	
2	Stromanschluss	GND Masse Anschluss REM Remote Antennenanschluss BATT +12 Volt (Batterie)	
3	Zustandsanzeige	Grün OK (Gerät in Betrieb) Rot Fehler (Gerät in Schutzschaltung)	
4	Signaleingang	Zum Anschluss des Vorverstärker-Ausgangs (RCA) des Steuergerätes oder einer separaten aktiven Frequenzweiche (z.B. DSP)	
5	Eingangsempfindlichkeit	Zur Einstellung der Eingangsempfindlichkeit	
6	Bass Boost - Regler	Zum Einstellen des Bass Boost Levels im Bereich von 0 bis +12 dB (für die Kanäle 3/4)	
7	Mode - Schalter	Zur Auswahl der Frequenzweichenfunktion LOW*: Es werden nur Frequenzen unterhalb der gewählten Trennfrequenz übertragen (LPF) FULL: Alle Frequenzen werden übertragen HIGH: Es werden nur Frequenzen oberhalb der gewählten Trennfrequenz übertragen (HPF) *bei Wahl der LOW Einstellung ist auch der Hochpassfilter aktiv und kann als Subsonic-Filter (SUBS) eingesetzt werden. Dies entspricht einer Bandpass-Filter Funktion (BP)	
8	Hochpass - Regler	HPF: Einstellung der Hochpass-Trennfrequenz (zwischen 5 und 500 Hz)	
9	Tiefpass - Regler	LPF: Einstellung der Tiefpass-Trennfrequenz (zwischen 40 und 4000 Hz)	

Stereobetrieb



Brückenbetrieb



Fehlerdiagnose

Problem	Kontrolle	Hilfe
Kein Ton Verstärker schaltet nicht ein	Leuchtet die PWR LED?	Sicherung prüfen Remote Kabel prüfen + 12 Volt prüfen Masse prüfen
	Leuchtet die PROT LED?	Kurzschluss am Lautsprecher Gerät überhitzt Gerät defekt
	Keine Stromzufuhr	Sicherung prüfen +12 Volt prüfen Masse prüfen
	Keine Spannung am Remote	Remote am Radio prüfen
Verstärker schaltet bei Lautstärke ab	Lautsprecherimpedanz prüfen	Prüfen Sie, ob der Widerstand am LS Terminal von 2 Ohm nicht unterschritten wird
Kein Ton (eine Seite)	Cinch / Lautsprecherkabel prüfen	Kabel/Stecker beschädigt
Protection LED leuchtet	Verstärker überhitzt	Lautstärke verringern oder Gerät einige Zeit abschalten
Trolection LLD leucillei	Kurzschluss am Lautsprecheranschluss	Lautsprecherkabel auf Kurzschluss prüfen

Garantiebedingungen

Die Gewährleistung entspricht der gesetzlichen Regelung. Eine Rücksendung kann nur nach vorheriger Absprache und in der Originalverpackung erfolgen. Bitte unbedingt einen maschinell erstellten Kaufbeleg und eine Fehlerbeschreibung beilegen. Von der Gewährleistung ausgeschlossen sind Defekte, die durch Überlastung, unsachgemäße Behandlung oder bei Teilnahme an Wettbewerben entstanden sind. Wir behalten uns das Recht vor, zukünftige Änderungen oder Verbesserungen an Produkten vorzunehmen, ohne zuvor darüber zu informieren.



Musik hören kann unter anderem emotional, beeindruckend, entspannend oder unterhaltsam sein. Dabei spielt es kaum eine Rolle, welche Art von Musik der jeweils persönliche Favorit ist, also ob es sich um instrumentale Musik, Jazz, Electro, Latin, Klassik, Rock oder eine andere Musikrichtung handelt. Die Wiedergabequalität bei dem jeweils gewünschten Pegel spielt dabei hingegen eine wichtige Rolle. Manche Musik verlangt nach gehobenen Pegeln, während andere eher leisere Töne bevorzugt.

GROUND ZERO berücksichtigt all die unterschiedlichen Wünsche der Kunden bei der Entwicklung neuer Produkte. Hierbei gilt stets die Zielsetzung, einen möglichst realistischen Sound zu erzeugen und damit die Seele der Musik und die Intention des Künstlers zu vermitteln. Zu einem einzigen Satz zusammengefasst: RESPECT THE MUSIC!

Ground Zero GmbH

Erlenweg 25 85658 Egmating Germany Tel. +49 (0)8095/873 830 www.ground-zero-audio.com



