## Mqtt and RS485 Bidirectional transmission

## 1. Overview

This is a very userful fucntion. It support any non-standard protocol by RS485 to MQTT.

## 2. Steps:

- 1. Set user's own MQTT IP and port in zm.cgi.
- 2. Connect to internet or MQTT server in local network.
- 3. Enable "RS485 to mqtt enable".

I/O Control| I/O Settings| Input Status| System Settings| Trigger Event| RS485 Interface

RS485 Interface

## Item Status Baud rate(4800,9600,38400,115200) 9600 Check bit lotzone's Sensor Modbus RTU to TCP MODBUS enable RS485 to mqtt enable I/O Control by RS485 RS485 Address(Serial relay mode is valid) OK Undo

4. The subscribe topic is "sn+stateraw", publish topic "sn+ctrraw"

3 贞明电	子MQ数据测试	軟件 V1.2.2							_		×
连接设置	=				发布数据订阅						
	192.168.1	. 199	用户名:								0
订阅号:	vf9fe4bea	2cb544estaterav	密码:		1	☑ 自动清除	1000	清除发布订阅			
发布号:	vf9fe4bea2cb544ectrraw		1	断开		□ 班级示					
13:15:20	3:>abcdefghi	ijk			13:15:20:>	31 32 33 34 35	36 37 38 39				
					数据发布度	ῗ 5	唆送 □ 窟	寸发送 1000	•	手动发	送
Addr:					ModBus发送						
	olumn1	Column2	Column3	Column4	C 设备地址		寄存器地址	长度	数据		
<b>F</b>					2 後無地址	4 4	新行器·吧址		\$338 0		÷
										手动发	
										T-9/102	:.\\
						长度: 11	ModBus设备地均				
		_			ModBusin	i≎:	ModBus数据长度	ŧ:			

