All sections except for Laptop NTRIP should have checkmarks confirming steps have been completed.

Sentera RTK PPK Module Checkout	
Confirm name and Date are listed	Performed By: Amanda Janssen
	Date: 10/12/26
Confirm all numbers match modules being sent	Module Serial Number: 122
	Module Radio Net ID 32011-00172
	Sensor Serial Number: 116
	Checkout Type (circle one): (Module) / Sensor
	RMA Number: —

System Setup - Indoors	Check / Fill In / Circle
Sensor Setup	
List sensor type (circle one) — This confirms what camera and aircraft used for testing.	6X / 6XT / 6XTP / (65R)
Verify intended aircraft (circle one) — Can be different, this is the standard.	(IF800) / IF1200
Verify sensor has Gen II or greater markings *sensor will not work with the RTK PPK hardware without Gen II upgrades*	✓
Verify sensor configuration *sensor must have Aircraft-Sentera GNSS config applied*	✓
Aircraft Setup	
Install sensor onto aircraft	✓
Install module onto aircraft	✓
Connect coax cable to module and aircraft *IF800: MCX to MCX cable and aircraft pass through* *IF1200: MCX to SMA with rail mounted bracket*	✓
Install 900Mhz antenna to aircraft	✓
Connect module to sensor via USB-C to USB-C cable	✓
Secure cable with cable clips	✓
Aircraft Hand Controller Setup	
Power on handcontroller	✓

Connect controller to hotspot / internet	✓
Open IGC	✓
Open the NTRIP menu *(Located top center, T Icon with ((·)))*	✓
Enter NTRIP credentials	✓
Select mountpoint	✓
Verify connection to NTRIP network	✓
Disconnect from NTRIP network & power off	✓
Choose Base Station OR Laptop NTRIP Setup	
Emlid Base Station	
Power on	✓
Connect to base station WiFi	✓
Verify base station output is set to USB OTG 115200	✓
Connect ground radio to Emlid using USB-C to USB-C cable	✓
Verify the ground radio has green scrolling LEDs *(if RTK-PPK module is powered on the LEDs will be solid green on ground radio)*	✓
Power down	✓
Laptop NTRIP *(Not needed if Emlid Base Station above is completed - skip to System Testing-Outdoors)*	
Power on laptop	
Connect ground radio to laptop via USB-C cable	
Verify the ground radio has green scrolling LEDs	
Connect laptop to hotspot/internet source	
Open an NTRIP client *(can be found on Evault under 27300 folder)*	
Connect to NTRIP network & set mountpoint	
Enter current LAT/LON/ALT of current location	

Set output to serial with appropriate COM port and bitrate (115200)	
Start corrections stream and verify output	
Disconnect from NTRIP network	
System Testing - Outdoors	
Ground Radio Checkout (Base Station or Laptop NTRIP)	
Selection ground radio corrections source type — Base Station is used for Testing	(Base Station) / Laptop NTRIP
Setup base station / laptop	✓
Verify corrections are ready *Base Station: Self survey is complete* *Laptop: corrections stream is running*	✓
Power on aircraft	✓
Verify status LED on module illuminates solid red	✓
Power on hand controllers and open IGC	✓
Verify status LED on module turns green	✓
Verify the sensor starts a session	✓
Verify GPS fix type — Do not pass unless RTK FIXED	Standard GPS / RTK Float / (RTK Fixed)
Verify module acheives an RTK Fixed solution	
Webpage verification *Open web browser on hand controller and navigate to 192.168.144.141*	Time Sync present ✓
Sentera camera interface verification *Camera icon in the upper right hand corner of IGC v1.4 and greater*	✓
Take 5 images — Confirm "Time sync Present" is listed somewhere in the section. Does not matter what slot it is in.	✓
Power down ground radio	✓
Verify the the GPS status returns to standard GPS	
Webpage verification *Open web browser on hand controller and navigate to 192.168.144.141*	✓
Sentera camera interface verification *Camera icon in the upper right hand corner of IGC v1.4 and greater*	✓
Hand Controller NTRIP	
Connect hotspot to hand controller	✓

Open NTRIP menu in IGC (Located top center, ((T)) Icon)	✓
Connect to the NTRIP network	✓
Verify the GPS fix type — Do not pass unless RTK FIXED	Standard GPS / RTK Float / RTK Fixed
Verify module acheives an RTK Fixed solution	
Sentera camera interface verification *Camera icon in the upper right hand corner of IGC v1.4 and greater* *DO NOT USE WEBPAGE*	Time Sync present
Take 5 images — Confirm "Time sync Present" is listed somewhere in the section. Does not matter what slot it is in.	✓
Power down systems	✓
Disconnect and Pack System	
Remove USB-C to USB-C Cable and clips and pack in RTK-PPK case	✓
Remove 900 Mhz antenna from aircraft and pack in RTK-PPK case	✓
Disconnect coax cable from module and aircraft, pack in RTK-PPK case	✓
Remove module from aircraft, pack in RTK-PPK case	✓
Ensure all remaining items originally in RTK-PPK case are placed back inside	✓
Data Retention - Indoors	
Navigate to: *\\taurus\production\Systems & Kits\21076-XX -- RTK PPK Module*	✓
Create a folder with the module serial number as the folder name If this is for a camera RMA place these item into the appropriate RMA folder	✓
Place data into the folder	✓
Scan and upload a copy of this document to the same folder	✓