

Sentera RTK PPK Module Checkout	
Performed By:	Amanda Sarsen
Date:	8/18/26
Module Serial Number:	110
Module Radio Net ID	32011 00 160
Sensor Serial Number:	116
Checkout Type (circle one):	Module / Sensor
RMA Number:	—
System Setup - Indoors	Check / Fill In / Circle
Sensor Setup	
List sensor type (circle one)	6X / 6XT / 6XTP / 65R
Verify intended aircraft (circle one)	IF800 IF1200
Verify sensor has Gen II or greater markings <i>sensor will not work with the RTK PPK hardware without Gen II upgrades</i>	✓
Verify sensor configuration <i>sensor must have Aircraft-Sentera GNSS config applied</i>	✓
Aircraft Setup	
Install sensor onto aircraft	✓
Install module onto aircraft	✓
Connect coax cable to module and aircraft <i>IF800: MCX to MCX cable and aircraft pass through</i> <i>IF1200: MCX to SMA with rail mounted bracket</i>	✓
Install 900Mhz antenna to aircraft	✓
Connect module to sensor via USB-C to USB-C cable	✓
Secure cable with cable clips	✓
Aircraft Hand Controller Setup	
Power on handcontroller	✓

Connect controller to hotspot / internet	✓
Open IGC	✓
Open the NTRIP menu <i>(Located top center, T Icon with ({}))</i>	✓
Enter NTRIP credentials	✓
Select mountpoint	✓
Verify connection to NTRIP network	✓
Disconnect from NTRIP network & power off	✓
Choose Base Station OR Laptop NTRIP Setup	
Emlid Base Station	
Power on	✓
Connect to base station WiFi	✓
Verify base station output is set to USB OTG 115200	✓
Connect ground radio to Emlid using USB-C to USB-C cable	✓
Verify the ground radio has green scrolling LEDs <i>(if RTK-PPK module is powered on the LEDs will be solid green on ground radio)</i>	✓
Power down	✓
Laptop NTRIP	
<i>(Not needed if Emlid Base Station above is completed - skip to System Testing-Outdoors)</i>	
Power on laptop	
Connect ground radio to laptop via USB-C cable	
Verify the ground radio has green scrolling LEDs	
Connect laptop to hotspot/internet source	
Open an NTRIP client <i>(can be found on Evault under 27300 folder)</i>	
Connect to NTRIP network & set mountpoint	
Enter current LAT/LON/ALT of current location	

Set output to serial with appropriate COM port and bitrate (115200)	
Start corrections stream and verify output	
Disconnect from NTRIP network	
System Testing - Outdoors	
Ground Radio Checkout (Base Station or Laptop NTRIP)	
Selection ground radio corrections source type	Base Station Laptop NTRIP
Setup base station / laptop	✓
Verify corrections are ready <i>Base Station: Self survey is complete</i> <i>Laptop: corrections stream is running</i>	✓
Power on aircraft	✓
Verify status LED on module illuminates solid red	✓
Power on hand controllers and open IGC	✓
Verify status LED on module turns green	✓
Verify the sensor starts a session	✓
Verify GPS fix type	Standard GPS / RTK Float / RTK Fixed
Verify module achieves an RTK Fixed solution	✓
Webpage verification <i>Open web browser on hand controller and navigate to 192.168.144.141</i>	✓
Sentera camera interface verification <i>Camera icon in the upper right hand corner of IGC v1.4 and greater</i>	Time Sync present
Take 5 images	✓
Power down ground radio	✓
Verify the the GPS status returns to standard GPS	✓
Webpage verification <i>Open web browser on hand controller and navigate to 192.168.144.141</i>	✓
Sentera camera interface verification <i>Camera icon in the upper right hand corner of IGC v1.4 and greater</i>	✓
Hand Controller NTRIP	
Connect hotspot to hand controller	✓

Open NTRIP menu in IGC (Located top center, ((T)) icon)	✓
Connect to the NTRIP network	✓
Verify the GPS fix type	Standard GPS / RTK Float / RTK Fixed
Verify module achieves an RTK Fixed solution	✓
Sentera camera interface verification <i>Camera icon in the upper right hand corner of IGC v1.4 and greater DO NOT USE WEBPAGE</i>	Time Sync present
Take 5 images	✓
Power down systems	✓
Disconnect and Pack System	
Remove USB-C to USB-C Cable and clips and pack in RTK-PPK case	✓
Remove 900 Mhz antenna from aircraft and pack in RTK-PPK case	✓
Disconnect coax cable from module and aircraft, pack in RTK-PPK case	✓
Remove module from aircraft, pack in RTK-PPK case	✓
Ensure all remaining items originally in RTK-PPK case are placed back inside	✓
Data Retention - Indoors	
Navigate to: \\taurus\production\System & Kits\21076-XX -- RTK PPK Module	✓
Create a folder with the module serial number as the folder name	✓
If this is for a camera RMA place these item into the appropriate RMA folder	✓
Place data into the folder	✓
Scan and upload a copy of this document to the same folder	✓