Brava One Espresso Machine: User Manual

Thank you for choosing the Brava One. This manual covers setup, daily use, cleaning and troubleshooting. Model number BR-100, firmware 2.4. Keep this manual for later reference.

Safety. Connect the machine only to a grounded outlet with 220 to 240 volts. Never immerse the machine, the power cord or the plug in water. Children under 8 years must not use or clean the machine. The steam wand and the brew group get hot during use; do not touch them until they have cooled for at least 10 minutes.

Setup

Place the machine on a flat, dry surface at least 10 cm away from the wall. Remove the water tank, rinse it and fill it with fresh, cold water up to the MAX mark. The tank holds 1.8 liters.

Before the first use, insert the water filter cartridge. Soak it in cold water for 5 minutes, then screw it into the holder inside the tank. Set the water hardness in the menu under Settings, Water hardness. The factory setting is level 3 (medium).

Press the power button. The machine heats up in about 45 seconds and rinses the brew group automatically. The coffee button lights up white when the machine is ready.

Making Coffee

Fill the bean container with up to 250 grams of whole beans. Do not use oily, caramelized or flavored beans, as they can block the grinder.

The grinder has 12 settings. Setting 1 is the finest and setting 12 the coarsest. Change the grind setting only while the grinder is running. For a classic espresso we recommend settings 4 to 6.

Press the espresso button once for one cup (40 ml) or twice for two cups. Hold the button for 3 seconds to save a new cup volume between 20 and 220 ml. The brew temperature can be set to low (90 degrees Celsius), medium (92 degrees Celsius) or high (94 degrees Celsius).

Milk. Immerse the steam wand in cold milk and turn the steam knob counterclockwise. Wipe the steam wand with a damp cloth and release steam for 2 seconds after every use.

Cleaning and Maintenance

Empty the drip tray and the coffee grounds container daily. The grounds container holds up to 12 portions; the display shows a message when it is full.

Rinse the brew group under running water once a week. Do not use detergent and do not put the brew group in the dishwasher. Let it air-dry before inserting it again.

Replace the water filter cartridge every 2 months or after 50 liters of water, whichever comes first. Only use Brava CF-2 filter cartridges.

Descaling. The machine asks for descaling with the message Descale. Use one bottle of Brava descaler (250 ml) mixed with water up to the 0.5 liter mark. Descaling takes about 25 minutes and must not be interrupted. Remove the water filter before descaling.

Troubleshooting

E01: The brew group is missing or not inserted correctly. Insert the brew group and close the service door.

E03: The grinder is blocked. Switch off the machine, empty the bean container and remove foreign objects with the cleaning brush. If the error remains, contact customer service.

E05: The water tank is empty or the float is stuck. Fill the tank and check that the float moves freely.

E09: The water circuit is blocked by limescale. Descale the machine. If E09 appears again within one week, contact customer service.

Coffee is too watery: choose a finer grind setting and use fresh beans. Coffee is not hot enough: set the brew temperature to high and preheat the cups.

Technical Specifications

Power: 1450 watts. Voltage: 220 to 240 volts, 50 Hz. Pump pressure: 15 bar. Water tank: 1.8 liters. Bean container: 250 grams. Grounds container: 12 portions. Weight: 8.2 kg. Dimensions: 24 cm wide, 44 cm deep, 36 cm high. Power consumption in standby: under 0.5 watts.

The machine switches off automatically after 30 minutes without use. The auto-off time can be set to 15, 30, 60 or 120 minutes.

Warranty and Service

Brava gives a warranty of 2 years from the date of purchase. Registering the machine at the Brava website within 30 days extends the warranty to 3 years.

The warranty does not cover damage caused by missing descaling, by using unsuitable beans, or by repairs from unauthorized service partners.

Customer service is available Monday to Friday from 8:00 to 18:00 at +49 30 1234 5678. Please have the serial number ready; it is printed on the label behind the drip tray.