



結構設計 Structural Design

結構分析軟體PISA3D之應用

陳沛清博士

Pei-Ching Chen, Ph.D

Associate Professor

Department of Civil and Construction Engineering,
National Taiwan University of Science and Technology, Taiwan

Adjunct Associate Researcher

National Center for Research on Earthquake Engineering

E-mail: peichingchen@mail.ntust.edu.tw

112學年度第2學期 - 營建工程初階設計與實作





結構分析軟體PISA3D之應用

課程助教張原嘉鍾國佑

Graduate Student

Department of Civil and Construction Engineering,
National Taiwan University of Science and Technology, Taiwan

E-mail:

M11205314@mail.ntust.edu.tw M11205335@mail.ntust.edu.tw






■下載連結

PISA3D

The latest PISA3D for free trial and academic applications (the maximum number of nodes is 200) can be downloaded from here:

[DOWNLOAD]

If you need the technical support of using PISA3D, please contact us via the e-mail: PISA3D@narlabs.org.tw











112學年度第2學期 - 營建工程初階設計與實作





4.










6. ■執行



7. ■ 完成安裝












■使用手册





Example	2024/4/5 下午 06:12	檔案資料夾
GetYourlD	2024/4/5 下午 06:12	檔案資料夾
	2024/4/5 下午 06:12	檔案資料夾
PISA3D SE	2024/4/5 下午 06:12	檔案資料夾
Read Me	2024/4/5 下午 06:12	檔案資料夾







Platform of Inelastic Structural Analysis for 3D Systems PISA3D Standard Edition R3.2 **User's Manual Bo-Zhou Lin** Yi-Jer Yu Ming-Chieh Chuang Keh-Chyuan Tsai

National Center for Research on Earthquake Engineering, Taiwan

Department of Civil Engineering, National Taiwan University

All rights reserved, March, 2011

Table of Contents		
Introduction	I	
Notes on Running Analysis	п	
Contents of Output Files	IV	
PART A. Initial Setting Command	A-1	
A01. Analysis Platform Line	A-1	
A02. Analysis Title Line	A-1	
A03. Force Unit Line	A-2	
A04. Length Unit Line	A-2	
PART B. Analysis Method Command	B-1	
B01. One-Step Nonlinear Static Analysis	B-1	
B02. Load Control Nonlinear Static Analysis	B-2	
B03. Displacement Control Nonlinear Static Analysis	B-3	
B04. Modal Analysis	B-5	
B05. Nonlinear Dynamic Analysis (Newmark Method)	B-6	
B06. Nonlinear Dynamic Analysis (OS Method)	B-8	
PART C. Analysis Control Setting Command	C-1	
C01. Geometric Nonlinear Effect	C-1	
PART D. Node Data Command	D-1	
D01. Node Generation	D-1	
D02. Nodal Degree of Freedom Assign	D-2	
D03. Nodal Lump Mass Assign	D-4	
D04. Nodal Linear Spring	D-5	
D05. Constraint Definition (Rigid Diaphragm)	D-6	
PART E. Load Pattern Command	E-1	
E01. Nodal Load	E-1	
E02. Ground Acceleration Record	E-2	
PART F. Material Definition Command	F-1	
F01. Elastic Material	F-1	
F02. Bilinear Material	F-3	
F03. Hardening Material	F-5	
-		

	J01. Termination of Input File	J-1
PART J. End Input Command		J-1
	103. Output todal responses in a specified file	1-0
	105. Output nodal responses in a specified file	I-6
	103. Output Nodal Relative Responses 104. Output element responses in a specified file	I-4 I-5
	I02. Output Nodal Absolute Responses I03. Output Nodal Relative Responses	I-3 I-4
	I01. Output Interval Setting Command	I-1
P	1	I-1
DA	ART I. Output Setting Command	I-1
	H08. Element Section Definition - BCSection03 Command	H-16
	H07. Element Section Definition - BCSection02 Command	H-14
	H06. Element Load Case	H-13
	H05. Element Load (Fixed End Force)	H-11
	H04. Interaction Surface Definition (RC Column Type)	H-9
	H03. Interaction Surface Definition (Wide-Flange Steel Type)	H-5
	H02. Rigid End Zone Definition	H-3
ľA	HOL Frame Section Definition - BCSection Command	H-1
		** *
	G06. BilinearDamper Element	G-27
	G05. Damper Element	G-22
	G04. Panel Element	G-16
	G03. Joint Element	G-12
	G02. BeamColumn Element	G-5
	G01. Truss Element	G-1
PA	PART G. Element Definition Command	
	F09. TensionOnlyBilinear Material	F-28
	F08. Buckle Material	F-21
	F07. Fracture Material	F-16
	F06. Bilinear02 Material	F-14
	F05. Bilinear-Elastic Material	F-12
	F04. Degrading Material	F-8