

WS8461  
**User manual**

**1. Introduction**  
To all residents of the European Union  
Important environmental information about this product:  
This symbol on the device or the package indicates that the device after its lifecycle could harm the environment.  
The device should be disposed of at a specialized company for recycling.  
This device should be returned to a specialized company for recycling service. Respect the local environmental regulations.  
Thank you for choosing Velleman! Please read the manual before bringing this device into service. If the device was damaged during transport, do not use it and contact your dealer.

**Safety Instructions**

Keep this device away from children and pets.

**General Guidelines**

Refer to the Velleman® Service and Quality Manual.

Protect this device from shocks and abuse while operating the device.

Protect the device against extreme heat and cold.

Familiarise yourself with the functions of the device.

All modifications of the device are forbidden.

Only use the device for its intended purpose.

Damage caused by unauthorised use will void the warranty.

Damage caused by disregard of the instructions is not covered by the warranty and the manufacturer is not liable for any ensuing defects or problems.

**4. Use**

Connect the outdoor sensor to the device.

Insert 1 x 1.5V AAA battery into the battery compartment.

Press C/F to switch between °C and °F.

Press IN/OUT to switch between indoor and outdoor display.

Press MIN/MAX to switch between the minimum and maximum memory.

Hold FREEZE pressed to freeze the display.

01.07.2010

