

Management interface

CLI and GUI management interfaces

Lenovo

Management tool overview

The 4450/5450/9450 series adapters support the following management interfaces, allowing them to be used with different Microchip companies:

- ARCCONF (CLI)
- maxView Storage Manager (GUI)

ARCCONF and maxView can be used to perform the following tasks:

- Creating and deleting logical drives
- Updating adapter firmware
- Monitoring logical drives status
- Collecting adapter service logs

Installing ARCCONF

1. Download the ARCCONF installation package from <https://support.lenovo.com/>.
2. When the download is complete, extract the package contents to the installation directory in your system – for example, C:\Program Files in Windows or /opt or /usr in Linux.
3. On Linux systems, use the `chmod arccconf +x` command to ensure the `arccconf` command tool has execute privilege.

Note: Installation procedures might vary with different operating systems. For detailed installation information, refer to the Installing the Command Line Utility section of the [ThinkSystem 4450/5450/9450 Series Adapters Software User Guide](#).

Starting ARCCONF

1. To start ARCCONF, enter one of the following commands:

Options	Description
Windows	<code><install_dir>\arccconf.exe</code>
Linux	<code>/<install_dir>/arccconf</code>
VMware ESXi	<code>/opt/arccconf/bin/arccconf</code>

2. To see a list of available commands, type `ARCCONF` at the prompt. For more information about a specific command, type `ARCCONF <command_name> help`. Click [HERE](#) to see a list of ARCCONF commands.

Installing maxView Storage Manager

Prerequisites:

Users should prepare the following port numbers:

- Redfish Server port number – the default port is recommended (8081)
- maxView Web Server port number – the default port is recommended (8443)

Download steps:

1. Go to <https://datacentersupport.lenovo.com/>
2. Search for maxView as the keyword on the website and download the installation package. Click [HERE](#) to see a screenshot.
3. Installation and uninstallation procedures might vary with different operating systems. For detailed installation information, refer to the *Installing maxView Storage Manager* section of the [maxView™ Storage Manager User Guide](#)

Installing maxView Storage Manager



L

maxView

Q

X

My Account

English

REFINE BY

Clear all

Operating Systems

Q

☐ Linux

☐ OS Independent

☐ Red Hat Enterprise Linux 7 (64-bit)

Show More

Type

Q

☐ Downloads (34)

☐ How To's (41)

Show More

Categories

Q

☐ BIOS / UEFI / XCC

☐ Blue Screen / Error Codes / Crashing / Performance

☐ Blue Screen / Error Codes / Crashing / Performance

Show More

Products

Q

☐ ST250 V3 (ThinkSystem) - Type 7DC E

☐ ST250 V3 (ThinkSystem) - Type 7DC F

☐ Lenovo EveryScale (EveryScale .DSS .G .GSS)

Support > Data Center Support > Search Results

Search Results

Select your product for better results

All (75)

Downloads (34)

How To's (41)

Content Type

Sort By: Relevance

How To Install MaxView Storage Manager On Windows

Lightbulb icon

8/20/2024

How To Collect Logs Within MaxView Storage Manager

Lightbulb icon

4/19/2024

MaxView Storage Manager (For VMWare)

Download icon

10/17/2022

MaxView Storage Manager (For Linux)

Download icon

5/27/2022

MaxView Storage Manager (For Windows)

Download icon

3/9/2022

Reference

For more information about ARCCONF and maxView Storage Manager, refer to the following documents on the [ThinkSystem 4450/5450/9450 Series Adapter page](#)

- maxView™ Storage Manager User Guide
- Software User Guide (including ARCCONF information)



More information about the adapter is available at the following site:

[Lenovo Press](#)

The Installation and User Guide is available in PDF format:

 [Installation and User Guide for ThinkSystem 4450 Series](#)

 [Installation and User Guide for ThinkSystem 5450/9450 Series](#)

The Software User Guide is available in PDF format (English only):

 [Software User Guide](#)

The maxView™ Storage Manager User Guide is available in PDF format (English only):

 [maxView™ Storage Manager User Guide](#)