
Repair Manual

911 Carrera **(993)**

Volume VII: Wiring diagrams

Volume I:	Overall vehicle – General	0
General	Maintenance, diagnosis	03
Engine	Engine	1
	Engine – Crankcase, mounting	10
	Engine – Crankshaft, pistons	13
	Engine – Cylinder head, valve drive	15
	Engine – Lubrication	17
	Engine – Cooling	19
	Fuel, exhaust system, engine electrical system	2
	Fuel supply, control	20
	Exhaust system – Turbocharging	21
	Fuel system, electronic injection	24
	Fuel system, K-Jetronic	25
	Exhaust system	26
	Starter, power supply, GRA	27
	Ignition system	28
Volume II:	Transmission	3
Transmission	Clutch, control	30
Manual transmission	Manual transmission – Controls, case	34
	Manual transmission – Gears, shafts, inner operation	35
	Final drive, differential, differential lock	39
Volume III:	Transmission	3
Transmission	Automatic transmission – Torque converter	32
Automatic	Automatic transmission – Controls, case	37
transmission	Automatic transmission – Gears, control	38
	Final drive, differential, differential lock	39
Volume IV:	Chassis	4
Chassis	Front wheel suspension, drive shaft	40
	Rear wheel suspension, drive shaft	42
	Wheels, tires, alignment	44
	Anti-Lock System (ABS)	45
	Brakes – Mechanical	46
	Brakes – Hydraulics, regulator, booster	47
	Steering	48

Volume V:	Body	5
Body	Body front section	50
	Body center section, roof, frame	51
	Body rear section	53
	Hoods, lids	55
	Front doors, Central Locking System	57
	Exterior body equipment	6
	Sunroof	60
	Soft top, hardtop	61
	Bumpers	63
	Glasses, window control	64
	Exterior equipment	66
	Interior equipment, passenger protection	68
	Interior body equipment	7
	Trim, insulation	70
	Seat frames	72
	Seat upholstery, covers	74

Volume VI:	Air conditioning	8
Air conditioning	Heater	80
Vehicle electrics	Ventilation	85
	Air conditioning	87
	Auxiliary air conditioning system	88
	Electrical system	9
	Instruments, alarm	90
	Radio, telephone, on-board computer	91
	Windshield wipers and washer	92
	Exterior lights, lamps, switches	94
	Interior lights, lamps, switches	96

Volume VII:	Electrical system	9
Wiring diagrams	Wiring	97

Volume VIII:	Diagnosis	D
Diagnosis	Self-diagnosis	03
	DME Diagnosis	24
	Tiptronic Diagnosis	37
	PDAS Diagnosis	39
	ABS Diagnosis	45
	Airbag Diagnosis	68
	Heater Diagnosis	80
	Alarm Diagnosis	90

Preface

Structure

The "Technical Literature" for the "911 Carrera (993)" model is basically structured as before, i.e. the structure follows the familiar repair groups.

A new feature is that the structure includes the main groups **0 to 9** and the main group **D**.

Main groups:	0	Complete vehicle – General
	1	Engine
	2	Fuel, exhaust, engine electrical system
	3	Transmission
	4	Chassis
	5	Body
	6	Body equipment, outside
	7	Body equipment, interior
	8	Air conditioning
	9	Electrical system
	D	Diagnosis

Layout

The layout in the below items remains unchanged throughout the repair manual

1. Table of tightening torques
2. Special tools required
3. Exploded views
4. Legends for the exploded views
5. Assembly notes / use of special tools

As a new feature, however, the former item 6 (Repair group diagnosis) is no longer filed in the volume corresponding to the respective repair group. The **Diagnosis test plans / diagnosis procedures** have been combined in a **separate Diagnosis volume** broken down according to the main groups 0 to 9.

Another new feature is that the contents of the "Service Information Technik" are indicated in the Repair Manual. This brochure concentrates on a description of the design and function of components and of the new features introduced for a particular model year.

All major repair procedures and repair descriptions are identified by a two- or four-digit **Service Number** completed by two additional digits to identify the work that corresponds to the first six digits of the working position number in the Working Times and Damage Catalog.

Explanation:	30	37	37	50 (full working position number)
Repair group here: Clutch, control				
Component designation here: Clutch control shaft				
Activity here: Dismantling and assembling				
Index here: Removed				

30 37 37 50	Working position no. from Working Times and Damage Catalog , consisting of repair group, component designation, activity and index
30 37 37	Six-digit number in Repair Manual , consisting of repair group, component designation and activity
30 37	Service number in Service Information , consisting of repair group and component designation

The introduction of a service number in the "technical literature" is intended to facilitate standardization and positive identification to allow direct cross-referencing among the various documents. This is of particular importance with regard to the use of electronic media.

VII Wiring Diagrams

The Repair Manual of the 911 Carrera (1993) also includes the 911 Carrera 4 manual (1993 four-wheel drive). The 911 Carrera (1993) is the basic model covered by the repair operations described in this Manual. "911 Carrera (1993)" is also indicated in the header of each page.

Descriptions of repair operations that deviate for the 911 Carrera 4 will be included after the respective 911 Carrera section. The repair descriptions of both models are separated by a cover page. All pages included after the cover page (separation sheet) have the "911 Carrera 4" heading. To facilitate distinction, the page numbering will start with 100.

9 Electrical System

97 Wiring

97 90	Support, left-hand engine compartment side	97 - 01
97 97	Support, right-hand engine compartment side	97 - 02
97 09	Passenger compartment wiring harness	97 - 03
97 09 41	Repairing the passenger compartment wiring harness	97 - 05
97 16 41	Repairing the front-end wiring harness	97 - 07
97 09	Spare part - passenger compartment wire harness for Model '95	97 - 011
97 50 41	Repairing wire harness no. 173 (DME)	97 - 013
97 52	Engine wire harness	97 - 014
97 52	Spare part - passenger compartment wire harness for Model '96	97 - 015
97 09	Spare part - passenger compartment wire harness Model '96	97 - 017
97 09	Spare part - passenger compartment wire harness for Model '97	97 - 019
97	Wiring diagram 911 Carrera (1993) model '94	97 - 1
97	Wiring diagram 911 Carrera (1993) model '95	97 - 37
97	Wiring diagram 911 Carrera (1993) model '96	97 - 77
97	Wiring diagram 911 Carrera (1993) model '97/98	97 - 117

Survey of contents of Service Information Technik '95


The Service Information gives a detailed description of the technical features of the new 911 Carrera.

	Rep. Gr.	Page
Engine		
General		1 - 1
Engine cross-sections	10	1 - 4
Full-load curve		1 - 6
Belt pulley	13	1 - 8
Pistons	13	1 - 10
Hydraulic valve lash adjuster	15	1 - 16
Setting the timing	15	1 - 18
USA - auxiliary air pump		1 - 19
Fuel and ignition systems		
General		2 - 1
DME - Schematic	24	2 - 2
Fuel - air flow	24	2 - 3
Exhaust gas flow	26	2 - 5
DME control unit 2.10.1	24	2 - 9
Mass air flow sensor	24	2 - 12
Throttle potentiometer	24	2 - 18
Ignition system	28	2 - 24
Plausibility test		2 - 28
Diagnosis		2 - 29
Auxiliary air pump	26	2 - 33
Power transmission		
Transmission	30	3 - 1
Clutch	30	3 - 2
Manual transmission	34	3 - 3
Transmission ratios		3 - 6
Gear set	35	3 - 8
Synchromesh	35	3 - 9
Final drive	39	3 - 13
Oil supply		3 - 15
Porsche Tiptronic	37	3 - 16
Modifications for the '95 model year		3 - 17

	Rep. Gr.	Page
Running gear		
General		4 - 1
Front axle	40	4 - 2
Steering	48	4 - 7
Rear axle	42	4 - 8
Elasto-kinematic toe correction	42	4 - 12
Coil springs (layout)	42	4 - 13
Wheels, tires	44	4 - 15
Suspension alignment	44	4 - 17
Brakes	47	4 - 20
Bleeding the brakes	47	4 - 23
ABS 5	45	4 - 24
Operation of the ABD	45	4 - 30
Diagnosis ABS/ABD	45	4 - 34
Body		
General		5 - 1
Constructional dimensions	50	5 - 4
Aerodynamics and air ducting	50	5 - 8
Body equipment		
Body equipment		6 - 1
Color scheme as of 1995 model year	60	6 - 1
Windows	64	6 - 8
Airbag system	68	6 - 14
Body - interior trim		
Body - interior trim	70	7 - 1
Seats	72	7 - 5
Heating, air conditioning, ventilation		
Particle filter	85	8 - 1
Air ducting	80	8 - 3
Heating - air conditioning unit	85	8 - 5
Heating - air conditioning unit	87	8 - 6
Series resistor of rear blower	80	8 - 9

	Rep. Gr.	Page
Electrical system		
Instruments	90	9 - 1
Alarm system/central locking system	90	9 - 3
Heated rear window	64	9 - 6
Central Information System (Z I)	91	9 - 7
Radio "Alpine 7807"	91	9 - 10
Sound package, DSP-System	91	
Windshield wiper and washer system	92	
Headlights	94	
Front end light cluster	94	
Tail lights	94	
Engine compartment baseplate	97	
Wiring diagram		
Summary		
Maintenance		0 - 1
Number ranges		0 - 4
Technical data		0 - 5

97 90 Support, left-hand engine compartment side



210

1 - Not used

2 - Relay, auxiliary air pump (USA/Canada only)

3 - Relay, AC compressor

4 - Relay, heated rear window

5 - Relay, heater blower

6 - Not used

7 - Connector, suppression capacitor

8 - Not used

9 - Connector, DME X 4/2, engine X3

10 - Connector, DME X 60

11 - Fuse, heater blower 30 A


12 - Fuse, rear window 25 A

13 - Fuse, AC compressor 7,5 A

14 - Fuse, auxiliary air pump 40 A

15 - Suppression capacitor

97 97 Support, right-hand engine compartment side



Oil level sender

Micro switch lock

Temperature sensor catalytic converter

Not

Oxygen sensor CO potentiometer
(vehicles fitted with catalytic converter)

AC compressor

CO potentiometer, for vehicle not fitted
with catalytic converter

Rear lights

97 09 Passenger compartment wiring harness

Only one wiring harness is supplied world-wide for service. The following modifications are therefore required when replacing the wiring harness:

LHD vehicles

1. Connect jumper adapter 928. 615. 125. 00 to relay base R 34 on the Central Electrical System (not for Japan and USA/Canada vehicles).
The foglight relay is retained on Japan and USA/Canada vehicles.
2. Disconnect coding jumper (in front of speedometer) on vehicles with 72-liter tank (wire color orange).
3. On vehicles fitted with anti-drive-off feature (M 530), the wires (0.5 sq.mm br/gn) for the driver door (X 11/1, pin 12) and passenger door (X 12/1, pin 11) connections must be unlatched, cut off and insulated.
4. On Tiptronic vehicles **without anti-drive-off feature**, the yellow-black wire (0.75 sq.mm) for the DME connection (X 4/1, pin 13) must be unlatched and soldered to pin 2 along with the black wire (2.5 sq.mm) (i.e. both wires soldered to pin 2).
5. On manual transmission vehicles **without anti-drive-off feature**, the jumper adapter 964. 610. 184. 00 must be connected on the relay base R 61 of the Central Electrical System.
6. On vehicles **without four-wheel drive**, the brown wire (0.5 sq.mm) must be unlatched from connector II (white) of the Central Information System (pin 24) and insulated.

7. On vehicles **without sound package**, radio connector II (speaker wires) must be separated from the booster adapter (8-pin connector ahead of radio) and connected to the radio.

8. Instead of the buzzer (443. 951. 307 B) of the light reminder, the gong relay (928. 618. 102. 03) must be fitted (already fitted on USA / Canada and Saudi-Arabia vehicles)

RHD vehicles

1. Connect jumper adapter 928. 615. 125. 00 to relay base R 34 on the Central Electrical System (not for Japan and USA/Canada vehicles).
The foglight relay is retained on Japan and USA/Canada vehicles.
2. On vehicles **without four-wheel drive**, the brown wire (0.5 sq.mm) must be unlatched from connector II (white) of the Central Information System (pin 24) and insulated.
3. On vehicles **without sound package**, radio connector II (speaker wires) must be separated from the booster adapter (8-pin connector ahead of radio) and connected to the radio.

97 09 41 Repairing the passenger compartment wiring harness

Note

The ABS and brake pad wear indicator combination wires are integral parts of the wiring harness. When repairing damaged sections, the integral wires can be cut off and replaced with repair wires.

The passenger compartment wiring harness includes the rear left and right wires.

Run the following operational checks after completing the repair:

ABS: Check with system tester 9288.

Brake pad wear indicator: The lamp must go dim when the engine is running, provided that the pads are in good condition.

Joints

The joints for disconnecting the wiring are located inside the emergency seat pan on the left and right-hand sides ahead of the wire exit towards the outside.

1. Disconnect battery.
2. Fold emergency seat backrests forward.
3. Remove rear panel trim.
4. Tie damping mat out of the way with a strip of self-adhesive tape.

Note

Undo soft top motors on cabriolet vehicles (4 bolts).

5. Starting at the rubber grommets, cut insulating hose open along a length of approx. 20 mm towards the right.
6. Remove PVC insulating tape.
7. Remove shrink-fit caps from joints.


8. Cut off connectors.

9. Remove combination wires.

10. Fit repair wires from wheel carriers towards seat pan.

11. Strip wires along a length of 10 mm.

12. Connect wires according to table with crimp connectors and standard crimping tool (A).



1318 - 97

Combination wire		Wiring harness
Color	Length	Color
		Rear left
br/sw	30 mm	br/sw
br/gn	60 mm	br/gn
br/ws	90 mm	ws*
br/bl	120 mm	shield
br	150 mm	br

* shielded wires

Combination wire		Wiring harness
Color	Length	Color
		Rear right
br/sw	30 mm	br/sw
br/gn	60 mm	br/gn
br/ws	90 mm	ge*
br/bl	120 mm	shield
br	150 mm	br

* shielded wires

br - brown
 sw - black
 ge - yellow
 bl - blue
 ws - white
 gn - green

13. Solder wire tips after crimping (B).
14. Refit shrink-fit caps and shrink into place with hot air gun (C).
15. Wrap entire joint area with standard PVC tape.

97 16 41 Repairing the front-end wiring harness

Note

1910 - 97

The ABS and brake pad wear indicator combination wires are integral parts of the wiring harness. When repairing damaged sections, the integral wires can be cut off and replaced with repair wires.

The front-end wiring harness includes the front left and right wires.

Run the following operational checks after completing the repair:

ABS: Check with ABS tester.


Brake pad wear indicator: The lamp must go dim when the engine is running, provided that the pads are in good condition.

Joints

The joints for disconnecting the wiring are located on the right and left sides inside the luggage compartment above the side member near the strut towers.

Front right

1. Disconnect battery.
2. Remove right-hand front wheel
3. Remove rear wheel housing liner.
4. Undo tie-wrap in wheel housing area.
5. Undo tie-wrap in luggage compartment.



6. Cut insulating hose open at the wiring harness.

7. Remove PVC insulating tape.

8. Remove shrink-fit caps from joints.


9. Cut off connectors.

10. Remove combination wire.

11. Fit repair wire.

12. Strip wire along a length of 10 mm.

13. Connect wires according to table with crimp connectors and standard crimping tool (A).



Combination wire		Wiring harness
Color	Length	Color
		Front right
br/sw	30 mm	br/sw
br/gn	60 mm	br/gn
br/ws	90 mm	gn*
br/bl	120 mm	shield
br	150 mm	br


* shielded wire

br - brown
sw - black
bl - blue
ws - white
gn - green

14. Solder wire tips after crimping (B).
15. Refit shrink-fit caps and shrink into place with hot air gun (C).
16. Wrap entire joint area with standard PVC tape.


Front left

1. Disconnect battery.
2. Remove left-hand front wheel
3. Remove rear wheel housing liner.
4. Undo tie-wrap in wheel housing area.
5. Remove bracket for brake fluid reservoir.



1917 - 97


6. Undo tie-wrap in luggage compartment.



7. Cut insulating hose open at the wiring harness.
8. Remove PVC insulating tape.
9. Remove shrink-fit caps from joints.
10. Cut off connectors.
11. Remove combination wire.
12. Fit repair wire.
13. Strip wires along a length of 10 mm.

14. Connect wires according to table with crimp connectors and standard crimping tool (A).

17. Wrap entire joint area with standard PVC tape.



Combination wire		Wiring harness
Color	Length	Color
		Front left
br/sw	30 mm	br/sw
br/gn	60 mm	br/gn
br/ws	90 mm	rt*
br/bl	120 mm	shield
br	150 mm	br

* shielded wire

br - brown
 sw - black
 rt - red
 bl - blue
 ws - white
 gn - green

15. Solder wire tips after crimping (B).
16. Refit shrink-fit caps and shrink into place with hot air gun (C).

97 09 Spare part - passenger compartment wire harness for Model '95

World-wide, 8 wire harnesses are available as spare parts. When using this wire harness, the following modifications must therefore be made:

Left-hand drive vehicles, model '95

1. Insert jumper adapter 964.610.184.00 in relay socket R 34 on the central electrical system (not for Japan and USA/Canada vehicles).
On Japan and USA/Canada vehicles, the foglight relay remains in position.
2. On Tiptronic vehicles **without immobilizer**, the wire (0.75 mm² yellow/black) on the immobilizer relay (R 61), pin 7, must be cut off about 80 mm ahead of the relay socket. The lead from relay pin 7 must then be crimped to the lead (4 mm², yellow) from pin 3 (double connection).
See wiring diagram - section N 49 line (0.75 mm² yellow) "M 249 not M 530"
3. On manual vehicles **without immobilizer**, jumper adapter 964.610.184.00 must be inserted in relay socket R 61 on the central electrical system.
4. On vehicles **with immobilizer**, the lead (0.5 mm² orange/black) at connector X 4/2 pin 12 (double connection), must be cut off at the contact, insulated and tied up.
5. On vehicles **without four-wheel drive**, the lead (0.5 mm² brown) from connector II (white) on the central informer (Pin 24) must be unclipped and insulated.
6. On vehicles with small fuel tanks (approx. 71 l) the lead (0.5 mm² orange/black) from connector II (white) on the central informer (pin 26) must be unclipped and insulated.
7. On vehicles without **sound package**, radio connector II (loudspeaker lines) must be disconnected from the booster adapter (8-pin connector ahead of radio) and connected to the radio.
8. Instead of the buzzer (443.951.307 B) for the light warning, the gong relay (928.618.102.03) must be installed (already installed on vehicles for USA/Canada and Saudi Arabia).

97 09 Spare part - passenger compartment wire harness for Model '95

World-wide, 8 wire harnesses are available as spare parts. When using this wire harness, the following modifications must therefore be made:

Right-hand drive vehicles, model '95

1. Insert jumper adapter 964.610.184.00 in relay socket R 34 on the central electrical system.
(not for Japan and USA/Canada vehicles).
On Japan and USA/Canada vehicles, the foglight relay remains in position.
2. On Tiptronic vehicles **without immobilizer**, the wire (0.75 mm² yellow/black) on the immobilizer relay (R 61), pin 7, must be cut off about 80 mm ahead of the relay socket.
The lead from relay pin 7 must then be crimped to the lead (4 mm², yellow) from pin 3 (double connection).
See wiring diagram - section N 49 line (0.75 mm² yellow) "M 249 not M 530"
3. On manual vehicles **without immobilizer**, jumper adapter 964.610.184.00 must be inserted in relay socket R 61 on the central electrical system.
4. On vehicles **with immobilizer**, the lead (0.5 mm² orange/black) at connector X 4/2 pin 12 (double connection), must be cut off at the contact, insulated and tied up.
5. On vehicles **without four-wheel drive**, the lead (0.5 mm² brown) from connector II (white) on the central informer (Pin 24) must be unclipped and insulated.
6. On vehicles **without sound package**, radio connector II (loudspeaker lines) must be disconnected from the booster adapter (8-pin connector ahead of radio) and connected to the radio.
7. On vehicles **with sound package**, channels VR and VL and channels HR and HL must be interchanged at radio connector II (socket contact).
1.5 mm² brown/black (Pin 6) must be interchanged with
1.5 mm² brown/white (Pin 4)

1.5 mm² black (Pin 5) must be interchanged with
1.5 mm² white (Pin 3)


1.5 mm² brown/red (Pin 2) must be interchanged with
1.5 mm² brown/yellow (Pin 8)

1.5 mm² red (Pin 1) must be interchanged with
1.5 mm² yellow (Pin 7)

97 50 41 Repairing wire harness no. 173 (DME)**Note**

As of model year 1996, knock sensors, speed senders and temperature sensors with optimized plug connections will be installed. In this case, the connector housing of older wire harnesses must be modified.

1. Cut wires right next to the old connector housing.
2. Push new sheaths onto each individual wire and insulate wires on a length of approx. 5 mm.
3. Use a crimping tool to crimp the connector contact and the sheath.



2308-97

4. As for the terminal assignment in the connector housing, the wiring diagram and the following table must be observed.

Knock sensors 1 and 2

Term. 1 - WS (white)
Term. 2 - BR (brown)
Term. 3 - Sheath

Speed sender

Term. 1 - WS (white)
Term. 2 - BR (brown)
Term. 3 - Sheath

Engine temperature sensor (NTC II)

Term. 1 - SW/RT (black/red)
Term. 2 - Dummy plug
Term. 3 - BR (brown)

5. Terminal 2 on the temperature sensor is not used and has to be fitted with a dummy plug.

Note

These optimized parts can also be installed in the 911 Carrera (964) as of model year 1989. The old connector housings of the DME wire harness must be replaced.

97 52 Engine wire harness**Note**

The injection valves for cylinders 1 to 6 are no longer marked on the wire harness. Assignment is now based on the different colors of the connector housings.

Cylinder	Color of connector housing
1 and 4	white
2 and 5	brown
3 and 6	blue

97 09 Spare part - passenger compartment wire harness for Model '96

Remark

On Cabriolet and Targa vehicles, removing or installing the cable for the interior light and the passenger compartment monitoring sensor **below the A-pillar is impossible with the windshield installed**. In this case, cut off the passenger compartment wire harness (marked with yellow adhesive tape) before the instruments and as close to the main wire harness as possible.

When installing a new passenger compartment wire harness, cut off the wires behind the yellow adhesive tape and connect them to the vehicle's wires of the same color by soldering or crimping. Then insulate the wires thoroughly. New passenger compartment wire harness delivered by After-Sales always include lines for the passenger compartment monitoring system. Insulate these wires thoroughly if they are not used.

If the windshield has been removed or if the wire harness is installed in the A-pillar on vehicles without passenger compartment monitoring, cut off the 6-pin plug connection in the cutout for the light in the windshield frame. Then fit a flat receptacle N 17 480.5 and an insulating bushing 111.971.921 B to the brown, the brown/white and the red wire and connect these wires to the interior light. Insulate the yellow/red wire and the yellow/black wire thoroughly and tie them to the wire harness using tie-wraps.

Left-hand drive vehicles, model '96

1. Insert jumper adapter 964.610.184.00 in relay socket R 34 on the central electrical system (not for Japan and USA/Canada vehicles).

On Japan and USA/Canada vehicles, the foglight relay remains in position.

2. On Tiptronic vehicles **without immobilizer**, the wire (0.75 mm² yellow/black) on the immobilizer relay (R 61), pin 7, must be cut off about 80 mm ahead of the relay socket. The lead from relay pin 7 must then be crimped to the lead (4 mm², yellow) from pin 3 (double connection).
See wiring diagram - section N 49 line (0.75 mm² yellow) "M 249 not M 530"
3. On manual vehicles **without immobilizer**, jumper adapter 964.610.184.00 must be inserted in relay socket R 61 on the central electrical system.
4. On vehicles **with immobilizer**, the lead (0.5 mm² orange/black) at connector X 4/2 pin 12 (double connection), must be cut off at the contact, insulated and tied up.
5. On vehicles **without four-wheel drive**, the lead (0.5 mm² brown) from connector II (white) on the central informer (Pin 24) must be unclipped and insulated.
6. On vehicles with small fuel tanks (approx. 71 l) the lead (0.5 mm² orange/black) from connector II (white) on the central informer (pin 26) must be unclipped and insulated.
7. On vehicles without **sound package**, radio connector II (loudspeaker lines) must be disconnected from the booster adapter (8-pin connector ahead of radio) and connected to the radio.
8. Instead of the buzzer (443.951.307 B) for the light warning, the gong relay (928.618.102.03) must be installed (already installed on vehicles for USA/Canada and Saudi Arabia).

97 09 Spare part - passenger compartment wire harness for Model '96**Right-hand drive vehicles, model '96**

1. Insert jumper adapter 964.610.184.00 in relay socket R 34 on the central electrical system.
(not for Japan and USA/Canada vehicles).
On Japan and USA/Canada vehicles, the foglight relay remains in position.
2. On Tiptronic vehicles **without immobilizer**, the wire (0.75 mm² yellow/black) on the immobilizer relay (R 61), pin 7, must be cut off about 80 mm ahead of the relay socket. The lead from relay pin 7 must then be crimped to the lead (4 mm², yellow) from pin 3 (double connection).
See wiring diagram - section N 49 line (0.75 mm² yellow) "M 249 not M 530"
3. On manual vehicles **without immobilizer**, jumper adapter 964.610.184.00 must be inserted in relay socket R 61 on the central electrical system.
4. On vehicles **with immobilizer**, the lead (0.5 mm² orange/black) at connector X 4/2 pin 12 (double connection), must be cut off at the contact, insulated and tied up.
5. On vehicles **without four-wheel drive**, the lead (0.5 mm² brown) from connector II (white) on the central informer (Pin 24) must be unclipped and insulated.
6. On vehicles without **sound package**, radio connector II (loudspeaker lines) must be disconnected from the booster adapter (8-pin connector ahead of radio) and connected to the radio.
7. On vehicles with **sound package**, channels VR and VL and channels HR and HL must be interchanged at radio connector II (socket contact).
1.5 mm² brown/black (Pin 6) must be interchanged with
1.5 mm² brown/white (Pin 4)

1.5 mm² black (Pin 5) must be interchanged with
1.5 mm² white (Pin 3)

1.5 mm² brown/red (Pin 2) must be interchanged with
1.5 mm² brown/yellow (Pin 8)

1.5 mm² red (Pin 1) must be interchanged with
1.5 mm² yellow (Pin 7)

97 09 Spare part - passenger compartment wire harness for Model '96**Note**

Supplement to Spare part-passenger compartment wire harness for Model '96, on Page 97 - 015 for left-hand drive vehicles or Page 97 - 016 for right-hand drive vehicles.

Left-hand drive vehicles, '96 model

1. In general, all unneeded tie-outs and connectors must be carefully tied in and secured against rattling when replacement harnesses are used.
2. On **Targa vehicles with telephone (M615)**, the telephone antenna must be subsequently pulled through the central electrical system flange (toward luggage compartment). Excess length is accommodated in front of right-hand A-pillar.
3. On **Coupe vehicles with naturally aspirated engine**, the tie-out for the interior light and passenger compartment monitoring (left-hand A-pillar for Targa) must be tied back or cut off and insulated.
4. On **Targa vehicles**, the sliding-roof switch plug (2.5 sq. mm wire) – or the two plugs for glass roof and roller sun blind (each 3 x 0.5 sq. mm wire) on Coupe vehicles – must be tied back and secured against rattling.
5. Tie back excess length at rear spoiler switch (required on Targa with rear window wiper) if not used.
6. On **Coupe vehicles**, the excess length must be carefully tied back at the rear-wiper motor.
7. On **UST vehicles**, the rear-spoiler tie-out must be tied back at the right in the engine compartment.
8. On **Targa vehicles with manual transmission for the USA**, the two tied-in wires 0.5 YE/BK and 0.5 YE/RD on plug II of the alarm system control module must be swapped with the two wires of the same colour in ports II 24 and II 8.
9. On **Coupe and Targa vehicles with naturally aspirated engines for the USA**, the combination wire (ABS - BVA) must be routed through the heel plate at the rear left instead of through the seat well (like Turbo). Close off seat well bore with the old wiring harness grommet and sealant.
10. On **RS vehicles (M003)** with battery disconnection switch, the tied-in red 2.0 sq. mm wire must be swapped with the wire of the same colour at terminal 30 in the plug of the hazard warning light switch. Cut off contact at former wire and carefully insulate and tie in the wire.
11. On **UST vehicles** with large tank (90 l = M 545), the wire (0.5 BN) must be disconnected from pin 26 of plug II (white) in the central information system and insulated.

Right-hand drive vehicles, '96 model

1. In general, all unneeded tie-outs and connectors must be carefully tied in and secured against rattling when replacement harnesses are used.
2. On Coupe vehicles with naturally aspirated engine, the tie-out for the interior light and passenger compartment monitoring (left-hand A-pillar for Targa) must be tied back or cut off and insulated.
3. On Targa vehicles, the sliding-roof switch plug (2.5 sq. mm wire) – or the two plugs for glass roof and roller sun blind (each 3 x 0.5 sq. mm wire) on Coupe vehicles – must be tied back and secured against rattling.
4. Tie back excess length at rear spoiler switch (required on Targa with rear-window wiper) if not used.
5. On Coupe vehicles, the excess length must be carefully tied back at the rear-wiper motor.
6. On UST vehicles, the rear-spoiler tie-out must be tied back at the right in the engine compartment.
7. On Targa vehicles with manual transmission for the USA, the two tied-in wires 0.5 YE/BK and 0.5 YE/RD on plug II of the alarm system control module must be swapped with the two wires of the same colour in ports II 24 and II 8.
8. On Coupe and Targa vehicles with naturally aspirated engine for the USA, the combination wire (ABS - BVA) must be routed through the heel plate at the rear left instead of through the seat well (like Turbo). Close off seat well bore with the old wiring harness grommet and sealant.
9. On RS vehicles (M003) with battery disconnection switch, the tied-in red 2.0 sq. mm wire must be swapped with the wire of the same colour at terminal 30 in the plug of the hazard warning light switch. Cut off contact at former wire and carefully insulate and tie in the wire.

97 09 Spare part - passenger compartment wire harness for Model '97**Note**

All conversion work described on Pages 97 - 015 to 97 - 018 for the spare part - passenger compartment wire harness for Model '96 also must be performed on the spare part - passenger compartment wire harness for Model '97. Four further conversion work steps are necessary for the model year '97.

Left-hand drive vehicles, '97 model

1. On **vehicles with DSP** (M680), the wire 0.5 WT/RD must be removed from port 1 of radio plug A (black) and insulated.
2. On **vehicles with telephone** (M615 or M618) in combination with sound package, the 2-pole connection wire BU and BU/BN in the centre console is connected to the amplifier instead of the loudspeaker.
3. On **LHD UST vehicles** (not 553), the plug interlock must be cut off and the two wires BN and BN/WT crimped or soldered together. Then insulate them carefully and tie in (starter function!!).

Right-hand drive vehicles, '97 model

1. On **vehicles with DSP** (M680), the wire 0.5 WT/RD must be removed from port 1 of radio plug A (black) and insulated.

Wiring Diagram Type 911 Carrera (993) Model 95

Coordinates		
Sheet 1	1 - 10	Lights
Sheet 2	11 - 20	Alarm System, Central Locks, Mirror, Power Window Regulator, Inside Lights
Sheet 3	21 - 30	Heater, AC, Coolant Fan, Rear Window Defogger
Sheet 4	31 - 40	ABS, ABD
Sheet 5	41 - 50	Motor, Ignition, Cruise Control
Sheet 6	51 - 60	Instruments, Sensor, Central Informer, On-board computer
Sheet 7	61 - 70	Seats
Sheet 8	71 - 80	Rear Spoiler, Two-Tone Horns, Wipe- and Wash Cleaners, Sun Roof, Convertible Top
Sheet 9	81 - 90	Radio, Telephone
Sheet 10	91 - 100	Fog Light, Rear Fog Light
Sheet 11		Central Electric
Sheet 12	111 - 120	Airbag
Sheet 13	121 - 130	Tiptronic
Sheet 14	131 - 140	Ground Points
Sheet 15		Construction Components
Sheet 16		Plug Connections, M-Numbers, Abbreviations
Sheet 17	141 - 150	Code Lock

Wiring Diagram Type 911 Carrera (993) Model 95

The wiring diagram consists of 14 *individual wiring diagrams*, 1 sheet *construction components*, 1 sheet *plug connections* and 1 sheet *ground points*. These are divided into coordinate fields.

Each individual wiring diagram contains a part of the central-electrics box in a dashdotted frame.

This part of the central-electrics box shows all the lines and relays necessary for the individual wiring diagram.

The earth/ground points are identified by "GP" and their location is shown in a vehicle diagram.

The 10-pin connectors on the central-electrics box are clipped together out of 3 parts, the 20-pin connectors are clipped together out of 5 parts.

Part 1, with the moduled-on fastening lug, is the "starting element".

Parts 2,3 and 4 are "module elements".

The 10-pin connectors only contents one "module element".

Start- and module elements are identified by the numbers 1.....5.

Part 5 ist a "coding element".

The designations of the plug connections in the wiring diagram refer to the "starting element" from, for example, A 11.....15, and to the first module element from A 21.....25.

The connectors are identified by an X and a number.

Wherever wires branch to another page, the coordinates and, in certain cases, the terminal markings are indicated.

The input and output signals of control units are indicated by arrows.

The feed wire of wire joints is indicated by an arrow.

Wiring Diagram 911 Carrera (993) Model 95/2

Coordinates

Sheet 1	1 - 10	
Sheet 2	11 - 20	Alarm System, Central Locks, Mirror, Power Window Regulator, Inside Lights
Sheet 3	21 - 30	Heater, AC, Coolant Fan, Rear Window Defogger
Sheet 4 A	31 - 40	
Sheet 4 B	31 - 40	ABS (RS)
Sheet 5 A	41 - 50	Motor, Ignition, Cruise Control
Sheet 6	51 - 60	Instruments, Sensor, Central Informer, On-board computer
Sheet 7	61 - 70	
Sheet 8	71 - 80	Rear Spoiler, Two-Tone Horns, Wipe- and Wash Cleaners, Sun Roof, Convertible Top
Sheet 9	81 - 90	Radio, Telephone
Sheet 10	91 - 100	Fog Light, Rear Fog Light
Sheet 11	101 - 110	Code Lock
Sheet 12	111 - 120	Airbag
Sheet 13	121 - 130	Tiptronic
Sheet 14	131 - 140	Ground Points
Sheet 15		Construction Components
Sheet 16		Plug Connections, M-Numbers, Abbreviations
Sheet 17		Central Electric

**For vehicles with V.I.N.s from WP0 AA2 99 1SS3 21454 and from
WP0 CA2 99 8SS3 41225**

Wiring Diagram 911 Carrera (993) Model 95/2

The wiring diagram consists of 15 *individual wiring diagrams*, 1 sheet *construction components*, 1 sheet *plug connections* and 1 sheet *ground points*. These are divided into coordinate fields.

Each individual wiring diagram contains a part of the central-electrics box in a dashdotted frame.

This part of the central-electrics box shows all the lines and relays necessary for the individual wiring diagram.

The earth/ground points are identified by "GP" and their location is shown in a vehicle diagram.

The 10-pin connectors on the central-electrics box are clipped together out of 3 parts, the 20-pin connectors are clipped together out of 5 parts.

Part 1, with the moduled-on fastening lug, is the "starting element".

Parts 2,3 and 4 are "module elements".

The 10-pin connectors only contents one "module element".

Start- and module elements are identified by the numbers 1 .5.

Part 5 ist a "coding element".

The designations of the plug connections in the wiring diagram refer to the "starting element" from, for example, A 11.....15, and to the first module element from A 21.....25.


The connectors are identified by an X and a number.

Wherever wires branch to another page, the coordinates and, in certain cases, the terminal markings are indicated.

The input and output signals of control units are indicated by arrows.

The feed wire of wire joints is indicated by an arrow.

MODEL 95/2 SHEET 1



F


G

H

J

K

L



F

G

H

J

K

L

BK = BLACK

WT = WHITE

RD = RED

GRN = GREEN


YL = YELLOW

GR = GREY

BU = BROWN

BL = BLUE

W = WIRE







L M N O P

UNIT ALARM SYSTEM/CENTRAL LOCKING SYSTEM


DOOR CONTACT SWITCH LEFT

DOOR CONTACT SWITCH RIGHT

INSIDE LIGHTS CONVERTIBLE



LAY
OVER WINDOW
SA. NORMALLY OPEN RELAY ONLY




CENTRAL ELECTRIC


SEAT
RIGHT
SHEET 7

X38

911 Carrera (1993) MODEL 95/2 SHEET 3

HEATER / AC






GR - GRAY

BR - BROWN

BL - BLUE

VI - VOLT

PK



911 Carrera 993) MODEL 95/2 SHEET 4 A

ABS

A

B

D

E

31

32

33

34

35


36

37




38

39

40




F	G	H	J	K	L
---	---	---	---	---	---





F	G	H	J	K	L
---	---	---	---	---	---


WT = WHITE RE = RED GN = GREEN YE = YELLOW GR = GREY BR = BROWN BL = BLUE V = VIOLET




MODEL 95/2 SHEET 4 B









911 Carrera (1993) MODEL 95/2 SHEET 5 A
ENGINE ELECTRICS M2.10, FUEL, IGNITION SYSTEM, CRUISE CONTROL






911 Carrera (1993) MODEL 95/2 SHEET 6


INSTRUMENTS AND SENSOR





CENTRAL INFORMER


L M N O P



BRAKE PAD
WEAR INDICATOR


911 Carrera (1993) MODEL 95/2 SHEET 7

SEATS




COMFORT SEAT LEFT AND RIGHT


496 37 MAY 2004



911 Carrera (1993) MODEL 95/2 SHEET 8


REAR SPOILER, TWO-TONE HORNS, WIPE- AND WASH CLEANERS, SUN ROOF, CONVERTIBLE TOP






911 Carrera (1993) MODEL 95/2 SHEET 9

RADIO, TELEPHONE




F G H J K L


RADIO AND AUDIO OPTION PACK



F G H J K L

WT - WHITE, RE - RED, GN - GREEN, YL - YELLOW, GR - GREY, BR - BROWN, BL - BLUE, VI - VIOLET, PK - PINK





F

G

H

J


K

L

AND REAR FOG LIGHT-WIRINGS


M487-NORWAY

FOG LIGHT + REAR FOG LIGHT
ONLY WITH S7



M553-USA

FOG LIGHT WITH S6b



F

G

H

J

K

L

L

M

N

O

P

91

92

93

94

95

96


97

98


99

100

M193 JAPAN
FOG LIGHT WITH SW - ST
RFL AS OF '98




ANTI-DRIVE-OFF DEVICE (M530)





F	G	H	J	K	
					101
					102
15.25 100 100					103
					104
					105
15.10					106
15.10					107
15.10					108
15.10					109
15.10					110


911 Carrera (1993) MODEL 95/2 SHEET 12


AIRBAG

	A	B	C	D	E
113					
114					
115					
116					
117					
118					
119					













911 Carrera (1993) MODEL 95/2 SHEET 14

GROUND POINTS






F	G	H	J	K	L
---	---	---	---	---	---

a	c	d	e	K	L	M	N	O	P	Q	R
---	---	---	---	---	---	---	---	---	---	---	---

L M N O P

CODE	NOTE	POSITION IN VEHICLE
GP 1	LUGGAGE COMPARTMENT, WHEEL HOUSING LEFT	2cP
GP 4	LUGGAGE COMPARTMENT, WHEEL HOUSING RIGHT	---
GP 5	GROUND OF POWER CONSUMERS, UNDER SEAT LEFT	---
GP 6	ENGINE ELECTRONICS/TIPTRONE	---
GP 7	CENTRAL ELECTRIC, ON SIDE MEMBER RIGHT	---
GP 8	ANTENNA AMPLIFIER ON SIDE MEMBER LEFT	---
GP VIII	INSIDE LIGHT CONVERTIBLE, ROOF CENTRE FRONT	---
GP IX	INSIDE LIGHT, ROOF RIGHT	---
GP X	INSIDE LIGHT, ROOF LEFT	11aP
GP XI	BATTERY, LUGGAGE COMPARTMENT LEFT	3aP
GP XII	GROUND STRAP (STARTER, TRANSMISSION, ENGINE, BODY)	---
GP XIII	ENGINE COMPARTMENT REAR LEFT	---
GP XIV	ENGINE COMPARTMENT REAR RIGHT	---
GP XV	INSTRUMENTS, SIDE MEMBER LEFT	---
GP XX	SEAT CROSS MEMBER UNDER SEAT RIGHT	---
GP XXI	GROUND OF POWER CONSUMERS, CAMSHAFT CASING CYL 3	15cP





GP VII



GP IX LEFT



GP IX RIGHT



A B C D E

CONSTRUCTION COMPONENTS

DESIGNATION FUNCTION	POSITION IN VEHICLE		NOTE	FIELD WORK
	LHD	RHD		
ALARM HORN	130P	130P	REAR LH CROSSMEMBER	J20
	72L	72D	IN LUGGAGE COMPARTMENT	
	30P	30P	IN LUGGAGE COMPARTMENT	
	4CL	4CL	IN LUGGAGE COMPARTMENT RIGHT	
AMPLIFIER	94M	94M	UNDER THE SEAT RIGHT	
BLOWER FINAL STAGE	60M	60M	IN LUGGAGE COMPARTMENT	
	16C0	16C0	ON ENGINE	H30
	6CM	6CM	IN LUGGAGE COMPARTMENT	S30
	6CP	6CP	IN LUGGAGE COMPARTMENT	P30
	14D	14D	IN LUGGAGE COMPARTMENT	
	14DN	14DN	BY TRANSMISSION RIGHT	
	20D	20D	IN WHEEL HOUSING FRONT LEFT	
	60P	60M	BY CLUTCH PEDAL UNDER FLOOR PANEL	
	16CP	16CP	CARRIER PLATE IN ENGINE COMPARTMENT	
	20M	20M	IN LUGGAGE COMPARTMENT	
	6C0	6C0	ON INSTRUMENT PANEL	
	94M	94M	UNDER THE SEAT RIGHT	
	10CP	10CP	UNDER THE SEAT LEFT	
	7CM	7CP	ON RH SIDE OF TRANSVERSE WALL	
	7C0	7C0	ON INSTRUMENT PANEL	
	6CM	6CM	CENTRAL ELECTRIC	
	6CM	6CM	IN LUGGAGE COMPARTMENT	
CENTRAL INFORMER	7CP	7CM	ON FIREWALL	H32
DIAGNOSIS CONNECTION	7CL	7C0	IN PASSENGER'S FOOTWELL	G50
ENGINE SPEED SENSOR				
ENGINE TEMPERATURE SENSOR				
FLASHER				
FUEL PUMP	60M	16P	BEHIND THE BASE	
FUSES ENGINE COMPARTMENT	16CP	16CP	CARRIER PLATE IN ENGINE COMPARTMENT	L28
FUSE IN LUGGAGE COMPARTMENT	4CP	4CP	BELOW HYDRAULIC UNIT COVER	Q37/1
FUEL LEVEL SENSOR	5CM	5CP	IN FUEL TANK	R51
GONG RELAY	72D		LH SIDE IN FRONT OF INSTRUMENTS	P53/1
HALL SENSOR	17C0	17C0	ON DISTRIBUTOR	
HYDRAULIC UNIT ABS	30P	30P	IN LUGGAGE COMPARTMENT	
HEADLIGHT CLEANER PUMP	3C0	3C0	BY WASHING FLUID RESERVOIR IN WHEEL HOUSING FL	A79/1
HEADLIGHT CLEANER RELAY	6CM	6CM	CENTRAL ELECTRIC	F78
IDLE SPEED POSITIONER	150M	150M	ON ENGINE	H/14
IGNITION CONTROL UNIT	11CP	11CP	UNDER THE SEAT LEFT	
IGNITION COIL 1	17CP	17CP	ON ENGINE	L61
IGNITION COIL 2	17CP	17CP	ON ENGINE	L61
KICK-DOWN SWITCH	60D	60M	BY ACCELERATOR PEDAL UNDER FLOOR PANEL	H122
KNOCK SENSOR CYL 1-3	15CP	15CP	ON ENGINE	A67
	16CM	16CM	ON ENGINE	A67
LATERAL ACCELERATION SENSOR TIPTRONIC TRANSMISSION				
LIGHTS ON BUZZER				
MFI - DI RELAY	6CM	6CM	CENTRAL ELECTRIC	J44
MFI - DI CONTROL UNIT	94P	94P	UNDER THE SEAT LEFT	B-64
	16C0	16C0	ON ENGINE	A63
MICRO SWITCH ROOF RIGHT	90M	90M	AT CONVERTIBLE TOP FRAME	H79
MICRO SWITCH ROOF LEFT	90D	90D	AT CONVERTIBLE TOP FRAME	L79
MICRO SWITCH REAR SPOILER EXTENDED	160P	160P	ON TAILGATE	Q79
MICRO SWITCH REAR SPOILER RETRACTED	160P	160P	ON TAILGATE	Q79

F

G

H

J

K

L

N
DIAGRAM

82

M85

4/30

19

2

16

19/130

14

14

4/7

4

40

7

DESIGNATION, FUNCTION	POSITION IN VEHICLE		NOTE	FIELD IN WIRING DIAGRAM
	LHD	RHD		
MICRO SWITCH TDC	12L	12L	BEHIND SIDE PANEL COVERING	Q71
	12L	12L	BEHIND SIDE PANEL COVERING	P71
	12RN	12RN	IN ROOF	G73
MOTOR TOP CONTROL RIGHT	15L	15L	BEHIND REAR SEAT	N71
MOTOR TOP CONTROL LEFT	15L	15L	BEHIND REAR SEAT	N71
MOTOR TOP LOCK RIGHT	9L	9L	AT CONVERTIBLE TOP FRAME	K/L39
	9R	9R	AT CONVERTIBLE TOP FRAME	J/K79
	16P	16P	ON ENGINE	G30
	15L	15L	ON ENGINE	AA2
OUTSIDE TEMP. SENSOR	2P	2P	FRONT LH BUMPER	A60
OXYGEN SENSORS CYL 1-3	16P	16P	ON ENGINE	F150
OXYGEN SENSORS CYL 4-6	16P	16P	ON ENGINE	D150
OL PRESSURE SENSOR/SWITCH	16L	16L	ON ENGINE	A5A
OL COOLER BLOWER	2L	2L	IN WHEEL HOUSING FRONT RIGHT	D21
OL LEVEL SENSOR	12L	12L	IN WHEEL HOUSING REAR RIGHT	E51
OL TEMPERATURE SENSOR FOR INSTRUMENT	16L	16L	ON ENGINE	A53
OL TEMPERATURE SENSOR FOR OL COOLER BLOWER	2L	2L	IN WHEEL HOUSING FRONT RIGHT	J21
PRESSURE TRANSDUCER CHARGE AIR PRESSURE	16P	16P	ON ENGINE	A5A
PRESSURE SWITCH AIR CONDITIONING SYSTEM	160	160	IN LUGGAGE COMPARTMENT	E30
PRESSURE WARNING SWITCH	100	100	IN LUGGAGE COMPARTMENT	PLN39
REAR FOG LIGHT CUTOFF RELAY	17RN	17RN	BEHIND REAR PANEL	H108
REAR WINDOW WIPER RELAY	150	150	ON REAR WINDOW WIPER MOTOR	E71
	16P	16P	IN ENGINE COMPARTMENT	J30
	200	200	IN WHEEL HOUSING FRONT LEFT	M21
RESISTOR OL COOLER BLOWER	2L	2L	IN WHEEL HOUSING FRONT RIGHT	
RELAY CONDENSER BLOWER	6CM	6CM	CENTRAL ELECTRIC	L21
RELAY AC COMPRESSOR	16P	16P	CARRIER PLATE IN ENGINE COMPARTMENT	L30
RELAY TWO-TONE HORN	6CM	6CM	CENTRAL ELECTRIC	F78
RELAY POWER WINDOW	6CM	6CM	CENTRAL ELECTRIC	K/L79
RELAY BLOWER ENGINE COMPARTMENT	16P	16P	CARRIER PLATE IN ENGINE COMPARTMENT	J/K30
RELAY STARTER TPTONIC TRANSMISSION	6CM	6CM	CENTRAL ELECTRIC	N50
RELAY BACKUP LIGHT	700	700	IN LUGGAGE COMPARTMENT LEFT	
RELAY THERMO SWITCH CATALYTIC CONVERTER	6CM	6CM	CENTRAL ELECTRIC	L/M51
RELAY TERM X	6CM	6CM	CENTRAL ELECTRIC	J/K44
RELAY TERM Y E	6CM	6CM	CENTRAL ELECTRIC	K/L44
RELAY RFL - BACKUP LIGHT	6CM	6CM	CENTRAL ELECTRIC	J/K7, A-M54
RELAY FRONT FOG LAMP	6CM	6CM	CENTRAL ELECTRIC	J, C-094
RELAY OL COOLER BLOWER	6CM	6CM	CENTRAL ELECTRIC	K21
	6L	6L	IN LUGGAGE COMPARTMENT RIGHT	H39
	6CM	6CM	CENTRAL ELECTRIC	H75
RELAY DAYTIME RUNNING LIGHT CANADA	6CM	6CM	CENTRAL ELECTRIC	D1
RELAY FOG LIGHT SWITCH OFF USA/JAPAN	6CM	6CM	CENTRAL ELECTRIC	N/P/94, F/510
SECONDARY AIR PUMP RELAY	17P	17P	ON CARRIER ON LH SIDE IN ENGINE COMPARTMENT	A50
STOP LIGHT SWITCH	6P	6P	AT THE BRAKE PEDAL BELOW THE FLOOR PANEL	N9
	1200	1200	ON GEARBOX	D-F129
SHIFT VALVE RESONANCE FLAP		150N	ON ENGINE	N61
STARTER	16N	16N	BY CLUTCH HOUSING RIGHT	PL9/50
SECONDARY AIR PUMP	16N	16N	ON ENGINE	D/150
	150N	150N	ON THROTTLE VALVE ASSEMBLY	A44
TIMING VALVE	16CM	16CM	ON ENGINE	L750
TANK VENTING VALVE	16P	16P	ON ENGINE	K41
TWO-TONE HORN I	3L	3L	IN WHEEL HOUSING FRONT RIGHT	F80
TWO-TONE HORN II	3L	3L	IN WHEEL HOUSING FRONT RIGHT	G80
V-BELT CONTROL	1700	1700	ON ENGINE REAR MIDDLE	A55
WINDSHIELD WASHING FLUID PUMP	3L	3L	BY WASHING FLUID RESERVOIR IN WHEEL HOUSING FL	A78
WIPER INTERMITTENT CONTROL RELAY	6CM	6CM	CENTRAL ELECTRIC	F/575

F

G

H

J

K

L

L

M


N

O

P

FIELD IN
WIRING DIAGRAM

301
302
303
471
472
K/379
K/379
530
A42
A40
A50
350
A54
921
L51
A47
301
A58
E30
M/329
H/08
E71
330
M21
M21
77
L30
F78
K/379
K/379
M50
772
L/351
K/344
K/344
M/379 A M54
J/379
K21
H39
H75
E1
M/379 F/379
H50
H50
L/379
F/379
F/379
A44
L50
A41
E69
A80
A55
A78
F/379



911 Carrera (1993) MODEL 95/2 SHEET 16

CONNECTORS AND ABBREVIATIONS

A B C D E

PLUG CONNECTIONS

CODE	NUMBER OF PINS	DESIGNATION, FUNCTION	POSITION IN VEHICLE		NOTE
			LHD	RHD	
X142	2	CONNECTION WL PASSENGER COMPARTMENT/ WL FRONT END	6CL	6CL	
X13	4	CONNECTION WL PASSENGER COMPARTMENT/ WL MOTOR	9AP	16CP	CARRIER PLATE
X141	2	CONNECTION WL PASSENGER COMPARTMENT/ WL HEATER	9AP	9BP	UNDER THE SEAT
X142	2	CONNECTION WL PASSENGER COMPARTMENT/ WL HEATER	9AP	9BP	UNDER THE SEAT
X143	2	CONNECTION WL PASSENGER COMPARTMENT/ WL DOOR DRIVER'S SIDE	6CL	6CL	UNDER THE INST.
X142	2	CONNECTION WL PASSENGER COMPARTMENT/ WL DOOR DRIVER'S SIDE	6CL	6CL	UNDER THE INST.
X141	2	CONNECTION WL PASSENGER COMPARTMENT/ WL DOOR PASSENGER'S SIDE	6CL	6CL	UNDER THE INST.
X142	2	CONNECTION WL PASSENGER COMPARTMENT/ WL DOOR PASSENGER'S SIDE	6CL	6CL	UNDER THE INST.
X142	2	CONNECTION WL PASSENGER COMPARTMENT/ WL HEATER, AIR CONDITIONER	6CM	6CM	UNDER INSTRUMENT
X24	10	CONNECTION WL PASSENGER COMPARTMENT/ WL TAILGATE	16CL	16CL	BOX RH SIDE OF
X25	2	CONNECTION WL PASSENGER COMPARTMENT/ WL TAIL LIGHTS	16CL	16CL	BOX RH SIDE OF
X26	2	CONNECTION WL PASSENGER COMPARTMENT/ WL CONVERTIBLE TOP	12CL	12CL	BEHIND SIDE PANEL
X28	2	CONNECTION WL PASSENGER COMPARTMENT/ WL ONTON LOCK	6CP	6CP	ON STEERING CO
X29	2	CONNECTION WL PASSENGER COMPARTMENT/ WL TAIL LIGHTS	16CL	16CL	BOX RH SIDE OF
X31	2	CONNECTION WL PASSENGER COMPARTMENT/ WL SIDE LIGHTS COUPE	75CM	75CM	BELOW THE PARKING
X32	2	CONNECTION WL PASSENGER COMPARTMENT/ WL SIDE LIGHTS CONVERTIBLE	6CL	6CL	UNDER INSTRUMENT
X33	2	CONNECTION WL PASSENGER COMPARTMENT/ WL SIDE TURN SIGNAL LEFT	70L	70L	IN LUGGAGE COMPARTMENT
X34	2	CONNECTION WL PASSENGER COMPARTMENT/ WL SIDE TURN SIGNAL RIGHT	70R	70R	IN LUGGAGE COMPARTMENT
X36	2	CONNECTION WL PASSENGER COMPARTMENT/ WL LIFTING CONVERTIBLE TOP	12CL	12CL	BEHIND SIDE PANEL
X37	2	CONNECTION WL PASSENGER COMPARTMENT/ WL SEAT LEFT	9AP	9AP	UNDER THE DRIVER'S SEAT
X38	2	CONNECTION WL PASSENGER COMPARTMENT/ WL SEAT RIGHT	9AP	9AP	UNDER THE PASSENGER'S SEAT
X39	6	CONNECTION WL PASSENGER COMPARTMENT/ WL LUGGAGE COMPARTMENT HOOD	70L	70L	ON RH SIDE OF LUGGAGE
X40	2	CONNECTION WL MOTOR/ WL MOTOR	9AP	9AP	CARRIER PLATE
X45	6	CONNECTION WL DOOR DRIVER'S SIDE/ WL OUTSIDE MIRROR LEFT	6CP	6CP	DRIVER'S DOOR
X46	6	CONNECTION WL DOOR PASSENGER'S SIDE/ WL OUTSIDE MIRROR RIGHT	6CP	6CP	PASSENGER'S DOOR
X49	2	CONNECTION WL FRONT END/ WL HEATER, AIR CONDITIONER	6CM	6CM	IN LUGGAGE COMPARTMENT

M - NUMBERS

M 113	CANADA VERSION (DAYTIME RUNNING LIGHT)	M 487	NORWAY
M 139	ADJUSTABLE SEAT HEATING, LEFT SEAT	M 490	AUDIO OPTION PACK
M 193	JAPAN VERSION	M 513	LUMBAR SUPPORT SEAT RIGHT
M 215	SAUDI-ARABIA VERSION	M 530	CODE LOCK
M 224	AUTOMATIC BRAKE DIFFERENTIAL	M 545	LARGE TANK
M 249	AUTOMATIC TRANSMISSION (TIPTRONIC)	M 553	USA / CANADA VERSION
M 339	FWD	M 562	AIRBAG
M 340	ADJUSTABLE SEAT HEATING, RIGHT SEAT	M 564	WITHOUT AIRBAG
M 383	SPORT SEAT LEFT ELECTRIC HEIGHT ADJUSTMENT	M 573	AIR CONDITIONING SYSTEM
M 387	SPORT SEAT RIGHT ELECTRIC HEIGHT ADJUSTMENT	M 576	WITHOUT REAR FOG LIGHT
M 419	REAR PACKAGE TRAY	M 586	LUMBAR SUPPORT SEAT LEFT
M 425	REAR WINDOW WIPER	M 601	LITRONIC
M 437	COMFORT SEAT LEFT	M 602	HIGH MOUNTED STOP LIGHT
M 438	COMFORT SEAT RIGHT	M 605	HEADLIGHT VERTICAL AIM CONTROL
M 439	ELECTRIC CONVERTIBLE TOP	M 614	TELEPHONE PREPARATION
M 441	RADIO PREPARATION	M 650	POWER SUNROOF
M 451	LIMITED RADIO PREPARATION	M 651	POWER WINDOWS
M 454	CRUISE CONTROL	M 659	ON-BOARD COMPUTER
M 480	TRANSMISSION	M 680	DIGITAL SOUND PACKAGE

CONNEX

F

G

H

J

K

L

FIELD


ARTMENT RIGHT	W/H94/K123
	C9E36G48B58/59
	K/L3J27/28048/49B53/54
	E/D45/46B55/L143
	F45/46B55.G/H148
	E/F16/17B87/88.F88
UMENT PANEL DRIVER'S SIDE	C16.F87/88
UMENT PANEL PASSENGER'S SIDE	E/F13/147/15.H84
UMENT PANEL PASSENGER'S SIDE	C14.H87/88
VT PANEL RIGHT	D16/17
NGINE COMPARTMENT	N10051/14.006
NGINE COMPARTMENT	N1005
	J-M76
	1162
	1000000000
VT PANEL LEFT	N1005
ARTMENT ON SIDE MEMBER LEFT	C11E9
ARTMENT ON SIDE MEMBER RIGHT	C11E9
L COVERING	N74
R SEAT	
GER SEAT	N19.A70E65/66
GGAGE COMP. LIO HINT	016.877
ENGINE COMPARTMENT	B46E48K42.B55.M142.M148
	B18/19
	B13
	G23/24

ABBREVIATIONS

CODE	MEANING	CODE	MEANING
ABC	AUTOMATIC BRAKE DIFFERENTIAL	FOG	FOG LIGHT
ABS	ANTI-LOCK BRAKING SYSTEM	GRND	GROUND
AC	AIR CONDITIONING SYSTEM	HORN	HORN
AD	ADDITIONAL DEFRIG. LIGHTS	HIGH	HIGH BEAM
APAL	AIR PUMP	HVAC	HVAC
BL	BRAKE LIGHT	INJ. VALVE	INJECTION VALVE
CL	CLOSE	INS.C	INSULATION
CLS	CENTRAL LOCKING SYSTEM	LED	LED
CU	CONTROL UNIT	LOC	LOCAL
EWL	CENTRAL WARNING LIGHT	OP	OPERATOR
FE	CENTRAL ELECTRIC	POT	POTENTIAL
CP	CONNECTING POINT	PWM	PULSE WIDTH MODULATION
CLOCK	CLOCK SIGNAL	PL	PULSE
CO	CARBU. METERING	PLS	PULSE
CATA	CATA SIGNAL	RA	REAR AXLE
DEF	DEFROST	RL	REAR LIGHT
DSP	DIGITAL SIGNAL PROCESSOR		
DP	DISCONNECTING POINT		
DI	ELECTRIC DIAPHRAGM SYSTEM WITH KNOCK CONTROL		
ESD	ENGINE SPEED SENSOR (RPM)		
ESS	ENGINE SPEED SENSOR		
ETC	ELECTRICAL TRANSMISSION CONTROL		
FA	FRONT AXLE		
FL	FRONT LEFT		
FR	FRONT RIGHT		

FIELD INDICATION
TERMINAL (1)

- P IGNITION SWITCH POSITION 0
X IGNITION SWITCH POSITION I-II
15 IGNITION SWITCH POSITION II-III
R IGNITION SWITCH POSITION I-II-III
K DIAGNOSIS K
L DIAGNOSIS L
30 PERMANENT POSITIVE
31 GROUND
54 STOP LIGHT
56 LIGHT SWITCH POSITION I
56a/56b HIGH BEAM/LOW BEAM
57 LIGHT SWITCH POSITION I
58 LIGHT SWITCH POSITION I-II
58R/58L SIDE MARKER LIGHT RIGHT/LEFT
58d INSTRUMENT LIGHTS
T1 INJECTION SIGNAL
Tn ROTATIONAL SPEED SIGNAL
61 GENERATOR D-



F

G

H

J

K

L

L


M

N

O


P


CODE	MEANING	CODE	MEANING
FOG	FOG LIGHT	ROK	TIRE PRESSURE CONTROL
GP	GROUND POINT	ROW	REST OF WORLD
HCS	HEADLIGHT CLEANING SYSTEM	RHD	RIGHT-HAND DRIVE
HF	HIGH FREQUENCY	RPL	REAR FOG LIGHT
HFM	HOT-FILM AIR MASS METER	SA	SALVO BRAKE
HVAC	HEADLIGHT VERTICAL AIM CONTROL	SAFETY LAMP	SAFETY LAMP
INJ. VALVE	FUEL INJECTOR	SERVICE	SERVICE
INS.C	INSTRUMENT CLUSTER	SSC	COMBINED STEERING COLUMN SWITCH
I.C	IGNITION CIRCUIT	SS	SPEED SENSOR
LED	LIGHT-EMITTING DIODE	THROTTLE	THROTTLE VALVE
LHD	LEFT-HAND DRIVE	TVS	THROTTLE VALVE SENSOR
LF	LOW FREQUENCY	TE	TERMINAL
MEP + DI	DIGITAL ENGINE ELECTRONICS	TEL MUTE	RADIO Muting CONTROL
MS 2	MOTRONIC 5.2	TI	INJECTION TIME
NO	NUMBER	TN	SPEED
NTC	NEGATIVE TEMPERATURE COEFFICIENT	TURBO	911 TURBO
OP	OPEN	TRP	TWIN-COL. ROTARY POSITIONER
PN	PN	USA	USA
POT	POTENTIOMETER	WL	WIRING LOOM
PSD	PORSCHE LIMITED SLIP DIFFERENTIAL	WP	WELD POINT
PWM	PULSE WIDTH MODULATION	WW	WORLDWIDE
PL	PLUG		
RA	REAR AXLE		
RL	REAR LEFT		
RR	REAR RIGHT		



911 Carrera (1993) MODEL 95/2 SHEET 17

CENTRAL ELECTRIC












L

M

N

O

P



— TERM. 31
 — TERM. 15
 — TERM. 15E
 — TERM. X
 — TERM. 30