

MAGNETOM

Troubleshooting Guide System

Host / Imager

Document Version

Siemens reserves the right to change its products and services at any time.

In addition, manuals are subject to change without notice. The hardcopy documents correspond to the version at the time of system delivery and/or printout. Versions to hardcopy documentation are not automatically distributed.

Please contact your local Siemens office to order a current version or refer to our website <http://www.healthcare.siemens.com>.

Disclaimer

Siemens provides this documentation “as is” without the assumption of any liability under any theory of law.

The content described herein shall be used by qualified personnel who are employed by Siemens or one of its affiliates or who are otherwise authorized by Siemens or its affiliates to use such documents.

Assemblers and other persons who are not employed by or otherwise directly affiliated with or authorized by Siemens or one of its affiliates are not entitled to use this documentation without prior written authority.

Copyright

“© Siemens, 2006” refers to the copyright of a Siemens entity such as:

Siemens Healthcare GmbH - Germany

Siemens Aktiengesellschaft - Germany

Siemens Shenzhen Magnetic Resonance Ltd. - China

Siemens Shanghai Medical Equipment Ltd. - China

Siemens Healthcare Private Ltd. - India

Siemens Medical Solutions USA Inc. - USA

Siemens Healthcare Diagnostics Inc. - USA and/or

Siemens Healthcare Diagnostics Products GmbH - Germany

1	Strategy	4
1.1	Host strategy	5
1.2	Imager strategy	6
1.3	MARS / Control strategy (Only valid for DOT upgrades)	7
2	Procedure	8
2.1	Host procedures	8
2.1.1	Replacing the host.	8
2.1.2	In-Room MRC.	8
2.2	Imager procedures	14
2.2.1	Imager boot environment.	14
2.2.2	Imager tests.	14
2.2.3	Accessing operating system at the Imager	14
2.3	MARS procedures	16
2.3.1	CODIAG logs from the MARS.	16
2.3.2	Install software MARS (Only valid for DOT upgrades).	16
2.3.3	Accessing operating system at the MARS	16
3	Changes to previous version	18
4	List of Hazard IDs	19

In most cases, the first question to arise is: Is the problem caused by the hardware or software?

Host

For the host, it is important to save the site specific data each time you make changes to the site specific configuration, Tune-up, or sequences and protocols. In case of a hard disk crash, you will be able to restore a valid set of site specific data.

If you suspect defects in the host hardware (except CD-RW "CD-burner"), replace the complete host.



The dongle is console-specific to protect the customer and service licenses (the dongle is not a part of the host HW.)

Imager

The Imager warrants no software troubleshooting since software is loaded into RAM via network at each boot.

The Imager software is located at the MRC.

If you suspect defects in the Imager hardware replace the complete Imager.

Tools

System software, including site specific data.

Additionally required documents

TDOC Installation Software (valid for the installed software version on your system).

1.1 Host strategy

Host strategy table:

No	Test Step	Probable Cause / Status	Service Action	Reference
1.	System boot	Boot hangs	Check that keyboard and mouse cables are properly plugged at the back of the “host”	
			Check the BIOS settings (Install BIOS settings from BIOS CD)	Refer to TDOC: “Install software” valid for the installed software version.
2.	NUMARIS start-up	NUMARIS start-up fails	Check that the licenses are valid	Refer to “ Application License ”
			Check the DONGLE	Refer to “ Defective DONGLE ”
			Check if HD’s are available	Refer to “ Check if HD’s are available ”
3.	Monitor output	No output at the TFT monitor	Connect the TFT monitor to your service laptop; if still defective, replace TFT monitor	
			Regarding low-quality TFT monitor output	Refer to TDOC Replacement of Parts “TFT Monitor”
4.	In-Room MRC	No output at the In-Room MRC TFT monitor	Connect the In-Room MRC TFT monitor to your service laptop; if still defective, replace TFT monitor	
			Remember to perform the “ protective conductor test ” at the new In-Room MRC TFT monitor before handing the system over to the customer	Refer to safety-related tests
Remarks: The CD-RW drive (CD burner) is the only FRU for the "Host".				

1.2 Imager strategy

Imager strategy table:				
No	Test Step	Probable Cause / Status	Service Action	Reference
1.	Imager boot / network connectivity	Measurement network problem, e.g. defective NIC at the Imager / "Imager not ready"	Test network connectivity from "MRC" to the "Imager"	Refer to "Connectivity MRC to MPCU/Imager"
		Boot fails "Imager not ready"	Check the Imager DHCP boot environment for the measurement network at the MRC.	Refer to (→ Imager boot environment / Page 14)
2.	Imager tests	Defective PCI receiver / image quality problems	Perform Imager tests (Service level 4 or higher, full access is needed)	Refer to (→ Imager tests / Page 14)
		Defective Imager HW / image calculation fails		
3.	Accessing the operating system of the Image	Imager HW detection	Check if correct HW is recognized by the operating system / Imager performance monitoring	Refer to (→ Accessing operating system at the Imager / Page 14)
		Imager performance		
		Rawdata RAID access error		

1.3 MARS / Control strategy (Only valid for DOT upgrades)

MARS strategy table:				
No	Test Step	Probable Cause / Status	Service Action	Reference
1.	MARS boot / network connectivity	Measurement network problem, e.g. defective NIC at the MARS / "MARS not ready"	Test network connectivity from "MRC" to the "MARS"	Refer to (→ Accessing operating system at the Imager / Page 14).
		Boot fails "MARS not ready"	Reinstall software on MARS	Refer to (→ Install software MARS / Page 16).
2.	Control PCIe tests	Defective PCIe receiver / image quality problems	Perform the following test: Test-Tools Expert > Fast select check boxes Control PCIe (Service level 4 or higher is required, full access is required for remote operation)	
		Defective MARS HW / image calculation fails		
3.	CAN24	Communication to MARS	Reload Meas & Recon	.
			Reinstall software on MARS	(→ Install software MARS / Page 16)

2.1 Host procedures

2.1.1 Replacing the host

- If the "Host" allows access to the "Service platform" (Service Software, e.g. as user administrator "**Disable Auto login for one session**", select **Backup & Restore** in the Service platform. (The Master-Backup package contains all packages except the HIPAA)
 - "Master backup"
 - **(Only valid for systems with HIPAA activated)** "Security_settings"
- Remember to move the dongle from the old "host" to the new "host"
- Install software at the new Host according to TDOC "Install Software" valid for your system.

2.1.2 In-Room MRC

The In-Room MRC is an option consisting of an additional TFT monitor, keypad (3 keys) and trackball located in the examination room.

2.1.2.1 Monitor

The video signal from the imager is split via the interconnection box to the In-Room MRC monitor and the MRC monitor. Both monitors have the same resolution and simultaneously display the same image.

2.1.2.2 Trackball

The trackball and the keypad are used to control NUMARIS from the In-Room MRC.

2.1.2.3 Protective conductor test

In case parts have been replaced for the In-Room MRC prior to switching on the system, measure the protective conductor resistance.

Use the protective conductor meter and measure the resistance between the protective conductor connection on top of the ACC and an uncoated screw at the top cover of the In-Room MRC.

NOTICE

Do not measure directly at the trackball.

- » **Since a strong current (about 10A) is used for the measurement, the small contact springs of the trackball may be damaged.**



CAUTION

Should the resistance exceed 200 mOhm, test the protective conductor in question for satisfactory electrically conductive connection.

- » In the interest of the safety of our personnel and others, the protective ground wires must be installed prior to switching on the product / system for the first time. The same applies when all work has been completed or before turning the system over to the customer. Pls. proceed according to the product documentation.

2.1.2.4 Location and assignment of LEDs and switches

Fig. 1: Interconnection box, front - indicator LEDs



- (1) LED transmission fault
- (2) LED fiber link

Power switch		Master switch for the interconnection box as well as the monitor. The monitor can be switched on/off separately using the soft switch at the monitor.
Power LED	Green	Power on
Video ok	Green	Valid signal is connected
Fiber link	Green	Fiber cable and connections are ok
	Blinking	Fiber cable or connection is faulty (at least one of two optic fibers)
Transmission fault	Off	Signal transmission ok
	Blinking red	Signal transmission fault occurred

Fig. 2: Monitor front side - indicator LED



(1) Indicator LED

Fig. 3: Monitor front side - indicator LED magnified



(1) Indicator LED

LED on front side	Green	Display shows information
	Yellow	No signal or power down of host
	Off	Monitor off or interconnection box off

Fig. 4: Right side of monitor - keypad and LEDs

- ☐ Energized
- ☐ BL max.
- ☒ MENU enter
- ☒ CONTR. right
- ☒ BRIGHT. left
- ☒ AUTO escape
- ☒ ON off

Energized	Green	Indicates power on for the interconnection box, and power supply cable from interconnection box to monitor is ok
BL max	Off	Backlight is not at maximum
	Red	The backlight is set to maximum resp. There is no more redundancy of brightness control caused at the end of the lifetime *)
MENU/enter		No function in normal operation (OSM locked)
		By pushing the MENU/enter button during power on, the OSM is unlocked
		If unlocked, the OSM can be started or inputs can be confirmed

CONTR./right		Hotkey for contrast adjustment
		Value increase in menu
BRIGHT./left		Hotkey for brightness adjustment
		Value decrease in menu
AUTO/escape		Hotkey for auto configuration of screen position
		Close the active menu
		Reset to default setting, if pressed down for 3 seconds
ON/off		Switching on/off the monitor (softswitch)
		An unlocked OSM is automatically locked after switching off/on

In back of monitor - indicator LEDs

POWER	Green
VIDEO OK	Green
Fiber link	Green
	Blinking
Transmission fault	Off
	Blinking red

2.1.2.5 Hotkeys

Auto Configuration

This function will adjust the screen position to the signal source.

Using an analog video signal, **perform this adjustment** after

- the In-Room MRC has been connected to the system
- the interconnection box has been replaced
- the host or graphic board has been replaced

Brightness and Contrast

Brightness and contrast are factory-adjusted to mid-range independent of the input signal. Nevertheless you can change the adjustments via hot key functions.

2.1.2.6 On-screen menu (OSM)

The OSM provides many adjustments that are useful for other applications. In this application, most adjustments are optimized and there is **no need to change them**.

Actually, quite the contrary is true. It is more likely to make misadjustments that could lead to very poor image quality.

2.1.2.7 Error messages

Error	Error message / additional indications	Cause	Other potential causes
In-Room MRC monitor is blank, not even the test image is (Siemens logo) displayed after turning on the MRC	Energized LED (on the side) lights up, Power LED (in back) lights up	Monitor defective	
	Power LED (in back) is off, and Power LED (interconnection box) is off	Interconnection box is off or defective	
	Power LED (in back) is off and Power LED (interconnection box) is on	Cable harness (FOC RGB) is defective or monitor (FOC receiver) is defective	
In-Room MRC monitor is blank, but the test image (Siemens logo) is displayed after switch on	Local monitor is blank as well	PC has power management enabled	Interconnection box is off or defective
		PC is turned off or defective	RGB cable from PC to interconnection box is loose or defective

2.2 Imager procedures

2.2.1 Imager boot environment

The imager boots its software at each system start-up, the boot is performed over the measurement network, the Imager sends a network broadcast to the host (MRC). The operating system including the "Imager" software is loaded from the MRC.

Some important environment conditions for the Imager:

- At the "MRC", simultaneously press **Ctrl - Esc**. Select **Start, Advanced User**; enter the advanced user password; click **OK**
- Simultaneously press **Ctrl - Esc**; select **Start, services.msc** ↵ check that "Startup Type" is set to "Manual" for the service "Siemens Med MR bootp server"
- Simultaneously press **Ctrl - Esc**; select **Start, regedit** ↵ check that registry key "HKEY_LOCAL_MACHINE\SOFTWARE\Siemens\MrBootpS\4D524952-0000-0000-0000-000000000000" has the following content: "ClientAddr"="192.168.2.3", "Hostname"="linuxclient", and "Boot-File"="pxelinux.0"
- Check with the "Windows file explorer" that the following boot loader files are available: C:\tftpboot\pxelinux.cfg\C0A80203 and C:\tftpboot\pxelinux.0
- Check with the "Windows file explorer" that the "compressed Linux kernel" and "root file system" files are available: C:\tftpboot\vmlinuz and C:\tftpboot\rootfs.ext2

2.2.2 Imager tests

Perform the "Imager" tests.

- Start the local service platform **TestTools**; select the "Imager" checkbox at the far right; click **GO**

For detailed information regarding "TestTools" and "Imager Tests", click **Help** at the top to the right in the Service platform.



After performing "Imager Tests", reboot the system

2.2.3 Accessing operating system at the Imager

To access the operating system at the Imager (Linux), use the command tool.

- At the "MRC", simultaneously press **Ctrl - Esc**. Select **Start, Advanced User**; enter the advanced user password; click **OK**
- Simultaneously press **Ctrl - Esc**; select **Start, cmd** ↵
- In the xwindow enter the command **ssh -l root mrir** ↵ (note the command contains an lower case **L**) to login at the "Imager".

2.2.3.1 Useful Imager commands

Commands	information
<code>cat /proc/cpuinfo ↵</code>	List CPU configuration.
<code>dmesg ↵</code>	Hardware detection and driver set-up messages from the last boot.
<code>mount ↵</code>	Display file system mount points.
<code>df -h ↵</code>	Display file system usage (-h human readable)
<code>raidtool -d -r /dev/sda1 ↵</code> or <code>raidtool -d -r /dev/sda2 ↵</code>	RAID information (Imager rawdata disks).
<code>more /var/log/messages ↵</code>	General system log messages for the Imager. Use e.g. the space bar to continue the scrolling. (The messages file is copied to the MRC in the folder c:\MRIR\var\log this is useful to for e.g. remote service)
<code>top ↵</code>	System performance and process information. (press Q to Quit the top monitor)
<code>ps -ax ↵</code>	Display active process information (two important "Imager" processes for the component manager communication are: "MrIrisProcessController" and "MrIrisContainer")
<code>reboot ↵</code>	Reboot the imager.
<code>shutdown -h now ↵</code>	shutdown the imager (including power off).

2.2.3.2 Imager RAID access error

To force a reinitialization of the rawdata RAID, e.g., if the RAID is not detected, the configuration file "setup.lastcall" has to be deleted.

- At the "**MRC**", simultaneously press **Ctrl - Esc**. Select **Start, Advanced User**; enter the advanced user password; click **OK**
- Simultaneously press **Ctrl - Esc**; select **Start, explorer ↵** navigate to the folder `c:\Medcom\MCIR\Med\config\scripts`
- Delete file setup.lastcall.
- Reboot the Imager.

2.3 MARS procedures

2.3.1 CODIAG logs from the MARS

If the host boots, check for detailed status messages regarding the last MARS status in the following CODIAG folder:

- Enable advanced user.
- Open a Windows Explorer file, navigate to: C : \MedCom\log\codiag
- Click on the codiag-MR2Way-DiagInv_Monitoring_XXout.html files, check for errors

2.3.2 Install software MARS (Only valid for DOT upgrades)

The MARS can be reinstalled via the network from the host via Service GUI > **TestTools** > **Trouble Reset** > **MCIR** > with the action **Install**

2.3.3 Accessing operating system at the MARS

To access the operating system at the MARS (Linux), use the command tool.

- At the "MRC", simultaneously press **Ctrl - Esc**. Select **Start, Advanced User**; enter the advanced user password; click **OK**
- Simultaneously press **Ctrl - Esc**; select **Start, cmd** ↵
- In the xwindow, enter the command **ssh -l root mrir** ↵ (note the command contains a lower case L) to login at the "MARS".

2.3.3.1 Useful MARS commands

Commands	information
cat /proc/cpuinfo ↵	List CPU configuration.
dmesg ↵	Hardware detection and driver set-up messages from the last boot.
mount ↵	Display file system mount points.
df -h ↵	Display file system usage (-h human readable)
raidtool -d -r /dev/sda1 ↵ or raidtool -d -r /dev/sda2 ↵	RAID information (MARS raw data disks).
more /var/log/messages ↵	General system log messages for the MARS. Use e.g. the space bar to continue scrolling. (The messages file is copied to the MRC in the folder c:\MRIR\var log. This is useful e.g. for remote service)
top ↵	System performance and process information. (press Q to Quit the top monitor)

Commands	information
ps -ax ↵	Display active process information (two important "MARS" processes for the component manager communication are: "MrlrisProcessController" and "MrlrisContainer")
reboot ↵	Reboot MARS.
shutdown -h now ↵	Shut down MARS (including power off).

2.3.3.2 MARS network interface

Tab. 1 MARS LAN connections

ETH 0
Host (MRAWP)

- » Adaptations for software version VB15.

Version 03:

- Minor changes to support D13.

There are no Hazard IDs in this document.

- Restricted - All documents may only be used by authorized personnel for rendering services on Siemens Healthcare Products. Any document in electronic form may be printed once. Copy and distribution of electronic documents and hardcopies is prohibited. Offenders will be liable for damages. All other rights are reserved.

healthcare.siemens.com/services

Siemens Healthineers Headquarters
Siemens Healthcare GmbH
Henkestr. 127
91052 Erlangen
Germany
Telephone: +49 9131 84-0
siemens.com/healthineers

Print No.: M6-020.840.12.03.02 | Replaces: M6-020.840.12.02.02
Doc. Gen. Date: 06.12 | Language: English
© Siemens Healthcare GmbH, 2006

siemens.com/healthineers