

Technical Publications

Direction 2213107

Revision 1

LIGHTNING PDU

Operating Documentation

TABLE OF CONTENTS

<u>SECTION</u>	<u>PAGE</u>
TABLE OF CONTENTS	i
LIST OF ILLUSTRATIONS	iv
LIST OF TABLES	v
SECTION 1 -- OPERATION	1--1
1--1 INTRODUCTION	1--1
1--2 BENEFITS	1--2
1--3 FRONT PANEL	1--3
1--3--1 Main Circuit Breaker (A1)	1--3
1--3--2 Power Off (A3)	1--4
1--3--3 Emer. Stop Reset (A5)	1--4
1--3--4 SCR Failure Light (A15)	1--4
1--3--5 Fail Reset Switch (A4)	1--4
1--3--6 Bypass Switch (A2)	1--5
1--3--7 Test Points (TP1--TP7)	1--5
1--3--8 Load Panel (A5)	1--5
1--3--9 Service Outlets (A12)	1--5
1--3--10 Output Status Lights (DS1--DS3)	1--5
1--3--11 Front Panel Fuses (F1, F8)	1--5
1--4 STARTUP	1--8
1--4--1 Tools Needed	1--8
1--4--2 Startup Procedure	1--8
1--5 OPERATION	1--10
1--5--1 Normal Condition	1--10
1--5--2 Special Condition	1--10
SECTION 2 -- PREINSTALLATION	2--1
2--1 ENVIRONMENTAL REQUIREMENTS	2--1
2--2 FLOOR LOADING	2--1
2--3 FLOOR LAYOUT AND CABLE ACCESS	2--2
2--4 SEISMIC INFORMATION	2--2
2--5 ROUTE TO INSTALLATION SITE	2--3
2--6 DELIVERY INFORMATION	2--4
SECTION 3 -- SERVICE	3--1
3--1 INSTALLATION	3--1
3--1--1 Unpacking and Positioning	3--1
3--1--2 Facility Power and Dedicated Ground Connection	3--3
3--1--3 Functional Checks	3--9
3--1--4 Calibrate Logic Board	3--12
3--2 CONFIGURATION	3--14
3--2--1 Model 46--317099P20	3--14
3--2--2 Model 46--317099P21	3--14

<u>SECTION</u>	<u>PAGE</u>
3- -3 TROUBLESHOOTING	3- -15
3- -3- -1 Prestartup	3- -15
3- -3- -2 Basic Check	3- -16
3- -3- -3 Functional Check	3- -18
3- -3- -4 SCR Troubleshooting	3- -20
3- -3- -5 Filter Troubleshooting	3- -21
3- -3- -6 Miscellaneous Problems	3- -23
3- -4 LIGHTNING PDU SERVICE	3- -27
3- -4- -1 Service a Circuit Board	3- -27
3- -4- -2 Replace an SCR	3- -28
3- -4- -3 Replace Main Circuit Breaker (A8A1)	3- -29
3- -4- -4 Replace Bypass Switch (A8A2)	3- -31
3- -4- -5 Replace Surge Suppressor (A11A1)	3- -34
3- -4- -6 Change Transformer Tap- -lead Position (A6T1)	3- -35
3- -5 RENEWAL PARTS	3- -37
3- -5- -1 Lightning PDU System	3- -37
3- -5- -2 Circuit Breaker Panel	3- -41
3- -5- -3 Filter Assembly	3- -42
3- -5- -4 Current Transformer	3- -43
3- -6 PERIODIC MAINTENANCE	3- -44
3- -6- -1 When to Perform	3- -44
3- -6- -2 How to Perform	3- -44
3- -6- -3 Tools Required	3- -44
3- -6- -4 PM Procedure	3- -44
SECTION 4 -- ADVANCED SERVICE	4- -1
4- -1 THEORY OF OPERATION	4- -1
4- -1- -1 General	4- -1
4- -1- -2 Filter Assembly (A11)	4- -3
4- -1- -3 Logic Board (A14A2- -A14A4)	4- -5
4- -1- -4 Driver Board (A9A3- -A9A5)	4- -6
4- -1- -5 PDU Control Board (A14A1)	4- -6
4- -1- -6 Snubber Board	4- -6
4- -1- -7 SCR Sense Board (A9A2)	4- -6
SECTION 5 -- SCHEMATICS	5- -1
5- -1 46- -317099P20 and P21 System Schematic Diagram	5- -1
5- -2 Output Wiring Diagram	5- -4
5- -3 Control Logic Diagram	5- -6
5- -4 SCR Driver Board	5- -8

<u>SECTION</u>	<u>PAGE</u>
SECTION 5 -- SCHEMATICS (Continued)	
5- -5 SCR Failure Sense Board	5- -10
5- -6 PDU Control Board	5- -12
5- -7 SCR Snubber Board	5- -15
5- -8 Input Filter	5- -17
APPENDIX A -- SPECIFICATIONS	A--1
APPENDIX B -- SYSTEM OPTIONS	B--1
APPENDIX C -- ADDED FEATURES	C--1
GLOSSARY	G--1

LIST OF ILLUSTRATIONS

<u>ILLUSTRATION</u>	<u>PAGE</u>
1--1 LIGHTNING PDU	1--1
1--2 REGULATED SYSTEM RESPONSE	1--2
1--3 LOCKOUT DETAIL	1--3
1--4 FRONT PANEL AND LOAD PANEL	1--7
2--1 CABLE ENTRANCE	2--2
2--2 SERVICE AND VENTILATION CLEARANCE	2--3
3--1 LOCATE FLOOR ANCHORS	3--2
3--2 OPEN LOAD PANEL DOOR	3--3
3--3 REMOVE SIDE PANEL	3--4
3--4 CABLE ACCESS	3--5
3--5 TB 10 (A2) AND BUS BARS WITH DIFFERENT CABLE CLAMP CONFIGURATIONS	3--6
3--6 LOAD CENTER SILK SCREEN	3--8
3--7 FILTER ASSEMBLY	3--10
3--8 FRONT PANEL (REAR VIEW)	3--10
3--9 LOAD CENTER BRACKET ASSEMBLY (A14)	3--11
3--10 LOGIC BOARD	3--13
3--11 TRANSFORMER POWER CONNECTIONS, MODEL 46-317099P21	3--14
3--12 SCR BANK	3--16
3--13 SCR ASSEMBLY	3--20
3--14 SCR ASSEMBLY	3--28
3--15 FRONT PANEL (REAR VIEW)	3--30
3--16 FILTER WIRING DIAGRAM	3--33
3--17 TRANSFORMER TAP CONNECTION	3--35
3--18 LIGHTNING PDU PARTS LOCATIONS	3--37
3--19 LIGHTNING PDU PARTS LOCATIONS	3--39
3--20 CIRCUIT BREAKER PANEL	3--40
3--21 FILTER ASSEMBLY	3--42
3--22 CURRENT TRANSFORMER	3--43
3--23 LOAD CENTER BRACKET ASSEMBLY	3--45
3--24 REGULATION PANEL	3--47
3--25 FRONT PANEL (REAR VIEW)	3--48
4--1 PDU BLOCK DIAGRAM	4--2
4--2 REGULATOR OUTPUT ACCURACY	4--3
4--3 FILTER ASSEMBLY BLOCK DIAGRAM	4--4
4--4 TRANSIENT RESPONSE	4--5

LIST OF TABLES

<u>TABLE</u>		<u>PAGE</u>
2--1	FLOOR LOADING	2--1
2--2	CENTER OF GRAVITY	2--3
2--3	SITE PLANNING SPECIFICATIONS	2--4
3--1	PHASE SEQUENCE	3--9
3--2	VOLTAGE INPUT BY MODEL	3--11
A--1	SPECIFICATIONS	A--1

REVISION HISTORY

REV	DATE	PRIMARY REASON FOR CHANGE
0	MARCH 20 1998	Preliminary release.
1	August 20,1998	

LIST OF EFFECTIVE PAGES

PAGE	REV	PAGE	REV	PAGE	REV	PAGE	REV	PAGE	REV
Title Page	1								
A	1								
i to v	1								
1--1 to 1--10	1								
2--1 to 2--4	1								
3--1 to 3--48	1								
4--1 to 4--8	1								
5--1 to 5--18	1								
A--1	1								
B--1	1								
C--1	1								
G--1 to G--2	1								