

TABLE OF CONTENTS

TABLE OF CONTENTS	1
DESCRIPTION	2
1- PHASE SEQUENCE CHECK	2
REVISION HISTORY	3

DESCRIPTION

The Full-Size PDU is a two-bay cabinet, and the Compact PDU is a single-bay cabinet. Procedures for the Full-Size PDU do not apply to the Compact PDU.

1- PHASE SEQUENCE CHECK



FATAL SHOCK HAZARD!! LETHAL VOLTAGES EXIST WITHIN THE PDU DURING THIS CHECK. FOLLOW THE STEPS BELOW EXACTLY. FAILURE TO DO SO COULD CAUSE SEVERE INJURY, OR DEATH.

1. Turn off all circuit breakers in PDU. Turn main disconnect off. Verify that Transient Protection Nominal indicators are off.
2. Connect a phase sequence indicator to secondary of main transformer. Phases A, B, and C correspond to lugs X1, X2, and X3, respectively.
3. Close main disconnect and verify that phase sequence is correct. If not correct, open main disconnect and rearrange primary input connections. Close main disconnect and recheck.
4. Open main disconnect and remove phase sequence indicator.
5. Close all PDU doors and panels.

REVISION HISTORY

REV	DATE	AUTHOR	PRIMARY REASONS FOR CHANGE
0	July 17, 1998	R Hawthorne	Initial conversion to MS Word