

FCT SERVICE NOTE

SN05080810b

Class A Service information enclosed.

Date: August 8, 2005

Subject: VCT AW Direct Connect Procedure

Effectivity: VCT M3a

Details: NOTE: This Service Note supplies the AW Direct Connect Procedure for VCT M3a SW. The procedure did not make into the M3a SW LFC manual in time for its release..

AW Direct Connect:

Feature Summary

AW Direct Connect is a feature available with the AW 4.3 platform software and the VCT system. Both systems are required for the feature to function. Direct Connect allows the user to utilize the AW to process images on the CT console, without actually transferring those images to the AW. Source images remain on the CT console, while new post-processed images are saved to the AW.

Hardware Connection for AW Direct Connect

- RJ 45 cables of category **CAT 5e or CAT 6** must be used for 1GBPS connection.
 - It is mandatory to use a Direct Connection from the AW to the CT console, physically separated from the hospital network.

The cable should be connected to the "AW/X" port on the back of the console. For more information, please refer to the VCT Console Schematic in the Install documentation. For more information on creating a Direct Connect network, please refer to the AW4.3 Service Manual, Chapter 1, Section 2 (Installation Guide).

Configure the console for AW Direct Connect

1. Shutdown Applications on the Service Desktop (under Utilities tab)
2. Open a Unix shell:
 - a. Login as root:
 - Type: **su - <Enter>**
 - Type: **#bigguy <Enter>**
 - b. Type: **reconfig <Enter>**
3. Select the | **Network** | tab
4. Select the following button to configure the eth4 port for Direct Connect:
 - o **"Enable AW Direct Connect"**

This permits the AW to nfs mount the console file system and activates the eth4 port. Copy down the following information, as these will be required for the configuration of the AW:

“Console IP Address”: (10.44.22.20)_____

“AW IP Address”: (10.44.22.22)_____

- Select **Accept**

Upon restart, the port will be correctly configured for AW Direct Connect.

Please note that the CT console assigns the AW a Direct Connect IP address (which you have copied down, above). This IP address must be used to configure the AW for Direct Connect. If the AW4.3 has already been configured, you will need to re-configure it with the assigned IP address. Configuration of the AW for Direct Connect can be found in the AW4.3 Service Manual, Chapter 1, Section 11 (Installation Job Cards List—Job Card IST 001).

For information on how to set-up the CT console as a Direct Connect remote host on the AW4.3, please refer to the AW4.3 Service Manual, Chapter 1, Section 11 (Installation Job Cards List—Job Card IST 002).

Resolution: N/A

James Lehouillier
Console Service Methods Design Engineer