

GE MR Host Info

System Usernames and Passwords

- Applications login (5.x) - signa – 4\$app
- Applications login (9.x) - signa - adw2.0
- Applications login (11.x and above) - sdc - adw2.0
- Applications login (Profile, Contour) - signa - gemr7
- su (superuser/admin) - root - operator
- Report Manager - mrgol
- Sun ICN web utility - root - changeme

Useful folders in the GE MR filesystem

- /usr/g/bin - most executable MR apps commands are here
- /w/config - this is where all of the system configuration files are (gradient, coil, stage, etc.)
- /usr/g/service/cclass/spt - all of the system performance test spec files are here
- /usr/g/caldir - all of the calibration files are here (shim, grafidy, group delay, back, etc.)
- /usr/g/mrraw - raw data files are here
- /usr/g/service/data - this is where all of the test files are stored (lvshim, spt, ept, etc.)
- /usr/g/service/log - this is where the error logs and “core” files are located
- /usr/g/service/protocols - this is where all of the protocols are located
- /export/home/signa/protocols/site - alternate location of site protocols
- /export/home/signa/tools - location of many calibration and test programs
- /export/home/vre/netinstall - location where VRE software is saved on host

Linked/shortcut folders in the GE MR filesystem

- /usr/g is a shortcut to /export/home/signa
- /usr/g/mrraw is a shortcut to /export/home/signa/research/mrraw
- /usr/g/service is a shortcut to /export/home/service
- /w is a shortcut to /export/home/signa/w

Useful files in the GE MR filesystem

- /crontab - list of all automated tasks that host runs at night (Profile, Contour)
- /eject - software command to eject CD tray for use if button isn't working
- /hostname - shows Linux hostname of computer
- /etc/passwd - allows you to change password of your current user state (root, sdc, etc.)
- /etc/config/static-route.options - of default and additional router/gateway addresses (LX, excite?) (syntax: *\$ROUTE \$QUIET add net default (default router address) or \$ROUTE \$QUIET add (host IP) (static router address)*)
- /etc/rc2.d/S93route - location of default and additional router/gateway addresses (Profile, Contour, 5.x) (syntax: *route add default xxx.xxx.xxx.xxx 1*)
- /etc/sysconfig/network-scripts/ifcfg-eth0 - system options are tied to MACADDR in this file (11.x and up)
- /export/home/signa/vre/install/getipandmac.pl sun - shows current IP address of ICN

GE MR Host Info

- /export/home/signa/vre/install/icnRemoteConsole.pl –bmcip=x.x.x.x - opens remote console of ICN. Replace x.x.x.x with IP address found using getipandmac.pl sun (note two dashes before bmcip).
- /usr/local/bin/install/java/**Guided_Install** - opens guided install even if apps aren't up.
- /usr/g/bin/EndExam - kills open exam. Helpful if button is greyed out
- /usr/g/bin/GetPCHart - displays PC hardware configuration
- /usr/g/bin/**installTool FE_MODE** - forces open the guided install (verified on 23.x)
- /usr/g/bin/Notepad - lets you enter a line of text in the error log
- /usr/g/bin/prod.conf - detailed list of AP board configuration (pre-excite)
- /usr/g/bin/showVREConfig - displays VRE hardware info
- /usr/g/bin/**startBoreViewer** - displays patient comfort sensor data in graphs (23.x +)
- /usr/g/bin/sw_config_status - similar to getver. Shows installed software
- /usr/g/bin/**webCfgEditor** - GE config file manager (can run without apps up)
- /usr/g/bin/webErrDecoder - may be for error decoding. Haven't seen it work yet
- /usr/g/bin/webRptMgr - opens report manager if ResSvc has ever been loaded
- /usr/g/caldir/ecccoeff.dat - Grafidy calibration data
- /usr/g/caldir/grafidyx.cal - Grafidy calibration data
- /usr/g/caldir/grafidyy.cal - Grafidy calibration data
- /usr/g/caldir/grafidyz.cal - Grafidy calibration data
- /usr/g/caldir/gram_tune.dat - Grafidy calibration data
- /usr/g/service/cclass/sys_health - Creates a detailed system health report
 - Located of file is /usr/g/service/log/system_health.log
- /usr/g/service/cclass/report/rptmgr - GE's report manager program (password is "mrgol")
- /usr/g/service/cclass/spt/cal.spt - head and body gain specs are here
- /usr/g/service/cclass/spt/snr.spt - head and body SNR, TG, Ziso and Gradcal specs are here
- /usr/g/service/cclass/spt/fsestb.spt - all FSE stability specs
- /usr/g/service/cclass/spt/grestb.spt - all GRE stability specs
- /usr/g/service/data/temperature_log.data - Log of current magnet temperature (Profile)
- /usr/g/service/license/license.db - File shows all installed options (shortened names)
- /usr/g/service/log/**pcft.log** - patient comfort temperature sensor log file
- /usr/g/service/log/**gesys_systemID.log** - extended error log, "systemID" will be replaced with unique ID of your system. Use "gedit /usr/g/service/log/gesys*" to open the log from any shell
- /usr/g/service/log/scn.out - shows details of the last two days of scans.
- /usr/g/tools/bacc/run_bat - Bandpass Asymmetry Test manual start
- /usr/g/tools/cnt/run_cnt - manufacturing coherent noise test. Requires noise source box.
- /usr/g/tools/epiwp_tool/run_epiwp - manual start of the White Pixel tool
- /usr/g/tools/epiwp_tool/epiwpProtocol/series1/LxProtocol - shows setup of epiwp protocol
- /usr/g/tools/mc_qa_tool/run_mcqa - MCQA manual start
- /usr/g/tools/lvshim/runlvshim - forces the LV shim tool open (works on 15.x up)
- /usr/local/bin/install/configure/**mgdSubnetChoices** - shows the allowable MGD subnets
 - 10.217.x
 - 10.121.x
 - 192.168.x
 - 10.47.x

GE MR Host Info

- 10.0.x
- 172.22.x
- /usr/local/bin/install/java/Guided_Install - command to start Guided Install (must be root or su)
- /usr/local/bin/install/log/install_logfile - log file in the guided install
- /w/config/CoilConfig.cfg - this is where all of the individual coil configurations are
- /w/config/DcbCalib.cfg - file containing the DD open threshold values
- /w/config/DcbConfig.cfg - file used to change the configuration of the Driver Module. (10.x and newer)
- /w/config/ipg_stage - file used to emulate individual parts of the MR system (9.1 and older)
- /w/config/mgd_stage - file used to emulate individual parts of the MR system (10.0 and newer)
- /w/config/MRconfig.cfg - main MR configuration file
- /w/config/PM.config - change all values to zero to remove “PM required” message at startup. (11.x only)
- /w/config/ShimConfig.cfg - shows the installed shim currents and gradshim values.
- /w/config/spt_nesting - remove file to have SPT ask which length loader to use again.
- /w/config/Temperature.cfg - settings for bore temp and gradient amplifier temp warnings

Useful commands in the GE MR host

- blanktime 0 - used to disable screensaver until next reboot
- cd /(foldername) - moves you to a different folder (it is cd_space_/)
- cd .. - moves you back one folder
- checkINFO -pre - checks all saveinfo data on the hard drive (must be in root)
- checkINFO -post - checks saveinfo data on MOD (must be in root)
- checkINFO - checks all saveinfo data on both MOD and hard drive (won't check MOD if HD has issue)
- cp (filename) (copyname) - copies file in current directory with desired new name (useful to backup files before changing them. Add .bak to the end of the new file name to hide the backup from the software)
- cu scp then startBoreTemp - shows real time bore temp sensor reading
- df -h - shows disk usage on host split up by individual partitions
- endsession - shuts down applications and goes to login screen (saves reboot time)
- epiwp - used to run epi white pixel test from a shell window (only works with ResSvc loaded)
- fdisk -l - shows all USB and hard drives connected to host
- find / -name “*filename*” - finds all files with filename as a part of the actual name on the host computer
- find / -size +nc - finds all files over a filesize of n on the host computer (make sure to add the c at the end)
- getver - shows current software revision and patches with revisions
- hexdump -C filename - shows contents of hex or binary code files with ASCII (normal) output.
- hinv - shows current hardware configuration of host computer
- ls - lists all files in current folder
- ls -al - lists all files in current folder with all file attributes

GE MR Host Info

- `ls p*` - lists all files in current folder that start with lower case p (can be used with any character, case sensitive)
- `md5sum filename` - shows the MD5 checksum of the file
- `mkdir (foldername)` - creates new folder in current folder
- `more (filename)` - displays contents of current file in Cshell (enter to advance a line and space for a page)
- `mount /dev/xxxx /yourfolder` - used to mount a USB drive in Linux. Replace xxxx with the device name of your USB drive (found using `fdisk -l`). Replace `/yourfolder` with the folder that you would like to mount the USB drive to. It is recommended to make a new empty folder as the mount location.
- `ps -A` - shows all active processes on the host computer
- `kill 1234` - kills any active task on the host computer (replace 1234 with the process number you want to stop)
- `prune` - brings up pop-up box to prune error log file
- `pwd` - shows current folder path
- `rlogin (hostname)` - used to log in to other hosts remotely
- `sha1sum filename` - shows the SHA-1 checksum of the file
- `sha256sum filename` - shows the SHA-256 checksum of the file
- `sok_test` - shows currently installed options
- `su` - enters root superuser mode (password is operator)
- `tail (filename)` - shows the last 10 lines of a file.
 - `-f` - modifier before file name keeps tail open to watch files live as they grow
 - `-n xx` - modifier shows last xx lines of file. (replace xx with number of lines you wish to see)
- `top` - shows all open processes and constantly refreshes to show memory and CPU usage.
- `tps_reset` - used to perform a TPS reset from a shell window
- `umount /yourfolder` - used to unmount a USB drive that is currently mounted. Replace `/yourfolder` with the folder you have the USB drive mounted to.
- `vi` - very old file editor. Refer to Google for instructions on use.
- `&` - adding an ampersand (&) at the end of a command will disconnect that command from the current shell
- `!!` - repeats last command
- `resetftg` - enables Fast TG
- `setftg` - disables Fast TG
- `ximg <exam#> <series#> <image#>` - converts MR images to format that is used in MRIMAGE program on PC (puts them in `/usr/g/insite/tmp/`)

Octane specific commands in the GE MR host

- `jot` - text editor similar to windows notepad
- `toolchest` - opens tools menu for UNIX (find files, change backgrounds, find UNIX programs, etc.)
- `confidence` - program to test functionality of keyboard, mouse, and monitor
- `top` - shows active processes similar to windows task manager
- `string filename` - displays text contents of files, useful for identifying raw image files

GE MR Host Info

- **swmgr** - software manager for installing and removing patches
- **hw_config_status** - shows configuration of boards in the TPS chassis
- **cu ipg** - brings up a communication shell with the IPG board
- **cu cerd** - brings up a communication shell with the CERD
- **cu tps** - brings up a communication window with the TPS CPU board
- **~.** - must be used to close a communication window with the IPG, CERD or TPS
- **gattention** - used to bring up a pop up message box on the screen (*gattention "TEST"*)
- **imgworks** - image editing software
- **imgview** - image viewer software (supports more formats than imgworks and can convert .rgb to .jpg)
- **scrsave (filename)** - creates a SGI .rgb image file of whatever is currently on the screen in the current folder
- **snapshot** - creates a SGI .rgb file of either the whole screen or a selected area in the current folder
- **gunzip (filename.zip)** - unpacks .zip files in current folder
- **chmod 777 (filename.zip)** - modifies permission of named file to be completely accessible
- For more Octane specific info check out SGI's support website:
- <http://techpubs.sgi.com/library/tpl/cgi-bin/init.cgi?coll=0650>

Linux specific commands in the GE MR host

- **ethtool ethx** - shows health of host ethernet port. Replace "x" with 0 or 1
- **gedit** - text editor similar to windows wordpad. Ctrl+f allows you to search file contents.
- **gimp** - image editor software. Allows you to create screenshots
- **ifconfig -a** - shows network configuration of host
- **mgd_term** - opens up 3 separate log screens to show the output of the AGP, APS and SCP boards
- **mgd_termc** - kills open mgd_term windows
- **nautilus** - opens file explorer type window
- **popupmsg** - used to bring up a pop up message box on the screen (*popupmsg "TEST"*)
- **pkgmgr -i** - installs .rpm patch files
- **system-config-mouse** - opens box to choose what type of mouse is being used (must be in root)
- **gnome-mouse-properties** - opens mouse properties interface (must be in root)
- **xbill** - opens a "whack-a-mole" type game (only works on 11.x software)

5.x specific commands in the GE MR host

- **mrload** - used to change configuration of scanner (must be done with applications down)
- **sd -i** - shuts down applications
- **mt -f /dev/nrst8 rewind** - rewinds DAT tape
- **tar -tvf /dev/nrst8** - looks at contents of DAT tape (can be done multiple times to look at all sections of tape)
- **tar -xvf /dev/nrst8 *.pat.Z MrPatProtocols.cfg** - loads protocols from DAT tape

GE MR Host Info

Ultrasparc (Profile) specific commands in the GE MR host

- `tar -tvf /dev/rsst5` - looks at contents of MOD
- `tar -xvf /dev/rsst5` - moves contents of MOD to current folder. Can be used to move specific files