

The Driver Module is currently responsible for the multicoil switching of the 8 Channel Switch, for providing the Multicoil TR bias, and for providing bias for the head and multicoil preamps located inside the Low Profile Carriage Assembly. Be aware that switches SW1, SW2, and SW3 on the front of the Driver Module will be inoperable in systems that have a System Support Module (located inside the bottom of the SRF Cabinet) since these functions are still provided by the SSM. In normal operation the CAN Core Communication HeaRTbeat LED and the Digital Control Board HeaRTbeat LED repeatedly flash one opposite of the other. The CCC STATUS LED will repeatedly flash twice in quick succession if the Driver Module is able to communicate over the CAN link. If the CCC Board inside Driver Module faults then the CCC ERROR LED will illuminate. Be aware that the Driver Module provides 24VDC for the entire CAN link. The whole link would cease to function if this supply failed. The MODULE ERROR LED will illuminate if a fault that would normally not stop scanning, such as a power supply out of limit or fan status fault, occurs. Information for each of these faults is logged to the system error log as each occurs. The DRIVER FAULT LED will illuminate when a fault that would normally interrupt scanning, such as a multicoil TR driver fault or internal hardware failure, occurs. The NarrowBand Unblank LED (flashes during normal scanning), BroadBand LED, and Continuous Wave LED all provide visual indications of the unblank signal used for each. The INHIBIT LED illuminates when the unblank signal has been inhibited due to any kind of hardware fault. Note that Test Points 1-3 and a Ground access are provided for measurement of these unblank signals. J21 CCC_DEBUG and J22 DCB_DEBUG are standard RS-232 data ports. Field access to these is normally not necessary since existing Driver Module system diagnostics provide the same information in a more easy to read output format.

Available Driver Module

Diagnostics:

- Power Supply Data
- I/O Status
- Xpt Switch Test
- MCD Volt Test
- MCD Channel Disable Test
- MCD Channel Enable Test
- Gather Load Data

