

820-0235 – Install Instructions Liquid Pressure Transducer XD CR) (P/N: 205-0121-07) GE P/N: 5237643

Tools Required:

- 7/8" Wrench or slip wrench
- Loctite[™] 565

Removal Procedure:

1. Perform shutdown of system in accordance with Lytron manual #820-0190.
2. Lockout/Tag out system in accordance with GE procedures.
3. Drain system in accordance with Lytron manual #820-0190.
4. Locate Pressure Transducer (xdcr) to remove.
5. Remove electrical connection by pressing down on xdcr retention tab and carefully extracting the connection. (Refer to Photo 1)



Photo 1

6. Using a 7/8" wrench, remove the pressure xdcr from the system. Leave the cable in place.
End of Procedure

Install Instructions for Liquid Pressure Transducer (XD CR)

1. Prepare screw end of liquid pressure transducer (xdcr) with a moderate amount of Loctite[™] 565 or equivalent.
2. Carefully screw xdcr into manifold.
3. Using a 7/8" wrench, tighten to hand tight.
4. Connect signal harness to xdcr.
5. Fill system in accordance with Lytron manual #820-0190.
6. Check for leaks around unit just installed.
7. Return machine to running condition per Lytron manual #820-0190.
8. Check pressure reading associated with pressure transducer just replaced.

End of Procedure