

APPENDIX B - INSITE INTERACTIVE COMMAND OPTIONS

setReg options:

Modem Register Access Tool for InSite Interactive Platform

Usage: setReg -p port -r "register" [-s speed] [-d seconds]
setReg -h

-d seconds delay in seconds. This is optional. Sometimes an additional delay is needed to get a response back from the modem. Default is 2 seconds.

-h this helpful output

-p port the port the modem is connected to. Example:
 /dev/cua/a or /dev/ttyf1 .

-r "register" register string to pass to the modem. MUST BE IN DOUBLE QUOTES. May take the following forms:
 -r "S0=1"
 -r "S0=1S2=2S3=4"
 -r "S0=1 S2=2 S3=4"

-s speed serial port speed. This is optional. Typical speeds are 115200, 57600, 38400, 19200, 9600. Default is 38400.

-c process_id internal use only. Used to cleanup if port hangs

ConfigLink options

usage: ConfigLink [-v] [-p] [-d] [-P]

-v - verbose

-P - append -ppp to hostname (GEMS devenv only)

-p - pre-checkout (answer incoming calls only)

-d - debug (set idle timeouts to 30 sec, log activity)

-a - force ppp to restart

-k - For Mobile Use Only - remove ppp setup, disable serial port

-m - For Mobile Use Only - enable serial port, reconfigure ppp, start ppp

installinsite options

(NOTE: "iipadmin config" should be used to configure insite parameters instead of intallinsite)

usage: installinsite [Options]

Options:

[].....InSite Interactive Installation with GUI Interface

[-autocheckout].....Perform an autocheckout with the AutoSC

[-debug].....Turn Debugging ON

[-dn].....Report Current Dialout Number

[-dp].....Report Current Dialout Prefix

[-dp DialPre].....Set Current Dialout Number

[-healthpg].....Set up Health Page only with GUI Interface

[-ip].....Report Scanner IP Address

[-ld].....List Network Devices

[-ldp].....Report Available Dial Prefixes

[-lms].....List the Modem String used to set up the modem

[-logs].....Set up Logs only with GUI interface

[-modem].....Set up modem and InSite Checkout only with GUI Interface

[-nohealthpg].....Set up using the GUI Interface without Health Page

[-nomodem].....Set up using the GUI Interface without modem and InSite Checkout

[-noprodiags].....Set up using the GUI Interface without Proactive Diags

[-p].....Report Current Phone Number Info

[-port].....List the Serial Port Name

[-prodiags].....Set up Proactive Diags only with GUI Interface

[-reload].....Used after a restore to automate configure and checkout

[-spd].....List the Serial Port Speed

[-tp].....Report Current Line Type (TONE) or (PULSE)

[-tp tlp].....Set Current Line Type (T)one or (P)ulse

[-tty].....tty InSite Interactive Installation

installmodem options

(NOTE: "iipadmin config" should be used to configure modem parameters instead of installmodem)

Usage: installmodem [Options]

Options:

[].....Modem Installation

[-cm].....Display Modem Type Currently Selected

```

[-debug].....Turn Debugging ON
[-h].....Remote Boot Modem Hangup
[-i].....Current Configuration Inquiry
[-l].....List Available Modem Types
[-ld].....List Modem Menu Descriptions
[-m ModemType].....Install Specific Modem Type
[-os on|off].....Setup OS for Modem Dial In/Out
[-p].....Program CPU Board NVRAM Only (SUN Only)
[-q].....Query Modem Registers
[-r].....Reinitialize Modem Registers
[-zsmon ].....Check <zsmon> Port Monitor (SUN Only)

```

iipadmin options

Administration tool for InSite Interactive

```

Usage: iipadmin [-r root] [-f file] [-e extdir] [-m dir] [-k] install
       iipadmin [-r root] -b file {backup, restore}
       iipadmin [-r root] command
       iipadmin [-r root] [-m dir] M-command
       iipadmin -h

```

```

-e extdir  specify an extensions directory
-b file    "IIP backup" file
-f file    install "file" as $INSITE_HOME/.insiterc.local
           this file must contain the "setenv INSITE_HOME ..." directive
-r root    use the InSite Interactive root directory
           (should end with "insite")
-k         keep (do not /bin/rm) existing $INSITE_HOME directory
           during installation
-m dir     specify the directory that contains the class-M distribution
-h         this helpful output

```

```

commands:
  backup    backup IIP files to standard out
  config    configure to set modem / PPP
  install    initial install and configure to set site parameters
             if -m given, this will also do M-install
  restore    restore previously backed-up files
  start     start all deamons
  stop      stop all deamons

```

```

M-commands:
  M-install  install class M package only
  M-uninstall uninstall class M package only

```

iipadmin-basic options

Administration tool for iip-pppd

```

Usage: iipadmin-basic {install | start | stop | uninstall}

```

```

install  initial install of iip-pppd to set site parameters
start    start the iip-pppd
stop     stop the iip-pppd
uninstall uninstall the insite directory and associated files

```

iipadmin-server options

Administration tool for iip-httpd

```

Usage: iipadmin-server [-n nice] {install | start | stop | halt | uninstall}

```

```

-n        set a nice value to lower the process priority
install   initial install of iip-httpd to set site parameters
uninstall unconfigure iip-httpd to original distributed state
start     start the iip-httpd
stop      stop the iip-httpd using SIGTERM
halt      force exit the iip-httpd using SIGKILL

```

gzip options

gzip 1.2.4 (18 Aug 93)

```

usage: gzip [-cdfhlLnNtvV19] [-S suffix] [file ...]
-c --stdout      write on standard output, keep original files unchanged
-d --decompress  decompress
-f --force       force overwrite of output file and compress links
-h --help        give this help

```

```

-l --list          list compressed file contents
-L --license       display software license
-n --no-name       do not save or restore the original name and time stamp
-N --name          save or restore the original name and time stamp
-q --quiet         suppress all warnings
-S .suf --suffix .suf use suffix .suf on compressed files
-t --test          test compressed file integrity
-v --verbose       verbose mode
-V --version       display version number
-l --fast          compress faster
-9 --best          compress better
file...           files to (de)compress. If none given, use standard input.

```

viewlog options

Usage: [-h] [filename]

```

-h                prints this help page of .

filename          name of the log file to view

allows an ascii terminal to view a log file. If no filename is
passed in, the gesyslog is viewed.

```

pppdRestart options

Usage: pppdRestart

Used to restart the ppp daemon

Options:

```

[].....Normal ppp restart
[kill].....Terminate all ppp precesses
[auto].....Restart ppp with delay before terminating the old processes

```

pd_Install options

Usage: pd_Install [Options]

Options:

```

[].....Normal ProDiags Installation
[-auto].....Auto ProDiags Install (No User Questions)
[-debug].....Turn Debugging ON

```

pd_Install: '-h' is not a valid command line option

gattention options

usage: gattention ["text message"]

This command creates a pop-up Attention! window.
Example: gattention "Test Message"

prodiags options

Usage: prodiags [Options]

The user interface to Proactive Diagnostics

Options:

```

[].....Start Normal User Interface
[-e].....Start at 'Execute a Task' Menu
[-p].....Start at 'Change Phone Number' Menu
[-page size].....Adjust Display Page to 'size' Lines
[-s].....Start at 'Scheduler' Menu
[-sm].....Start at 'Modify Task Schedule' Menu
[-u].....Start at 'Utilities' Menu
[-vl].....Start at 'View Log' Menu
[-vr].....Start at 'View Results' Menu

```

less options

SUMMARY OF COMMANDS

Commands marked with * may be preceded by a number, N.
Notes in parentheses indicate the behavior if N is given.

```

h H          Display this help.
q :q :Q ZZ   Exit.

e ^E j ^N CR * Forward one line (or N lines).
y ^Y k ^K ^P * Backward one line (or N lines).
f ^F ^V SPACE * Forward one window (or N lines).
b ^B ESC-v    * Backward one window (or N lines).
z            * Forward one window (and set window to N).
w            * Backward one window (and set window to N).
d ^D          * Forward one half-window (and set half-window to
               N).
u ^U          * Backward one half-window (and set half-window to
               N).
F            Forward forever; like "tail -f".
r ^R ^L       Repaint screen.
R            Repaint screen, discarding buffered input.

-----
Default "window" is the screen height.
Default "half-window" is half of the screen height.
-----

/pattern      * Search forward for (N-th) matching line.
?pattern      * Search backward for (N-th) matching line.
n            * Repeat previous search (for N-th occurrence).
N            * Repeat previous search in reverse direction.
ESC-n        * Repeat previous search, spanning files.
ESC-N        * Repeat previous search, reverse dir. & spanning
               files.
ESC-u        Undo (toggle) search highlighting.

-----
Search patterns may be modified by one or more of:
! search for NON-matching lines.
* search multiple files.
@ start search at first file (for /) or last file (for ?).
-----

g < ESC-<    * Go to first line in file (or line N).
G > ESC->    * Go to last line in file (or line N).
p %          * Go to beginning of file (or N percent into file).
{            * Go to the } matching the (N-th) { in the top
               line.
}            * Go to the { matching the (N-th) } in the bottom
               line.
(            * Go to the ) matching the (N-th) ( in the top
               line.
)            * Go to the ( matching the (N-th) ) in the bottom
               line.
[            * Go to the ] matching the (N-th) [ in the top
               line.
]            * Go to the [ matching the (N-th) ] in the bottom
               line.
ESC-^F <c1> <c2> * Go to the c1 matching the (N-th) c2 in the top
               line.
ESC-^B <c1> <c2> * Go to the c2 matching the (N-th) c1 in the bottom
               line.
m<letter>    Mark the current position with <letter>.
'<letter>    Go to a previously marked position.
''           Go to the previous position.
^X^X        Same as '.

:e [file]    Examine a new file.
^X^V        Same as :e.
:n          * Examine the (N-th) next file from the command line.
:p          * Examine the (N-th) previous file from the command line.
:x          * Examine the first (or N-th) file from the command line.
= ^G :f      Print current file name.
V           Print version number of "less".

- <flag>     Toggle a command line flag [see FLAGS below].
_ <flag>     Display the setting of a command line flag.
+cmd        Execute the less cmd each time a new file is
               examined.

!command     Passes the command to $SHELL to be executed.
|X_Xcommand Pipe file between current pos & mark X_X to shell
               command.
v           Edit the current file with $VISUAL or $EDITOR.

-----

```

FLAGS

Most flags may be changed either on the command line,
or from within less by using the - command.

-?	Display help (from command line).
-a	Forward search skips current screen.
-b [N]	Number of buffers.
-B	Don't automatically allocate buffers for pipes.
-c -C	Repaint by scrolling/clearing.
-d	Dumb terminal.
-e -E	Quit at end of file.
-f	Force open non-regular files.
-g	Don't highlight matches for previous search pattern.
-G	Highlight ALL matches for previous search pattern.
-h [N]	Backward scroll limit.
-i	Ignore case in searches.
-I	Ignore case in searches and in search patterns.
-j [N]	Screen position of target lines.
-k [file]	Use a lesskey file.
-m -M	Set prompt style.
-n -N	Use line numbers.
-o [file]	Log file.
-O [file]	Log file (unconditionally overwrite).
-p [pattern]	Start at pattern (from command line).
-P [prompt]	Define new prompt.
-q -Q	Quiet the terminal bell.
-r	Output "raw" control characters.
-s	Squeeze multiple blank lines.
-S	Chop long lines.
-t [tag]	Find a tag.
-T [tagsfile]	Use an alternate tags file.
-u -U	Change handling of backspaces.
-V	Display the version number of "less".
-w	Display ~ for lines after end-of-file.
-x [N]	Set tab stops.
-X	Don't use termcap init/deinit strings.
-y [N]	Forward scroll limit.
-z [N]	Set size of window.