

TABLE OF CONTENTS

TABLE OF CONTENTS 1

1- FRONT END BELL REMOVAL..... 2

2- FRONT END BELL INSTALLATION 4

REVISION HISTORY 5

Description - Procedures for removing the front end bell.

1- FRONT END BELL REMOVAL

1. Lock out and tag out circuit breaker MR1 A14 CB6 at rear of RF/Pen Cabinet (MR1) on magnet enclosure power supply (MEPS) module.

For **RF/Pen II** and **RF/PDU Cabinet**: Lock out and tag out circuit breaker MR1 A20 CB4 at rear of RF/Pen II and RF/PDU Cabinet on System Support Module (SSM).
(Refer to *Procedure For Safety: Section 6.*)

2. Verify that voltage between MR1 A14 TP4 (+) and TP13 (–) is 0 Vdc.

For **RF/Pen II** and **RF/PDU Cabinet**, verify that voltage between MR1 A20 TP4 (+) (SRI+24V) and TP13 (–) (SRI RTN) is 0 Vdc.

3. Set the SCC to “Service Mode” by flipping the toggle switch from the top position to the bottom position. This will prevent the Magnet Monitor from dialing out.
4. Power off and perform Lock-out/Tag-out to the Systems Cooling Cabinet (SCC).
5. Remove bridge. See procedure for Bridge Removal Open Enclosure For Twin (ME2REA7.DOC).
6. Remove the cosmetic ring. See Illustration 1-1.



COSMETIC RING
ILLUSTRATION 1-1

7. Remove the cosmetic cover that fits over the RF Coil/front end bell junction.

8. Remove the temperature sensor cable that is routed through the front end bell.
9. Remove water fittings for the supply and return lines. Drain excess coolant into a bucket (see Illustration 1-2).



WATER FITTINGS SUPPLY AND RETURN LINES
ILLUSTRATION 1-2

10. Remove the two plates located on top of the coolant feed throughs (see Illustration 1-2).
11. Disconnect the four coolant lines located inside of the front end bell.
12. Remove the two bias lines at the front of the magnet. Extend the RF tube feet all the way down: two in front and two in the rear.
13. Remove the eight nuts that secure the front end bell to the RF coil (see Illustration 1-3).



FRONT END BELL
ILLUSTRATION 1-3

14. Use an 8 mm wrench to remove the 24 M10 bolts that secure the front end bell to the magnet.
15. Slowly remove the front end bell.

2- FRONT END BELL INSTALLATION

1. Ensure that the RF Tube feet are extended, then slowly move the front end bell into place.
2. Use an 8 mm wrench to install the 24 M10 bolts that secure the front end bell to the magnet. Use a star pattern when tightening the bolts. The front enclosure should touch the aluminum ring when finished.
3. Install the eight nuts that secure the front end bell to the RF coil (see Illustration 1-3).
4. Install the two bias lines at the front of the magnet.
5. Connect the four coolant lines located inside of the front end bell.
6. Install the two plates located on top of the coolant feed throughs (see Illustration 1-1).
7. Install the water fittings for the supply and return lines (see Illustration 1-2).
8. Route the temperature sensor cable through the front end bell.
9. Install the cosmetic cover over the RF Coil/front end bell junction.
10. Install the cosmetic ring. See Illustration 1-1.
11. At the SCC Cabinet, refill the coolant fluid that was drained during the removal process.
12. Replace the bridge. See procedure for Bridge Removal Open Enclosure For Twin (ME2REA7.DOC).
13. Remove the lock out and tag out from the RF Cabinet and the SCC Cabinet.
14. Flip the toggle switch on the SCC cabinet back to the upper position so the Magnet Monitor will be able to dial out.

REVISION HISTORY

REV	DATE	AUTHOR	PRIMARY REASONS FOR CHANGE
0	Oct. 22, 2001	K. Schraufnagel	Preliminary Release