

TABLE OF CONTENTS

TABLE OF CONTENTS	1
1- REMOVE, INSPECT, & REPLACE AIR FILTERS.....	2
2- RF/PEN CABINET FILTER REPLACEMENT.....	2
REVISION HISTORY.....	3

Description - The RF/Pen cabinet uses forced-air cabinet cooling. The cabinet air passes through viscous impingement air filters that must be replaced as necessary to assure proper cabinet cooling. **Filters should be replaced during initial installation of the site before turning system over to customer.**

1- REMOVE, INSPECT, & REPLACE AIR FILTERS

The RF/Pen cabinet has replaceable air filters. When replacing air filters, make sure that new filters are the same as the old ones, since there are more than one size. Refer to *Renewal Parts* for correct part number.

2- RF/PEN CABINET FILTER REPLACEMENT

1. Turn recessed screw at top center of cover 1/4-turn counterclockwise to release cover latch.
2. Tilt top of cover forward and lift up and out to remove cover for access to filter(s).
3. Remove four screws and lockwashers holding both filters on inside of cover.
4. For RF amplifier filter, slide filter up and out.
5. Inspect filter for dust build-up and replace as required.
6. For RF amplifier filter, insert filter into blower frame keeping intake side (side with cleaning instructions) facing out.
7. For front panel filters, insert filter into panel frame keeping intake side (side with cleaning instructions) facing out. Install four screws. Secure filter in front cover using lockwashers and screws.
8. Replace cover on cabinet by inserting lower cover lip behind trim strip at bottom of cabinet and swinging top of cover into spring loaded "slam-latch."

REVISION HISTORY

REV	DATE	AUTHOR	PRIMARY REASONS FOR CHANGE
0	July 21, 1998	J. Saperstein	Initial conversion from Toolbook to Word.