

TABLE OF CONTENTS

TABLE OF CONTENTS	1
1- QUICK CHECK DIAGNOSTICS	2
2- STARTING QUICK CHECK.....	3
3- SYSTEM FULL CHECK.....	3
REVISION HISTORY.....	4

1- QUICK CHECK DIAGNOSTICS

The System Quick Check runs most of the board level and data path tests in about eight minutes. It is used primarily as a quick confidence test of the hardware in the system. See Table 1-1 for a list of diagnostic tests that are executed when Quick Check is run.

TABLE 1-1
QUICK CHECK DIAGNOSTIC TESTS

<u>Power Up Tests</u> (Run after TPS Reset) - TPS Power Up - IPG Power Up	<u>CERD AIME</u> AG Registers Adr/Pat Interrupts B Port Mem Pattern B Port Mem Address C Port Mem Pattern C Port Mem Address A Port Mem Pattern A Port Mem Address DZI/DZO DCI/DCO CCR/CCI CSF DSFI/DSFO BFPI/BFPO Dataflow Function Codes	<u>CERD Receiver</u> Register Address Channel Present LO Loopback Unblank Attenuation Select Two Tone Anti Alias
<u>BIT3</u> (Only for Fiber-optic Bit3 boards)		
<u>Fast Receiver</u> (If present)		
<u>MEDCAM BLD</u> CE Memory Local CE Xbar Broadcast VME Master Interlink IPC Asynchronous		<u>CERD ASC</u> C40 Internal Interrupts ASC-CAP Comm Port Sign Extension Qin Memory Pattern Qin Walking 1/0's Qout Pattern Qout Address Filter Select Register Watchdog
<u>IPG BLD</u> SRI Loopback PAC Loopback PAC Power Up LCA Fast Update LCA Hammer Gradient Link Hammer	<u>CERD Exciter</u> Registers Address DPR DDS Center Frequency DDS Slice Frequency DDS Rho Frequency Sine LUT Center/Slice Site LUT Rho Rho Multiplier #1 Rho Multiplier #2 Frequency Cancel C/S Frequency Cancel Neg Frequency Cancel Pos Local Oscillator RF Output RF Blank RF Attenuation	<u>CERD RAP</u> Registers Interrupts FIFO Data FIFO Address XD FIFO Flags Trigger Modes Receiver Modes Offset, Peak, Clip Overrange Demod
<u>DataPath</u> Host-MEDCAM CERD-MEDCAM VSB IPG-CERD SSP		
<u>IPG MDS</u> MDS Link Gradient Driver Tests Digital Tuning Board	<u>CERD CAP</u> DUART VSB DPR Qout Memory ASC to CAP Interrupt RSC	

For descriptions of Board Level and Data Path diagnostic tests, see Procedure for TPS/ISE Board Level Tests or Procedure for TPS/ISE Data Path Tests.

2- STARTING QUICK CHECK

The Quick Check tests are downloaded from the host computer to the TPS/ISE subsystem. They can be selected/run only when Signa software is running. Status/error messages are returned to the host computer for logging/display as applicable.

The Quick Check test may be initiated as described below.

1. From the Service Desktop, select **[Diagnostics]**, **[Diags Main Menu]**, and **[Start...]**. Wait for the Diagnostics Main Menu to appear. Select **[Quick]**.
2. You may change the following test criteria as needed: **[Set Iterations]** (default is **1**), **[Test Loop Count]** (default is **1**), and **[Datapath Duration]** (default is **60 seconds**).
3. Select **[Run Diags]**. The Quick Check test runs approximately eight minutes (about 12 minutes w/TPS reset) for one iteration count (loop). This allows all default tests to execute at least once.

3- SYSTEM FULL CHECK

The System Full Check is similar to System Quick Check, but enables some of the more time consuming tests that are omitted from Quick Check. It is intended for more extensive system testing and validation.

REVISION HISTORY

REV	DATE	AUTHOR	PRIMARY REASONS FOR CHANGE
0	May 29, 1998	J. Saperstein	Initial Conversion from Toolbook to Word.
1	June 19, 1998	F. Fiore	Updates to Section 2, steps 1, 2 based on Card. Bay Validation
2	June 17, 1999	G. Boerner	Updated for release 8.3. Converted Table 1 from picture format to text.
3	Oct 13, 1999	M. Keber	Added missing tests to Table 1-1 (IPG, Medcam, CERD AIME), updated test time, and added correct proprietary header.
4	Jan 7, 2000	M. Keber	Added Bit3 and Fast Receiver tests to Table 1-1; updated test time.
5	May 25, 2000	M. Jones	Added startup info to "2- STARTING QUICK CHECK."
6	Aug 16, 2000	M. Jones	Sec 2, step 2: Changed iteration default from 0 to 1.