

TABLE OF CONTENTS

TABLE OF CONTENTS	1
1- PROCEDURE.....	2
REVISION HISTORY.....	3

Description - This is a basic test to check the functionality of the Transient Noise Filter (TNF).

The TNS Module has been renamed to TNF for Transient Noise Filter. It is important to note that this module is located in the rear of the System Cabinet, and could be labeled "TNS". This procedure relates to both the TNS and the TNF since they are the same.

1- PROCEDURE



Possible equipment damage. Use care not to bend center pins of SMB connectors DATA IN WINDOW (A24 J1) when disconnecting or connecting during functional check. Check connection by running manual prescan for any protocol with no RF; there will be excessive TNF counter incrementing with each TR pulse if the Receiver SMB pins are bent. There may also be counting due to the presence of actual spikes.

1. Connect Spike Test Circuit (A24 J4, located on the bottom edge of the TNF Assembly) to head channel input (A24 A1 A2 J5 IN) of the TNF Assembly using a short BNC coax cable.
2. Set Enable/Disable switch to Enable, and reset TNF counter. Disconnect DATA IN WINDOW (A24 J1) cable at the TNF Assembly.
3. Reset TNF counter if not zero. Set Enable/Disable switch to Enable; verify that TNF counter increments.
4. Repeat steps 1 through 3 for TNF Body channel (A24 A1 A1 J2) and TNF mutlicoil channels.

REVISION HISTORY

REV	DATE	AUTHOR	PRIMARY REASONS FOR CHANGE
0	June 1, 1998	J. Saperstein	Initial Conversion from Toolbook to Word.