

- 12.3.22. Set the Current Adjust Controls on power supply to 10 amps more than the parking current retrieved earlier.
- 12.3.23. Set the Voltage Control to adjust the power supply output current to the parking current value retrieved earlier.
- 12.3.24. Set the Heater 1 Main Switch to I (On).
- 12.3.25. Allow approximately one minute for the Main Switch to go normal.
- 12.3.26. When the Main Switch is normal, slowly decrease the Voltage Control (CCW) until -0.1 V is observed on the DVM.
- 12.3.27. Continue to adjust the power supply voltage, using the Voltage Control during rampdown in conformance with the voltages read on the DVM and Main Coil current ranges in the appropriate table below.

1.5T MR450w (HM Series) Rampdown Profile

Main Coil Voltage	Main Coil Current Range
-0.10 Volts	720 to 700 Amps
-0.30 Volts	700 to 675 Amps
-0.40 Volts	675 to 650 Amps
-0.50 Volts	650 to 625 Amps
-0.80 Volts	625 to 500 Amps
Gradually turn the Voltage Control to zero (fully CCW) then turn the Current Controls to zero (fully CCW).	500 to 0 Amps

1.5T LCCw (RD Series) Rampdown Profile

Main Coil Voltage	Main Coil Current Range
-0.10 Volts	Start to 720 Amps
-0.30 Volts	720 to 700 Amps
-0.40 Volts	700 to 675 Amps
-0.50 Volts	675 to 650 Amps
-0.80 Volts	650 to 625 Amps
-1.40 Volts	625 to 500 Amps
Gradually turn the Voltage Control to zero (fully CCW) then turn the Current Controls to zero (fully CCW).	500 to 0 Amps

3.0T MR750w (UA Series) Rampdown Profile

Main Coil Voltage	Main Coil Current Range
-0.25 Volts	> 580 Amps
-1.50 Volts	580 to 555 Amps
-3.00 Volts	555 to 480 Amps
-5.00 Volts	480 to 0 Amps
Gradually turn the Voltage Control to zero (fully CCW) then turn the Current Controls to zero (fully CCW).	At 0 Amps

- 12.3.28. Observe the voltmeter reading with the power supply's Voltmeter Select Switch in the MAIN COIL position. (A zero reading on the power supply's digital Voltage and Current Meters indicates that the magnet is fully discharged.)