

GE Healthcare

LightSpeed 7.X

Illustrated Parts List



OPERATING DOCUMENTATION



5116416-100
Rev 12

IMPORTANT PRECAUTIONS

LANGUAGE

WARNING

(EN)

- This Service Manual is available in English only.
- If a customer's service provider requires a language other than English, it is the customer's responsibility to provide translation services.
- Do not attempt to service the equipment unless this service manual has been consulted and is understood.
- Failure to heed this warning may result in injury to the service provider, operator, or patient, from electric shock or from mechanical or other hazards.

Предупреждение

(BG)

- ТОВА УПЪТВАНЕ ЗА РАБОТА Е НАЛИЧНО САМО НА АНГЛИЙСКИ ЕЗИК.
- АКО ДОСТАВЧИКЪТ НА УСЛУГАТА НА КЛИЕНТА ИЗИСКА ЕЗИК, РАЗЛИЧЕН ОТ АНГЛИЙСКИ, ЗАДЪЛЖЕНИЕ НА КЛИЕНТА Е ДА ОСИГУРИ ПРЕВОД.
- НЕ ИЗПОЛЗВАЙТЕ ОБОРУДВАНЕТО ПРЕДИ ДА СТЕ СЕ КОНСУЛТИРАЛИ И РАЗБРАЛИ УПЪТВАНЕТО ЗА РАБОТА.
- НЕСПАЗВАНЕТО НА ТОВА ПРЕДУПРЕЖДЕНИЕ МОЖЕ ДА ДОВЕДЕ ДО НАРАНЯВАНЕ НА ДОСТАВЧИКА НА УСЛУГАТА, ОПЕРАТОРА ИЛИ ПАЦИЕНТ В РЕЗУЛТАТ НА ТОКОВ УДАР ИЛИ МЕХАНИЧНА ИЛИ ДРУГА ОПАСНОСТ.

警告

(ZH-CN)

- 本维修手册仅提供英文版本。
- 如果维修服务提供商需要非英文版本，客户需自行提供翻译服务。
- 未详细阅读和完全理解本维修手册之前，不得进行维修。
- 忽略本警告可能对维修人员，操作员或患者造成触电、机械伤害或其他形式的伤害。

VÝSTRAHA

(CS)

- Tento provozní návod existuje pouze v anglickém jazyce.
- V případě, že externí služba zákazníkům potřebuje návod v jiném jazyce, je zajištění překladu do odpovídajícího jazyka úkolem zákazníka.
- Nesnažte se o údržbu tohoto zařízení, aniž byste si přečetli tento provozní návod a pochopili jeho obsah.
- V případě nedodržování této výstrahy může dojít k poranění pracovníka prodejního servisu, obslužného personálu nebo pacientů vlivem elektrického proudu, respektive vlivem mechanických či jiných rizik.

ADVARSEL

(DA)

- Denne servicemanual findes kun på engelsk.
- Hvis en kundes tekniker har brug for et andet sprog end engelsk, er det kundens ansvar at sørge for oversættelse.
- Forsøg ikke at servicere udstyret medmindre denne servicemanual har været konsulteret og er forstået.
- Manglende overholdelse af denne advarsel kan medføre skade på grund af elektrisk, mekanisk eller anden fare for teknikeren, operatøren eller patienten.

WAARSCHUWING

(NL)

- Deze onderhoudshandleiding is enkel in het Engels verkrijgbaar.
- Als het onderhoudspersoneel een andere taal vereist, dan is de klant verantwoordelijk voor de vertaling ervan.
- Probeer de apparatuur niet te onderhouden voordat deze onderhoudshandleiding werd geraadpleegd en begrepen is.
- Indien deze waarschuwing niet wordt opgevolgd, zou het onderhoudspersoneel, de operator of een patiënt gewond kunnen raken als gevolg van een elektrische schok, mechanische of andere gevaren.

HOIATUS

(ET)

- Käesolev teenindusjuhend on saadaval ainult inglise keeles.
- Kui klienditeeninduse osutaja nõuab juhendit inglise keelest erinevas keeles, vastutab klient tõlketeenuse osutamise eest.
- Ärge üritage seadmeid teenindada enne eelnevalt käesoleva teenindusjuhendiga tutvumist ja sellest aru saamist.
- Käesoleva hoiatuse eiramine võib põhjustada teenuseosutaja, operaatori või patsiendi vigastamist elektrilöögi, mehaanilise või muu ohu tagajärjel.

VAROITUS

(FI)

- Tämä huolto-ohje on saatavilla vain englanniksi.
- Jos asiakkaan huoltohenkilöstö vaatii muuta kuin englanninkielistä materiaalia, tarvittavan käännöksen hankkiminen on asiakkaan vastuulla.
- Älä yritä korjata laitteistoa ennen kuin olet varmasti lukenut ja ymmärtänyt tämän huolto-ohjeen.
- Mikäli tätä varoitusta ei noudateta, seurauksena voi olla huoltohenkilöstön, laitteiston käyttäjän tai potilaan vahingoittuminen sähköiskun, mekaanisen vian tai muun vaaratilanteen vuoksi.

ATTENTION

(FR)

- Ce manuel de service n'est disponible qu'en anglais.
- Si le technicien du client a besoin de ce manuel dans une autre langue que l'anglais, c'est au client qu'il incombe de le faire traduire.
- Ne pas tenter d'intervenir sur les équipements tant que le manuel service n'a pas été consulté et compris.
- Le non-respect de cet avertissement peut entraîner chez le technicien, l'opérateur ou le patient des blessures dues à des dangers électriques, mécaniques ou autres.

WARNUNG

(DE)

- Diese Serviceanleitung existiert nur in Englischer Sprache.
- Falls ein fremder Kundendienst eine andere Sprache benötigt, ist es Aufgabe des Kunden für eine Entsprechende Übersetzung zu sorgen.
- Versuchen Sie nicht diese Anlage zu warten, ohne diese Serviceanleitung gelesen und verstanden zu haben.
- Wird diese Warnung nicht beachtet, so kann es zu Verletzungen des Kundendiensttechnikers, des Bedieners oder des Patienten durch Stromschläge, Mechanische oder Sonstige Gefahren kommen.

ΠΡΟΕΙΔΟΠΟΙΗΣΗ

(EL)

- Το παρόν εγχειρίδιο σέρβις διατίθεται στα αγγλικά μόνο.
- Εάν το άτομο παροχής σέρβις ενός πελάτη απαιτεί το παρόν εγχειρίδιο σε γλώσσα εκτός των αγγλικών, αποτελεί ευθύνη του πελάτη να παρέχει υπηρεσίες μετάφρασης.
- Μην επιχειρήσετε την εκτέλεση εργασιών σέρβις στον εξοπλισμό εκτός εάν έχετε συμβουλευτεί και έχετε κατανοήσει το παρόν εγχειρίδιο σέρβις.
- Εάν δε λάβετε υπόψη την προειδοποίηση αυτή, ενδέχεται να προκληθεί τραυματισμός στο άτομο παροχής σέρβις, στο χειριστή ή στον ασθενή από ηλεκτροπληξία, μηχανικούς ή άλλους κινδύνους.

FIGYELMEZTETÉS

(HU)

- Ezen karbantartási kézikönyv kizárólag angol nyelven érhető el.
- Ha a vevő szolgáltatója angoltól eltérő nyelvre tart igényt, akkor a vevő felelőssége a fordítás elkészítése.
- Ne próbálja elkezdni használni a berendezést, amíg a karbantartási kézikönyvben leírtakat nem értelmezték.
- Ezen figyelmeztetés figyelmen kívül hagyása a szolgáltató, működtető vagy a beteg áramütés, mechanikai vagy egyéb veszélyhelyzet miatti sérülését eredményezheti.

AÐVÖRUN

(IS)

- Þessi þjónustuhandbók er eingöngu fáanleg á ensku.
- Ef að þjónustuveitandi viðskiptamanns þarfnast annas tungumáls en ensku, er það skylda viðskiptamanns að skaffa tungumálþjónustu.
- Reynið ekki að afgreiða tækið nema að þessi þjónustuhandbók hefur verið skoðuð og skilin.
- Brot á sinna þessari aðvörun getur leitt til meiðsla á þjónustuveitanda, stjórnanda eða sjúklings frá raflosti, vélrænu eða öðrum áhættum.

AVVERTENZA

(IT)

- Il presente manuale di manutenzione è disponibile soltanto in inglese.
- Se un addetto alla manutenzione richiede il manuale in una lingua diversa, il cliente è tenuto a provvedere direttamente alla traduzione.
- Si proceda alla manutenzione dell'apparecchiatura solo dopo aver consultato il presente manuale ed averne compreso il contenuto
- Il non rispetto della presente avvertenza potrebbe far compiere operazioni da cui derivino lesioni all'addetto, alla manutenzione, all'utilizzatore ed al paziente per folgorazione elettrica, per urti meccanici od altri rischi.

警告

(JA)

- このサービスマニュアルには英語版しかありません。
- サービスを担当される業者が英語以外の言語を要求される場合、翻訳作業はその業者の責任で行うものとさせていただきます。
- このサービスマニュアルを熟読し理解せずに、装置のサービスを行わないでください。
- この警告に従わない場合、サービスを担当される方、操作員あるいは患者さんが、感電や機械的又はその他の危険により負傷する可能性があります。

경고

(KO)

- 본 서비스 지침서는 영어로만 이용하실 수 있습니다 .
- 고객의 서비스 제공자가 영어 이외의 언어를 요구할 경우, 번역 서비스를 제공하는 것은 고객의 책임입니다 .
- 본 서비스 지침서를 참고했고 이해하지 않는 한은 해당 장비를 수리하려고 시도하지 마십시오 .
- 이 경고에 유의하지 않으면 전기 쇼크, 기계상의 혹은 다른 위험으로부터 서비스 제공자, 운영자 혹은 환자에게 위해를 가할 수 있습니다 .

BRDINJUMS

(LV)

- Šī apkalpes rokasgrāmata ir pieejama tikai angļu valodā.
- Ja klienta apkalpes sniedzējam nepieciešama informācija citā valodā, nevis angļu, klienta pienākums ir nodrošināt tulkošanu.
- Neveiciet aprīkojuma apkalpi bez apkalpes rokasgrāmatas izlasīšanas un saprašanas.
- Šī brīdinājuma neievērošana var radīt elektriskās strāvas trieciena, mehānisku vai citu risku izraisītu traumu apkalpes sniedzējam, operatoram vai pacientam.

ISPĖJIMAS

(LT)

- Šis eksploatavimo vadovas yra prieinamas tik anglų kalba.
- Jei kliento paslaugų tiekėjas reikalauja vadovo kita kalba – ne anglų, numatyti vertimo paslaugas yra kliento atsakomybė.
- Nemėginkite atlikti įrangos techninės priežiūros, nebent atsižvelgėte į šį eksploatavimo vadovą ir jį supratote.
- Jei neatkreipsite dėmesio į šį perspėjimą, galimi sužalojimai dėl elektros šoko, mechaninių ar kitų pavojų paslaugų tiekėjui, operatoriui ar pacientui.

ADVARSEL

(NO)

- Denne servicehåndboken finnes bare på engelsk.
- Hvis kundens serviceleverandør trenger et annet språk, er det kundens ansvar å sørge for oversettelse.
- Ikke forsøk å reparere utstyret uten at denne servicehåndboken er lest og forstått.
- Manglende hensyn til denne advarselen kan føre til at serviceleverandøren, operatøren eller pasienten skades på grunn av elektrisk støt, mekaniske eller andre farer.

OSTRZEŻENIE

(PL)

- Niniejszy podręcznik serwisowy dostępny jest jedynie w języku angielskim.
- Jeśli dostawca usług klienta wymaga języka innego niż angielski, zapewnienie usługi tłumaczenia jest obowiązkiem klienta.
- Nie próbować serwisować wyposażenia bez zapoznania się i zrozumienia niniejszego podręcznika serwisowego.
- Niezastosowanie się do tego ostrzeżenia może spowodować urazy dostawcy usług, operatora lub pacjenta w wyniku porażenia elektrycznego, zagrożenia mechanicznego bądź innego.

ATENÇÃO

(PT)

- Este manual de assistência técnica só se encontra disponível em inglês.
- Se qualquer outro serviço de assistência técnica solicitar estes manuais noutro idioma, é da responsabilidade do cliente fornecer os serviços de tradução.
- Não tente consertar o equipamento sem ter consultado e compreendido este manual de assistência técnica.
- O não cumprimento deste aviso pode pôr em perigo a segurança do técnico, do operador ou do paciente devido a choques elétricos, mecânicos ou outros.

ATENȚIE

(RO)

- Acest manual de service este disponibil numai în limba engleză.
- Dacă un furnizor de servicii pentru clienți necesită o altă limbă decât cea engleză, este de datoria clientului să furnizeze o traducere.
- Nu încercați să reparați echipamentul decât ulterior consultării și înțelegerii acestui manual de service.
- Ignorarea acestui avertisment ar putea duce la rănirea depanatorului, operatorului sau pacientului în urma pericolelor de electrocutare, mecanice sau de altă natură.

ОСТОРОЖНО!

(RU)

- Данное руководство по обслуживанию предлагается только на английском языке.
- Если сервисному персоналу клиента необходимо руководство не на английском, а на каком-то другом языке, клиенту следует самостоятельно обеспечить перевод.
- Перед обслуживанием оборудования обязательно обратитесь к данному руководству и поймите изложенные в нем сведения.
- Несоблюдение требований данного предупреждения может привести к тому, что специалист по обслуживанию, оператор или пациент получат удар электрическим током, механическую травму или другое повреждение.

UPOZORNENIE

(SK)

- Tento návod na obsluhu je k dispozícii len v angličtine.
- Ak zákazníkovi poskytovateľ služieb vyžaduje iný jazyk ako angličtinu, poskytnutie prekladateľských služieb je zodpovednosťou zákazníka.
- Nepokúšajte sa o obsluhu zariadenia skôr, ako si neprečítate návod na obsluhu a neporozumiete mu.
- Zanedbanie tohto upozornenia môže vyústiť do zranenia poskytovateľa služieb, obsluhujúcej osoby alebo pacienta elektrickým prúdom, do mechanického alebo iného nebezpečenstva.

ATENCION

(ES)

- Este manual de servicio sólo existe en inglés.
- Si el encargado de mantenimiento de un cliente necesita un idioma que no sea el inglés, el cliente deberá encargarse de la traducción del manual.
- No se deberá dar servicio técnico al equipo, sin haber consultado y comprendido este manual de servicio.
- La no observancia del presente aviso puede dar lugar a que el proveedor de servicios, el operador o el paciente sufran lesiones provocadas por causas eléctricas, mecánicas o de otra naturaleza.

VARNING

(SV)

- Den här servicehandboken finns bara tillgänglig på engelska.
- Om en kunds servicetekniker har behov av ett annat språk än engelska ansvarar kunden för att tillhandahålla översättningstjänster.
- Försök inte utföra service på utrustningen om du inte har läst och förstår den här servicehandboken.
- Om du inte tar hänsyn till den här varningen kan det resultera i skador på serviceteknikern, operatören eller patienten till följd av elektriska stötar, mekaniska faror eller andra faror.

DIKKAT

(TR)

- Bu servis kılavuzunun sadece ingilizcesi mevcuttur.
- Eğer müşteri teknisyeri bu kılavuzu ingilizce dışında bir başka lisandan talep ederse, bunu tercüme ettirmek müşteriye düşer.
- Servis kılavuzunu okuyup anlamadan ekipmanlara müdahale etmeyiniz.
- Bu uyarıya uyulmaması, elektrik, mekanik veya diğer tehlikelerden dolayı teknisyen, operatör veya hastanın yaralanmasına yol açabilir.

DAMAGE IN TRANSPORTATION

All packages should be closely examined at time of delivery. If damage is apparent, have notation "damage in shipment" written on all copies of the freight or express bill before delivery is accepted or "signed for" by a General Electric representative or a hospital receiving agent. Whether noted or concealed, damage MUST be reported to the carrier immediately upon discovery, or in any event, within 14 days after receipt, and the contents and containers held for inspection by the carrier. A transportation company will not pay a claim for damage if an inspection is not requested within this 14 day period.

To file a report:

- Call 1-800-548-3366 and use option 8.
- Contact your local service coordinator for more information on this process.
- GE Employees can fill out a report online at: <http://egems.med.ge.com/edq/home.jsp>

Rev. July 5, 2006

CERTIFIED ELECTRICAL CONTRACTOR STATEMENT

All electrical Installations that are preliminary to positioning of the equipment at the site prepared for the equipment shall be performed by licensed electrical contractors. In addition, electrical feeds into the Power Distribution Unit shall be performed by licensed electrical contractors. Other connections between pieces of electrical equipment, calibrations and testing shall be performed by qualified GE Healthcare personnel. The products involved (and the accompanying electrical installations) are highly sophisticated, and special engineering competence is required. In performing all electrical work on these products, GE will use its own specially trained field engineers. All of GE's electrical work on these products will comply with the requirements of the applicable electrical codes.

The purchaser of GE equipment shall only utilize qualified personnel (i.e., GE's field engineers, personnel of third-party service companies with equivalent training, or licensed electricians) to perform electrical servicing on the equipment.

IMPORTANT...X-RAY PROTECTION

X-ray equipment if not properly used may cause injury. Accordingly, the instructions herein contained should be thoroughly read and understood by everyone who will use the equipment before you attempt to place this equipment in operation. The General Electric Company, Medical Systems Group, will be glad to assist and cooperate in placing this equipment in use.

Although this apparatus incorporates a high degree of protection against x-radiation other than the useful beam, no practical design of equipment can provide complete protection. Nor can any practical design compel the operator to take adequate precautions to prevent the possibility of any persons carelessly exposing themselves or others to radiation.

It is important that anyone having anything to do with x-radiation be properly trained and fully acquainted with the recommendations of the National Council on Radiation Protection and Measurements as published in NCRP Reports available from NCRP Publications, 7910 Woodmont Avenue, Room 1016, Bethesda, Maryland 20814, and of the International Commission on Radiation Protection, and take adequate steps to protect against injury.

The equipment is sold with the understanding that the General Electric Company, Medical Systems Group, its agents, and representatives have no responsibility for injury or damage which may result from improper use of the equipment.

Various protective materials and devices are available. It is urged that such materials or devices be used.

LITHIUM BATTERY CAUTIONARY STATEMENT

CAUTION



Risk of Explosion.

Danger of explosion if battery is incorrectly replaced.

Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

ATTENTION



Danger d'Explosion

Il y a danger d'explosion s'il y a remplacement incorrect de la batterie.

Remplacer uniquement avec une batterie du même type ou d'un type recommandé par le constructeur. Mettre au rebut les batteries usagées conformément aux instructions du fabricant.

OMISSIONS & ERRORS

Customers, please contact your GE Sales or Service representatives.

GE personnel, please use the GE Healthcare PQR Process to report all omissions, errors, and defects in this publication.

Revision History

Rev	Date	Reason for change
12	3/28/08	Chapter 2: GT Table updated Table Assembly : 5127787 BOM Rev. 35 and ADW, Sheets 2 - 11, Rev. 10 Elevation Assembly: 5127773 BOM Rev. 25 and ADW, Sheets 2-6 , Rev. 8 Table Assembly MID positioning GT: 5134845 Rev. 31 and ADW, Sheet 2 -10, 12 , Rev. 10 Chapter 4: Gantry BOM 5123200, Rev. 18 and ADW, Sheet Rev. 9 BOM 5169298, Rev. and ADW, Sheet Rev.

Rev	Date	Reason for change
11	11/26/07	Chapter 2: Added or updated the following: • Table Assembly (5127787ADW, Sheet 1, Rev 5) • Table Assembly (5127787ADW, Sheet 10, Rev 6) • Table Assembly (5127787 BOM, Rev 28) • Elevation Assembly (5127773ADW, all sheets, Rev 6) • Elevation Assembly (5127773 BOM, Rev 21) • Top Frame Assembly (5127782ADW, Sheet 8, Rev 4) • Top Frame Assembly (5127782ADW, Sheet 9, Rev 6) • Top Frame Assembly (5127782ADW, Sheet 16, Rev 4) • Top Frame Assembly (5127782ADW, Sheet 19, Rev 4) • Top Frame Assembly (5127782 BOM, Rev 21) • Foot Switch Assy (5126796-2 BOM, Rev 4) • Rim Top Cover Front Assy Positioning GT (5127465-2ADW, Sheet 1, Rev 3) • Rim Top Cover Front Assy Positioning GT (5127465-3 BOM, Rev 3) • Rim IMS Cover Side LH Assy, Positioning GT (5191722ADW, Sheet 1, Rev 1) • Rim IMS Cover Side LH Assy, Positioning GT (5191722 BOM, Rev 1) • Rim IMS Cover Side RH Assy, Positioning GT (5191736ADW, Sheet 1, Rev 1) • Rim IMS Cover Side RH Assy, Positioning GT (5191736 BOM, Rev 1) • Table Assy Mid Positioning GT (5134845ADW, Sheet 1, Rev 4) • Table Assy Mid Positioning GT (5134845ADW, Sheet 10, Rev 5) • Table Assy Mid Positioning GT (5134845ADW, Sheet 11, Rev 5) • Table Assy Mid Positioning GT (5134845 BOM, Rev 24) • Top Frame 1700 Assembly (5133502ADW, Sheet 8, Rev 2) • Top Frame 1700 Assembly (5133502ADW, Sheet 9, Rev 5) • Top Frame 1700 Assembly (5133502ADW, Sheet 16, Rev 2) • Top Frame 1700 Assembly (5133502ADW, Sheet 19, Rev 2) • Top Frame-1700 Assy Positioning GT (5133502 BOM, Rev 13) • Ship Collector GT Table 1700 (5138509 BOM, Rev 5)

Rev	Date	Reason for change
10	5/07/07	Important Precautions: Updated the Language section. PQR13080416: Chapter 4, Table 4-8: Moved Mark 65, P/N 2269320-6 (SUPPORT BASE FOR PLATTER SR BRUSHBLK) after Mark 58, and added "Yes" to the FRU column. PQR13097416 (SPR FCTge28174): Chapter 4, Table 4-22: Moved Mark 44, P/N 2368331-3 (INVERTER-AUXILIARY PARTS FOR CT) after Mark 42, and added "Yes" to FRU column. Changed FRU = NO to FRU = "YES" and Rev no. to "2" for the BOM in the title for the Table 4-32. PQR13075893 (SPR FCTge28763) and PQR13096868: Chapter 4, Table 4-27: Moved Mark 2, P/N 5142145 (Cover, CCB Chassis) before Mark 6, and added "Yes" to the FRU column.
9	9/25/06	Chapter 2: General Updates. Chapter 4: Updated for Limited Access Room. Chapter 5: Added "Section 4.0 — Small Room Catalog (5191743)"
8	8/28/06	Chapter 4: Added new section "2.4 Subsystem Assembly, HDAS-Detector, VCT LS64 (5196400)"
7	7/19/06	PQRs 13067013, 13067865, 13071242, 13073680, 13079430: Updated entire manual.
6	1/28/06	PQR 13047843: Added P/N for ccb chassis assembly to Table 4-23, VCT Failsafe Collimator Assy (5130000, BOM Rev 6), in Chapter 4. PQR 13051598: Added P/N for Programmed kV Control Bd to Table 4-28, JH4 Inverter with Shield (2281950-3 BOM, Rev 3) in Chapter 4. M4 Release.
5	8/19/05	Chapter 2: General Updates. FCTge10633: Corrected part description (2361774, +24V PS) in Chapter 3. Chapter 4: - Updated for Pro32 Gantry - Added missing section: "2.6.1.1 Slip Ring Platter - VCT (2403229)" Chapter 5: Added "Section 2.0 — VCT Pro 32 Install Support Kit (5133492)"
4	6/24/05	Added drawings for VCT Collimator 5130001 and 5130000
3	4/28/05	Updated for GT1700 Table. Removed non-applicable HP Table chapter.
2	3/24/05	Added drawings for Gantry Assemblies: 5124068, 5124067, 5124066. Added P/Ns for "Routing Board Service Kits" to DAS/Detector Assembly BOM. FRU Corrections for M3.
1	3/05/05	Initial Release to support LightSpeed 7.X VCT M3 milestone.

End of Revision History.

Table of Contents

Chapter 1

Introduction	27
Section 1.0 — Page Layout, Including Finger Tabs	27
Section 2.0 — Manual Organization.....	27
Section 3.0 — Operator Console Parts Information	27

Chapter 2

GT Table	29
Section 1.0 — GT 2000 Table (5121647)	30
Positioning GT LONG TABLE ASSY (5121647ADW, sheet 1, rev 4)	30
Positioning GT LONG TABLE ASSY (5121647 BOM, Rev 18).....	31
1.1 Table Assembly (5127787).....	32
Table Assembly (5127787ADW, sheet 2, rev 10)	32
Table Assembly (5127787ADW, sheet 3, rev 10)	33
Table Assembly (5127787ADW, sheet 4, rev 10)	34
Table Assembly (5127787ADW, sheet 5, rev 10)	35
Table Assembly (5127787ADW, sheet 6, rev 10)	36
Table Assembly (5127787ADW, sheet 7, rev 10)	37
Table Assembly (5127787ADW, sheet 8, rev 10)	38
Table Assembly (5127787ADW, sheet 9, rev 10)	39
Table Assembly (5127787ADW, sheet 10, rev 10)	40
Table Assembly (5127787ADW, sheet 11, rev 10)	41
Table Assembly (5127787 BOM, Rev 35).....	42
1.1.1 – Elevation Assembly (5127773)	50
Elevation Assembly (5127773ADW, sheet 2, rev 8)	50
Elevation Assembly (5127773ADW, sheet 3, rev 8)	51
Elevation Assembly (5127773ADW, sheet 4, rev 8)	52
Elevation Assembly (5127773ADW, sheet 5, rev 8)	53
Elevation Assembly (5127773ADW, sheet 6, rev 8)	54
ELAVATION ASSY (5127773 BOM, Rev 25).....	55

1.1.2 – TOP FRAME ASSY (5127782)	60
Top Frame Assembly (5127782ADW, sheet 1, rev 7)	60
Top Frame Assembly (512778ADW2, sheet 2, rev 7)	61
Top Frame Assembly (5127782ADW, sheet 3, rev 7)	62
Top Frame Assembly (5127782ADW, sheet 4, rev 7)	63
Top Frame Assembly (5127782ADW, sheet 5, rev 7)	64
Top Frame Assembly (5127782ADW, sheet 6, rev 7)	65
Top Frame Assembly (5127782ADW, sheet 7, rev 7)	66
Top Frame Assembly (5127782ADW, sheet 8, rev 7)	67
Top Frame Assembly (5127782ADW, sheet 9, rev 7)	68
Top Frame Assembly (5127782ADW, sheet 10, rev 7)	69
Top Frame Assembly (5127782ADW, sheet 11, rev 7)	70
Top Frame Assembly (5127782ADW, sheet 12, rev 7)	71
Top Frame Assembly (5127782ADW, sheet 13, rev 7)	72
Top Frame Assembly (5127782ADW, sheet 14, rev 7)	73
Top Frame Assembly (5127782ADW, sheet 15, rev 7)	74
Top Frame Assembly (5127782ADW, sheet 16, rev 7)	75
Top Frame Assembly (5127782ADW, sheet 17, rev 7)	76
Top Frame Assembly (5127782ADW, sheet 18, rev 7)	77
Top Frame Assembly (5127782ADW, sheet 19, rev 7)	78
TOP FRAME ASSY (5127782 BOM, Rev 24)	79
1.1.2.1 – CRADLE STEEPING MOTAR CLUTCH ASSY Positioning GT (5127493)	84
CRADLE STEEPING MOTAR CLUTCH ASSY Positioning GT (5127493ADW, sheet 1, rev 3)	84
CRADLE STEEPING MOTOR CLUTCH 2000 ASSY Positioning GT (5127493 BOM, Rev 3)	85
1.1.3 – FOOT SW ASSY (5126796, 5126796-2)	86
Foot Switch Assembly (5126796ADW, sheet 1, rev 2)	86
Foot Switch Assembly (5126796ADW, sheet 2, rev 2)	87
FOOT SW ASSY (5126796-2 BOM, Rev 4)	88
1.1.4 – RIM TOP COVER FRONT ASSY positioning GT (5127465-3)	90
RIM TOP COVER FRONT ASSY positioning GT (5127465-2ADW, sheet 1, rev 3)	90
RIM TOP COVER FRONT ASSY positioning GT (5127465-3 BOM, Rev 3)	91
1.1.5 – TOP COVER REAR ASSY (5154872)	92
TOP COVER REAR ASSY (5127466ADW, sheet 1, rev 4)	92
TOP COVER REAR ASSY (5154872 BOM, Rev 2)	93
1.1.6 – TOP COVER SIDE L ASSY (5127467)	94
TOP COVER SIDE L ASSY (5127467ADW, sheet 1, rev4)	94

TOP COVER SIDE L ASSY (5127467 BOM, Rev 3)	95
1.1.7 – TOP COVER SIDE R ASSY (5127468)	96
TOP COVER SIDE R ASSY (5127468ADW, sheet 1, rev 4)	96
TOP COVER SIDE R ASSY (5127468 BOM, Rev 3).....	97
1.1.8 – SIDE-PANEL-FRONT-LEFT-ASSY, Positioning, GT (5130814)	98
Side Panel, Front Left Assembly (5130814ADW, sheet 1, rev 2)	98
SIDE-PANEL-FRONT-LEFT-ASSY, Positioning, GT (5130814 BOM, Rev 3)	99
1.1.9 – SIDE-PANEL-REAR-LEFT-ASSY, Positioning, GT (5130815)	100
Side Panel, Rear Left Assembly (5130815ADW, sheet 1, rev 2)	100
SIDE-PANEL-REAR-LEFT-ASSY, Positioning, GT (5130815 BOM, Rev 3).....	101
1.1.10 – SIDE-PANEL-FRONT-RIGHT-ASSY, Positioning, GT (5130816).....	102
Side Panel, Front Right Assembly (5130816ADW, sheet 1, rev 2)	102
SIDE-PANEL-FRONT-RIGHT-ASSY, Positioning, GT (5130816 BOM, Rev 3).....	103
1.1.11 – SIDE-PANEL-REAR-RIGHT-ASSY, Positioning, GT (5130817)	104
Side Panel, Right Rear Assembly (5130817ADW, sheet 1, rev 2).....	104
SIDE-PANEL-REAR-RIGHT-ASSY, Positioning, GT (5130817 BOM, Rev 3)	105
1.1.12 – RIM IMS COVER SIDE LH ASSY positioning GT (5191722)	106
RIM IMS COVER SIDE LH ASSY positioning GT (5191722ADW, sheet 1, rev 1)	106
RIM IMS COVER SIDE LH ASSY positioning GT (5191722 BOM, Rev 1)	107
1.1.13 – RIM IMS COVER SIDE RH ASSY positioning GT (5191736).....	108
RIM IMS COVER SIDE RH ASSY positioning GT (5191736ADW, sheet 1, rev 1).....	108
RIM IMS COVER SIDE RH ASSY positioning GT (5191736 BOM, Rev 1)	109
1.2 Table Ship Collector (5129558)	110
Table Ship Collector (5129558 BOM, Rev 8)	110
Section 2.0 — GT 1700 Table (5122080)	111
Positioning GT MIDDLE TABLE ASSY (5122080 BOM, Rev 18)	111
2.1 TABLE ASSY MID positioning GT (5134845)	112
Table Assembly (5127787ADW, sheet 2, rev 10)	112
Table Assembly (5127787ADW, sheet 3, rev 10)	113
Table Assembly (5127787ADW, sheet 4, rev 10)	114
Table Assembly (5127787ADW, sheet 5, rev 10)	115
Table Assembly (5127787ADW, sheet 6, rev 10)	116
Table Assembly (5127787ADW, sheet 7, rev 10)	117
Table Assembly (5127787ADW, sheet 9, rev 10)	118

Table Assembly (5127787ADW, sheet 10, rev 10)	119
Table Assembly (5127787ADW, sheet 12, rev 10)	120
TABLE ASSY MID positioning GT (5134845 BOM, Rev 31).....	121
2.1.1 – Elavation Assembly (5127773)	128
2.1.2 – Foot Switch Assembly (5126796-2)	128
2.1.3 – RIM Top Cover Assembly Positioning GT (5127465-3)	128
2.1.4 – Side-Panel-Front-Left-Assembly Positioning GT (5130814).....	128
2.1.5 – Side-Panel-Rear-Left-Assembly Positioning GT (5130815).....	128
2.1.6 – Side-Panel-Front-Right-Assembly Positioning GT (5130816)	128
2.1.7 – Side-Panel-Rear-Right-Assembly Positioning GT (5130817)	128
2.1.8 – RIM IMS Cover Side LH Assembly Positioning GT (5191722).....	128
2.1.9 – RIM IMS Cover Side RH Assembly Positioning GT (5191736).....	128
2.1.10 – TOP FRAME-1700 ASSY Positioning GT (5133502)	130
Top Frame 1700 Assembly (5133502ADW, sheet 1, rev 5).....	130
Top Frame 1700 Assembly (5133502ADW, sheet 2, rev 5).....	131
Top Frame 1700 Assembly (5133502ADW, sheet 3, rev 5).....	132
Top Frame 1700 Assembly (5133502ADW, sheet 4, rev 5).....	133
Top Frame 1700 Assembly (5133502ADW, sheet 5, rev 5).....	134
Top Frame 1700 Assembly (5133502ADW, sheet 6, rev 5).....	135
Top Frame 1700 Assembly (5133502ADW, sheet 7, rev 5).....	136
Top Frame 1700 Assembly (5133502ADW, sheet 8, rev 5).....	137
Top Frame 1700 Assembly (5133502ADW, sheet 9, rev 5).....	138
Top Frame 1700 Assembly (5133502ADW, sheet 10, rev 5).....	139
Top Frame 1700 Assembly (5133502ADW, sheet 11, rev 5).....	140
Top Frame 1700 Assembly (5133502ADW, sheet 12, rev 5).....	141
Top Frame 1700 Assembly (5133502ADW, sheet 13, rev 5).....	142
Top Frame 1700 Assembly (5133502ADW, sheet 14, rev 5).....	143
Top Frame 1700 Assembly (5133502ADW, sheet 15, rev 5).....	144
Top Frame 1700 Assembly (5133502ADW, sheet 16, rev 5).....	145
Top Frame 1700 Assembly (5133502ADW, sheet 17, rev 5).....	146
Top Frame 1700 Assembly (5133502ADW, sheet 18, rev 5).....	147
Top Frame 1700 Assembly (5133502ADW, sheet 19, rev 5).....	148
TOP FRAME-1700 ASSY Positioning GT (5133502 BOM, Rev 16)	149
2.1.10.1 – CRADLE STEEPING MOTOR CLUTCH ASSY (5135265).....	154
CRADLE STEEPING MOTOR CLUTCH ASSY (5135265ADW, sheet 1, rev 3).....	154

CRADLE STEEPING MOTOR CLUTCH 1700 ASSY Positioning GT (5135265 BOM, Rev 2).....	155
2.1.11 – TOP COVER REAR-1700 ASSY positioning GT (5133505)	156
TOP COVER REAR-1700 ASSY positioning GT (5133505ADW, sheet 1, rev 4).....	156
TOP COVER REAR-1700 ASSY positioning GT (5133505 BOM, Rev 4)	157
2.1.12 – TOP SIDE COVER L-1700 ASSY positioning GT (5133507)	158
TOP SIDE COVER L-1700 ASSY positioning GT (5133507ADW, sheet 1, rev 4)	158
TOP SIDE COVER L-1700 ASSY positioning GT (5133507 BOM, Rev 4)	159
2.1.13 – TOP SIDE COVER R-1700 ASSY positioning GT (5133506).....	160
TOP SIDE COVER R-1700 ASSY positioning GT (5133506ADW, sheet 1, rev 4).....	160
TOP SIDE COVER R-1700 ASSY positioning GT (5133506 BOM, Rev 5)	161
2.2 SHIP COLLECTOR GT TABLE 1700 (5138509)	162
SHIP COLLECTOR GT TABLE 1700 (5138509 BOM, rev 5)	162

Chapter 3

PDU.....	163
NGPDU-4 for VCT (B72352CA BOM, Rev 0)	163
Section 1.0 — NGPDU-4 (2326492-4)	164
NGPDU-4 Assembly (2326492-4 Sheet 2, Rev 4)	164
NGPDU-4 Assembly (2326492-4 BOM, Rev 12)	165
1.1 NGPDU Assembly (5125934)	166
NGPDU Assembly 4 (5125934, Sheet 1, Rev 4).....	166
NGPDU Assembly 4 (5125934, Sheet 2, Rev 4).....	167
NGPDU Assembly 4 (5125934, Sheet 3, Rev 4).....	168
NGPDU Assembly 4 (5125934 BOM, Rev 12).....	169

Chapter 4

Gantry.....	177
Section 1.0 — Gantry with Phantoms	177
VCT Gantry with Phantoms (5129909 BOM, Rev 5).....	177
Pro32 Gantry with Phantoms (5128861 BOM, Rev 1)	177
1.1 VCT Gantry.....	178
LightSpeed VCT Gantry (5124069 Sheet 1, Rev 4)	178
LightSpeed VCT Gantry (5124069 BOM, Rev 13)	179

1.2	Pro32 Gantry	180
	LightSpeed Pro32 Gantry (5126093 Sheet 2, Rev 1).....	180
	LightSpeed Pro32 Gantry (5126093 BOM, Rev 5).....	181
	Section 2.0 — VCT & Pro32 Gantry Sub-Assembly (5124068 & 5128859)	182
	LightSpeed VCT Gantry Sub-Assembly (5124068, Sheet 1, Rev 7).....	182
	LightSpeed VCT Gantry Sub-Assembly (5124068, Sheet 2, Rev 2).....	183
	LightSpeed VCT Gantry Sub-Assembly (5124068 BOM, Rev 7).....	184
	LightSpeed 32 Gantry Sub-Assembly (5128859 BOM, Rev 2).....	184
	LightSpeed VCT/Pro32 Common Slip Ring & Detector Component Collector (5126335 BOM, Rev 16).....	184
2.1	VCT and Pro32 Gantry Stationary Assembly (5124067)	188
	VCT and Pro 32 Gantry Stationary Assembly (5124067, Sheet 1, Rev 10).....	188
	VCT and Pro 32 Gantry Stationary Assembly (5124067, Sheet 2, Rev 5).....	189
	VCT and Pro 32 Gantry Stationary Assembly (5124067, Sheet 3, Rev 1).....	190
	VCT and Pro 32 Gantry Stationary Assembly (5124067, Sheet 4, Rev 2).....	191
	VCT and Pro 32 Gantry Stationary Assembly (5124067, Sheet 5, Rev 4).....	192
	VCT and Pro 32 Gantry Stationary Assembly (5124067, Sheet 6, Rev 2).....	193
	VCT and Pro 32 Gantry Stationary Assembly (5124067 BOM, Rev 20).....	194
	2.1.1 – Slip Ring Plate Assembly, VCT (5125905)	202
	Slip Ring Plate Assembly, VCT (5125905, Sheet 1, Rev 6).....	202
	Slip Ring Plate Assembly, VCT (5125905 BOM, Rev 8).....	203
	2.1.2 – Drive Assembly, HPower Axial (2217930-3)	204
	Drive Assembly, HPower Axial (2217930-3, Sheet 1, Rev 6).....	204
	Drive Assembly, HPower Axial (2217930-3, Sheet 3, Rev 5).....	205
	Drive Assembly, HPower Axial (2217930-3 BOM, Rev 1).....	206
	2.1.2.1 – Axial Motor w/Sprocket (2235342-3)	208
	Axial Motor w/Sprocket, HPower (2235342-3 Sheet 1, Rev 0).....	208
	Axial Motor w/Sprocket, HPower (2235342-3 BOM, Rev 0).....	209
	2.1.2.2 – Brake Assy, H2 AX Drive Motor (2277225)	210
	Brake Assy, H2 AX Drive Motor (2277225 Sheet 1, Rev 0).....	210
	Brake Assy, H2 AX Drive Motor (2277225 BOM, Rev 0).....	211
	2.1.2.3 – Axial Drive Motor Controller w/Corers Assy (2233402)	212
	Axial Drive Motor Controller w/Corers Assy (2233402 Sheet 1, Rev 2).....	212
	Axial Drive Motor Controller w/Corers Assy (2233402 Sheet 2, Rev 2).....	213
	Axial Drive Motor Controller w/Corers Assy (2233402 BOM, Rev 3).....	214

2.1.3 – Gantry Tilt Feedback Assembly, EMC ED2 (2356863-2)	216
Gantry Tilt Feedback Assy, EMC ED2 (2356863, Sheet 1, Rev 0)	216
Gantry Tilt Feedback Assy, EMC, ED2 (2356863-2 BOM, Rev 2)	217
2.1.4 – HP60 Gantry TGPU ED2 Assembly (5111425-2)	218
HP60 Gantry TGPU ED2 Assembly (5111425-2, Sheet 1, Rev 3)	218
HP60 Gantry TGPU ED2 Assembly (5111425-2, Sheet 2, Rev 2)	219
HP60 Gantry TGPU ED2 Assembly (5111425-2 BOM, Rev 8)	220
2.1.4.1 – HP60 Gantry TGPU Power Supply Assembly (5111429-2)	222
HP60 Gantry TGPU Power Supply Assembly (5111429, Sheet 1, Rev 2)	222
HP60 Gantry TGPU Power Supply Assembly for mobile (5111429-2, Rev 1)	223
2.1.5 – Service Outlet/E-Stop Assembly (2349257)	224
Service Outlet/E-Stop Assembly (2349257, Sheet 1, Rev 1)	224
Service Outlet/E-Stop Assembly (2349257 BOM, Rev 1)	225
2.1.6 – Power Pan Assembly - 550 Volt (5125761)	226
Power Pan Assembly - 550 Volt (5125761, Sheet 1, Rev 3)	226
Power Pan Assembly - 550 Volt (5125761, Sheet 2, Rev 3)	227
Power Pan Assembly - 550 Volt (5125761 BOM, Rev 3)	228
2.1.7 – Power Pan Assy VCT (2404232)	230
Power Pan Assy VCT (2404232 Sheet 1, Rev 5)	230
Power Pan Assy VCT (2404232 BOM, Rev 5)	231
2.1.8 – Service Board Assembly VCT (5125899)	232
Service Board Assembly VCT (5125899, Sheet 1, Rev 4)	232
Service Board Assembly VCT (5125899 BOM, Rev 5)	233
2.1.9 – Box Assembly, Blower Heater - VCT (5142966)	234
Box Assembly, Blower Heater - VCT (5142966, Sheet 1, Rev 2)	234
Box Assembly, Blower Heater - VCT (5142966, Sheet 2, Rev 1)	235
Box Assembly, Blower Heater - VCT (5142966 BOM, Rev 3)	236
2.1.10 – Power Supply - CFC Board Assembly (5158945)	238
Power Supply - CFC Board Assembly (5158945, Sheet 1, Rev 4)	238
Power Supply - CFC Board Assembly (5158945 BOM, Rev 5)	239
2.2 VCT and Pro32 Gantry Common Rotating Assembly (5124066)	240
VCT and Pro32 Gantry Common Rotating Assembly (5124066, Sheet 1, Rev 7)	240
VCT and Pro32 Gantry Common Rotating Assembly (5124066, Sheet 2, Rev 3)	241
VCT and Pro32 Gantry Common Rotating Assembly (5124066, Sheet 3, Rev 2)	242
VCT and Pro32 Gantry Common Rotating Assembly (5124066, Sheet 4, Rev 2)	243

VCT and Pro32 Gantry Common Rotating Assembly (5124066, Sheet 5, Rev 3)	244
VCT and Pro32 Gantry Common Rotating Assembly (5124066, Sheet 6, Rev 3)	245
VCT and Pro32 Gantry Common Rotating Assembly (5124066 BOM, Rev 19)	246
2.2.1 – VCT Gantry Frame with Failsafe Balance (5112448-2)	250
Gantry Frame Assembly VCT (5112448, Sheet 1, Rev 12)	250
Gantry Frame Assembly VCT (5112448, Sheet 2, Rev 4)	251
Gantry Frame Assembly VCT (5112448, Sheet 3, Rev 10)	252
VCT Gantry Frame with Failsafe Balance (5112448-2 BOM, Rev 8)	253
<i>2.2.1.1 – Hydraulic Tilt Motor Assembly (2334727)</i>	<i>256</i>
Hydraulic Tilt Motor Assembly (2334727, Sheet 1, Rev 2)	256
Hydraulic Tilt Motor Assembly (2334727, Sheet 2, Rev 0)	257
Hydraulic Tilt Motor Assembly (2334727, Sheet 3, Rev 0)	258
Hydraulic Tilt Motor Assembly (2334727 BOM, Rev 4)	259
2.2.2 – Performix PRO100/VCT (RG) (D3194T)	260
Performix PRO100/VCT - RG (D3194T BOM)	260
2.2.3 – VCT Failsafe Collimator Assy (5130001)	262
VCT Failsafe Collimator Assy (5130001, Sheet 1, Rev 1)	262
VCT Failsafe Collimator Assy (5130001, BOM, Rev 6)	263
<i>2.2.3.1 – VCT Failsafe Collimator Assy (5130000-2)</i>	<i>264</i>
VCT Failsafe Collimator Assy (5130000, Sheet 1, Rev 8)	264
VCT Failsafe Collimator Assy (5130000, Sheet 2, Rev 6)	265
VCT Failsafe Collimator Assy (5130000-2 BOM, Rev 3)	266
<i>VCT Failsafe Base Assy (5129999)</i>	<i>268</i>
VCT Failsafe Base Assy (5129999 Sheet 1, Rev 4)	268
VCT Failsafe Base Assy (5129999 BOM, Rev 4)	269
2.2.4 – JH4 Inverter with Shield (2281950-4)	272
JH4 Inverter with Shield (2281950-4, Sheet 2, Rev 3)	272
JH4 Inverter with Shield (2281950-4, Sheet 3, Rev 3)	273
JH4 Inverter with Shield (2281950-4, Sheet 4, Rev 3)	274
JH4 Inverter with Shield (2281950-4, Sheet 5, Rev 3)	275
JH4 Inverter with Shield (2281950-4, Sheet 6, Rev 3)	276
JH4 Inverter with Shield (2281950-4, Sheet 7, Rev 3)	277
JH4 Inverter with Shield (2281950-4 BOM, Rev 13)	278
2.2.5 – Performix PRO VCT Heat Exchanger (5124371)	282
Performix PRO VCT Heat Exchanger (5124371, Sheet 1, Rev 3)	282

	Performix PRO VCT Heat Exchanger (5124371 BOM, Rev 4)	283
	<i>2.2.5.1 – Performix PRO VCT Heat Exchanger Assembly (5123691)</i>	<i>284</i>
	Performix PRO VCT Heat Exchanger Assembly (5123691 Sheet 1, Rev 4).....	284
	Performix PRO VCT Heat Exchanger Assembly (5123691 Sheet 2, Rev 1).....	285
	Performix PRO VCT Heat Exchanger Assembly (5123691 Sheet 3, Rev 1).....	286
	Performix PRO VCT Heat Exchanger Assembly (5123691 Sheet 4, Rev 4).....	287
	Performix PRO VCT Heat Exchanger Assembly (5123691 BOM, Rev 5).....	288
	2.2.6 – Inverter-Auxiliary Parts for CT (2368331-3).....	291
	Inverter Auxilliary Parts for CT (2368331-3 BOM, Rev 2)	291
2.3	Subsystem Assembly, VDAS-Detector, VCT LS64 (5126400)	292
	Subsystem Assembly, DAS-Detector, VCT LS64 (5126400, Sheet 1, Rev 9)	292
	Subsystem Assembly, DAS-Detector, VCT LS64 (5126400, Sheet 2, Rev 9)	293
	Subsystem Assembly, DAS-Detector, VCT LS64 (5126400, Sheet 3, Rev 9)	294
	Subsystem Assembly, DAS-Detector, VCT LS64 (5126400 BOM, Rev 14)	295
	2.3.1 – Subsystem Assembly, DAS, VCT, LS64 (5116400-64)	298
	Subsystem Assembly, DAS, VCT, LS64 (5116400-64, Sheet 1, Rev 7).....	298
	Subsystem Assembly, DAS, VCT, LS64 (5116400-64 BOM, Rev 9).....	299
	<i>2.3.1.1 – Subsystem Base Assembly, DAS, VCT (5116400).....</i>	<i>300</i>
	Subsystem Base Assembly, DAS, VCT (5116400, Sheet 1, Rev 6)	300
	Subsystem Base Assembly, DAS, VCT (5116400 BOM, Rev 7)	301
	<i>Support Plate Mechanical Sub-Assembly, DAS, VCT LS64 (5114903)</i>	<i>302</i>
	Mechanical Support Plate Sub-Assembly, DAS, VCT LS64 (5114903, Sheet 1, Rev 6)	302
	Mechanical Support Plate Sub-Assembly, DAS, VCT LS64 (5114903 BOM, Rev 7)	303
	2.3.2 – Collimator HLA, VCT 64 (5121363).....	304
	Collimator HLA, VCT 64 (5121363 Sheet 1, Rev 2).....	304
	Collimator HLA, VCT 64 (5121363 BOM, Rev 7)	305
	2.3.3 – Plenum Assembly (5169298)	306
	Plenum Assembly (5169298 Sheet 1, Rev 2)	306
	Plenum Assembly (5169298 BOM, Rev 2).....	307
2.4	Subsystem Assembly, HDAS-Detector, VCT LS64 (5196400)	310
	V-Res Halo DAS-Detector Assembly (5196400, Sheet 1, Rev 1)	310
	V-Res Halo DAS-Detector Assembly (5196400, Sheet 2, Rev 1)	311
	V-Res Halo DAS-Detector Assembly (5196400, Sheet 3, Rev 1)	312
	V-Res Halo DAS-Detector Assembly (5196400 BOM, Rev 1)	313

2.4.1 – Subsystem Assembly, DAS, HALO LS64 (5170064)	316
Subsystem Assembly, DAS, HALO LS64 (5170064 Sheet 1, Rev 3)	316
Subsystem Assembly, DAS, HALO LS64 (5170064 BOM, Rev 1)	317
2.4.1.1 – Subsystem Base Assembly, DAS, HALO LS32-64 (5173264)	318
Subsystem Base Assembly, DAS, HALO LS32-64 (5116400 Sheet 1, Rev 7)	318
Subsystem Base Assembly, DAS, HALO LS32-64 (5173264 BOM, Rev 2)	319
Sub-Assembly, Mechanical, Support Plate, DAS, HALO w/ HALO Backplanes (5114903-2)	320
Sub-Assembly, Mechanical, Support Plate, DAS, HALO w/ HALO Backplanes (5114903 Sheet 1, Rev 7)	320
Sub-Assembly, Mechanical, Support Plate, DAS, HALO w/ HALO Backplanes (5114903 BOM, Rev 1)	321
2.5 Subsystem Assembly, VDAS-Detector, VCT LS32 (5123200)	322
Subsystem Assembly, DAS-Detector, VCT LS32 (5123200, Sheet 1, Rev 4)	322
Subsystem Assembly, DAS-Detector, VCT LS32 (5123200, Sheet 2, Rev 3)	323
Subsystem Assembly, DAS-Detector, VCT LS32 (5123200, Sheet 4, Rev 2)	324
Subsystem Assembly, DAS-Detector, VCT LS32 (5123200 BOM, Rev 18)	325
2.5.1 – Subsystem Assembly, DAS, VCT LS32 (5116400-32)	328
Subsystem Assembly, DAS, VCT LS32 (5116400-32, Sheet 1, Rev 4)	328
Subsystem Assembly, DAS, VCT LS32 (5116400-32 BOM, Rev 6)	329
2.5.2 – VCT Plenum Assembly (5117776)	330
VCT Plenum Assembly (5117776, Sheet 1, Rev 3)	330
VCT Plenum Assembly (5117776 BOM, Rev 3)	331
2.5.3 – VCT Plenum Assembly (5169298)	334
VCT Plenum Assy (5169298, Sheet 2, Rev. 5)	334
VCT Plenum Assembly (5169298 BOM, Rev 6)	335
2.6 VCT Slip Ring Assembly (2402401)	338
VCT Slip Ring Assembly (2402401 Sheet 1, Rev 3)	338
VCT Slip Ring Assembly (2402401 BOM, Rev 4)	339
2.6.1 – 2.5 GB 2 Channel HSDCD Slip Ring Assembly (2376399)	340
2.5 GB 2 Channel HSDCD Slip Ring Assembly (2376399, Sheet 1, Rev 4)	340
2.5 GB 2 Channel HSDCD Slip Ring Assembly (2376399 BOM)	341
2.6.1.1 – Slip Ring Platter - VCT (2403229)	342
Slip Ring Platter - VCT (2403229, Sheet 1, Rev 3)	342
Slip Ring Platter - VCT (2403229 BOM, Rev 4)	343
2.6.1.2 – VCT Slip Ring Brushblock (5120819)	344
VCT Slip Ring Brushblock (5120819, Sheet 1, Rev 3)	344
VCT Slip Ring Brushblock (5120819 BOM, Rev 3)	345

Power Brush Tip Collector (2349603)	345
Power Brush Tip Collector (2349603 BOM, Rev 0).....	345
Signal Brush Tip Collector (2349604)	345
Signal Brush Tip Collector (2349604 BOM, Rev 0).....	345
Section 3.0 — Gantry Covers	346
3.1 Cover Assembly, Front Gantry (2397075)	346
Cover Assembly, Front Gantry (2397075, Sheet 1, Rev 6)	346
Cover Assembly, Front Gantry (2397075 BOM, Rev 9)	347
3.1.1 – Cover Sub Assy, Front Gantry-VCT (2397074)	348
Cover Sub Assy, Front Gantry-VCT (2397074 BOM, Rev)	348
3.2 Cover Assembly, Rear Gantry (2397078)	350
Cover Assembly, Rear Gantry (2397078, Sheet 1, Rev 4)	350
Cover Assembly, Rear Gantry (2397078 BOM, Rev 8).....	351
3.3 Top Cover Right Side Assy w/ DC Fans (5114585).....	352
Top Cover Right Side Assembly with DC Fans (5114585, Sheet 1, Rev 3).....	352
Top Cover Right Side Assembly with DC Fans (5114585 BOM, Rev 4).....	353
3.4 Cover Assy, Side Gantry Right - Pro32 (2276690-5)	354
Cover Assy, Side Gantry Right - Pro32 (2276690, Sheet 1, Rev 2).....	354
Cover Assy, Side Gantry Right - Pro32 (2276690-5 BOM, Rev 0).....	355
3.5 Top Cover Left Side Assy w/ DC Fans (5114585-2).....	356
Top Cover Left Side Assembly with DC Fans (5114585-2, Sheet 1, Rev 3).....	356
Top Cover Left Side Assembly with DC Fans (5114585-2 BOM, Rev 5)	357
Section 4.0 — Phantom Kit (5129910).....	358
Phantom Kit (5129910 BOM, Rev 1).....	358

Chapter 5

Miscellaneous Items 359

Section 1.0 — LS VCT/Pro32 Common Non-Mobile Shipping Collector (5120455).....	359
LS VCT/Pro32 Gantry & HP/GT Table Common Non-Mobile Shipping Collector (5120455 BOM)	359
1.1 Base Cover Collector (2290278-4)	360
Base Cover Collector (2290278-4 BOM, Rev 0)	360

1.2	Fuse Kit (5125429)	361
	Fuse Kit - Originally Developed for VCT (5125429 BOM, Rev 2).....	361
1.3	VCT Gantry & HP/GT Table Common Shipping Collector (5130493)	362
	VCT Gantry & HP/GT Table Common Shipping Collector (5130493 BOM, Rev 16)	362
	VCT Gantry & HP/GT Table Common Shipping Collector (5130493 BOM, Rev 8)	363
1.3.1	– Non-Tilt Dolly Rear Cover (2282011)	365
	Non-Tilt Dolly Rear Cover (2282011 BOM, Rev 1).....	365
1.3.2	– CT-9800 Accessories (46-229452G1)	365
	CT-9800 Accessories (46-229452G1 BOM, Rev 3)	365
Section 2.0 — Cable Collectors		366
2.1	Short Cable Collector (2281840-7)	366
	Short Cable Collector (2281840-7 BOM, Rev 3)	366
2.1.1	– Console Cable - Short VCT Kit (2371133-4)	366
	Console Cable - Short VCT Kit (2371133-4 BOM, Rev 1)	366
2.1.2	– Gantry Cables - Short VCT Kit (2371134-4)	366
	Gantry Cables - Short VCT Kit (2371134-4 BOM, Rev 2)	366
2.2	Long Cable Collector (2281840-6)	367
	Long Cable Collector (2281840-6 BOM, Rev 3).....	367
2.2.1	– Console Cables - Long VCT Cables (2371133-3)	367
	Console Cables - Long VCT Cables (2371133-3 BOM, Rev 1)	367
2.2.2	– Gantry Cables - Long VCT Kit (2371134-3)	367
	Gantry Cables - Long VCT Kit (2371134-3 BOM, Rev 1).....	367
Section 3.0 — IVY 3150 ECG Monitor Collector		368
	IVY 3150 ECG Monitor Collector (5133408 BOM, Rev 1).....	368
Section 4.0 — Small Room Catalog (5191743)		369
	Small Room Catalog (5191743 BOM, Rev 1)	369
4.1	Dolly, Pivoting, Small Room, RH (5179183)	370
	Dolly, Pivoting, Small Room (5179183 Sheet 1, Rev 3).....	370
	Dolly, Pivoting, Small Room, RH (5179183 BOM, Rev 2)	371
4.2	Dolly, Pivoting, Small Room, LH (5179183-2)	372
	Dolly, Pivoting, Small Room (5179183 Sheet 1, Rev 3).....	372
	Dolly, Pivoting, Small Room, LH (5179183-2 BOM, Rev 2)	373

Chapter 1

Introduction

Section 1.0 — Page Layout, Including Finger Tabs

Headers and footers in this publication are designed to allow you to quickly identify your location. The document's part number, revision number and title appear in the header on every page. All page footers display the current page number, at left (when viewed landscape). Odd numbered page footers include a reversed "finger tab" to help the user quickly flip through this manual. These tabs include chapter number and name, plus the name of the current major (level one) section heading. Where applicable, even page footers will show the current minor (level two) section number and name (e.g., Section 2.0 — Manual Organization) - otherwise, they repeat the current major (level one) section heading and name (e.g., Section 1.0 — Page Layout, Including Finger Tabs).

Section 2.0 — Manual Organization

This document is organized according to product structure. That is, the order in which the contents appear is based on the BOMs (Bills of Material) used herein. This means that the user may be required to "dig down" through the product structure in order to find the part they are looking for. [For pdf users, hyperlinks are provided for quick navigation downward (the "back" arrow may be used to move back up)].

WHAT IS A BOM?

A BOM is a Bill (list) Of Materials (parts) used to produce an item. The Parent Item is the thing that is made from the parts listed on the BOM. Because BOMs describe the materials required for a specific manufacturing process, they may not necessarily list every single item used to produce the parent item. The parts on a BOM themselves may be the result of a separate process, and thus have their own BOMs, listing the secondary items required to produce these primary parts.

Section 3.0 — Operator Console Parts Information

The Operator's Console that is used with the LightSpeed 7.X VCT Scanner is the GOC5 (Global Operator Console, version 5). For Parts Information on the GOC5, please refer to Direction 5135498-100, available as a PDF on the LightSpeed 7.X Service Information CD-ROM, Dir 5116423-200.

End of Chapter.