

GE Healthcare

LightSpeed 5.X RT

Illustrated Parts List

OPERATING DOCUMENTATION



5134004-100
Rev 6

Effectivity

The information in this manual applies to the following LightSpeed RT CT Systems:

- LightSpeed RT w/MDAS (4-Slices)
- LightSpeed RT w/GDAS (4-Slices)

IMPORTANT PRECAUTIONS

LANGUAGE

警告 (ZH-CN)	• 本维修手册仅提供英文版本。 • 如果维修服务提供商需要非英文版本，客户需自行提供翻译服务。 • 未详细阅读和完全理解本维修手册之前，不得进行维修。 • 忽略本警告可能对维修人员，操作员或患者造成触电、机械伤害或其他形式的伤害。
ПРЕДУПРЕЖДЕНИЕ (BG)	• Това упътване за работа е налично само на английски език. • Ако доставчикът на услугата на клиента изиска друг език, задължение на клиента е да осигури превод. • Не използвайте оборудването, преди да сте се консултирали и разбрали упътването за работа. • Неспазването на това предупреждение може да доведе до нараняване на доставчика на услугата, оператора или пациент в резултат на токов удар или механична или друга опасност.
VÝSTRAHA (CS)	• Tento provozní návod existuje pouze v anglickém jazyce. • V případě, že externí služba zákazníkům potřebuje návod v jiném jazyce, je zajištění překladu do odpovídajícího jazyka úkolem zákazníka. • Nesnažte se o údržbu tohoto zařízení, aniž byste si přečetli tento provozní návod a pochopili jeho obsah. • V případě nedodržování této výstrahy může dojít k poranění pracovníka prodejního servisu, obslužného personálu nebo pacientů vlivem elektrického proudu, respektive vlivem mechanických či jiných rizik.
ADVARSEL (DA)	• Denne servicemanual findes kun på engelsk. • Hvis en kundes tekniker har brug for et andet sprog end engelsk, er det kundens ansvar at sørge for oversættelse. • Forsøg ikke at servicere udstyret medmindre denne servicemanual har været konsulteret og er forstået. • Manglende overholdelse af denne advarsel kan medføre skade på grund af elektrisk, mekanisk eller anden fare for teknikeren, operatøren eller patienten.

WAARSCHUWING (NL)	• Deze onderhoudshandleiding is enkel in het Engels verkrijgbaar. • Als het onderhoudspersoneel een andere taal vereist, dan is de klant verantwoordelijk voor de vertaling ervan. • Probeer de apparatuur niet te onderhouden voordat deze onderhoudshandleiding werd geraadpleegd en begrepen is. • Indien deze waarschuwing niet wordt opgevolgd, zou het onderhoudspersoneel, de operator of een patiënt gewond kunnen raken als gevolg van een elektrische schok, mechanische of andere gevaren.
WARNING (EN)	• This Service Manual is available in English only. • If a customer's service provider requires a language other than English, it is the customer's responsibility to provide translation services. • Do not attempt to service the equipment unless this service manual has been consulted and is understood. • Failure to heed this warning may result in injury to the service provider, operator, or patient, from electric shock or from mechanical or other hazards.
HOIATUS (ET)	• Käesolev teenindusjuhend on saadaval ainult inglise keeles. • Kui klienditeeninduse osutaja nõuab juhendit inglise keelest erinevas keeles, vastutab klient tõlketeenuse osutamise eest. • Ärge üritage seadmeid teenindada enne eelnevalt käesoleva teenindusjuhendiga tutvumist ja sellest aru saamist. • Käesoleva hoiatuse eiramine võib põhjustada teenuseosutaja, operaatori või patsiendi vigastamist elektrilöögi, mehaanilise või muu ohu tagajärjel.
VAROITUS (FI)	• Tämä huolto-ohje on saatavilla vain englanniksi. • Jos asiakkaan huoltohenkilöstö vaatii muuta kuin englanninkielistä materiaalia, tarvittavan käännöksen hankkiminen on asiakkaan vastuulla. • Älä yritä korjata laitteistoa ennen kuin olet varmasti lukenut ja ymmärtänyt tämän huolto-ohjeen. • Mikäli tätä varoitusta ei noudateta, seurauksena voi olla huoltohenkilöstön, laitteiston käyttäjän tai potilaan vahingoittuminen sähköiskun, mekaanisen vian tai muun vaaratilanteen vuoksi.

ATTENTION (FR)	• Ce manuel de service n'est disponible qu'en anglais. • Si le technicien du client a besoin de ce manuel dans une autre langue que l'anglais, c'est au client qu'il incombe de le faire traduire. • Ne pas tenter d'intervenir sur les équipements tant que le manuel service n'a pas été consulté et compris • Le non-respect de cet avertissement peut entraîner chez le technicien, l'opérateur ou le patient des blessures dues à des dangers électriques, mécaniques ou autres.
WARNUNG (DE)	• Diese Serviceanleitung existiert nur in Englischer Sprache. • Falls ein fremder Kundendienst eine andere Sprache benötigt, ist es aufgabe des Kunden für eine Entsprechende Übersetzung zu sorgen. • Versuchen Sie nicht diese Anlage zu warten, ohne diese Serviceanleitung gelesen und verstanden zu haben. • Wird diese Warnung nicht beachtet, so kann es zu Verletzungen des Kundendiensttechnikers, des Bedieners oder des Patienten durch Stromschläge, Mechanische oder Sonstige gefahren kommen.
ΠΡΟΕΙΔΟΠΟΙΗΣΗ (EL)	• Το παρόν εγχειρίδιο σέρβις διατίθεται στα αγγλικά μόνο. • Εάν το άτομο παροχής σέρβις ενός πελάτη απαιτεί το παρόν εγχειρίδιο σε γλώσσα εκτός των αγγλικών, αποτελεί ευθύνη του πελάτη να παρέχει υπηρεσίες μετάφρασης. • Μην επιχειρήσετε την εκτέλεση εργασιών σέρβις στον εξοπλισμό εκτός εαν έχετε συμβουλευτεί και έχετε κατανοήσει το παρόν εγχειρίδιο σέρβις. • Εάν δε λάβετε υπόψη την προειδοποίηση αυτή, ενδέχεται να προκληθεί τραυματισμός στο άτομο παροχής σέρβις, στο χειριστή ή στον ασθενή από ηλεκτροπληξία, μηχανικούς ή άλλους κινδύνους.
FIGYELMEZTETÉS (HU)	• Ezen karbantartási kézikönyv kizárólag angol nyelven érhető el. • Ha a vevő szolgáltatója angoltól eltérő nyelvre tart igényt, akkor a vevő felelőssége a fordítás elkészíttetése. • Ne próbálja elkezdni használni a berendezést, amíg a karbantartási kézikönyvben leírtakat nem értelmezték. • Ezen figyelmeztetés figyelmen kívül hagyása a szolgáltató, működtető vagy a beteg áramütés, mechanikai vagy egyéb veszélyhelyzet miatti sérülését eredményezheti.

AÐVÖRUN (IS)	• Þessi þjónustuhandbók er eingöngu fánleg á ensku. • Ef að þjónustuveitandi viðskiptamanns þarfnast annas tungumáls en ensku, er það skylda viðskiptamanns að skaffa tungumálþjónustu. • Reynið ekki að afgreiða tækið nema að þessi þjónustuhandbók hefur verið skoðuð og skilin. • Brot á sinna þessari aðvörun getur leitt til meiðsla á þjónustuveitanda, stjórnanda eða sjúklings frá raflosti, vélrænu eða öðrum áhættum.
AVVERTENZA (IT)	• Il presente manuale di manutenzione è disponibile soltanto in inglese. • Se un addetto alla manutenzione richiede il manuale in una lingua diversa, il cliente è tenuto a provvedere direttamente alla traduzione. • Si proceda alla manutenzione dell'apparecchiatura solo dopo aver consultato il presente manuale ed averne compreso il contenuto • Il non rispetto della presente avvertenza potrebbe far compiere operazioni da cui derivino lesioni all'addetto, alla manutenzione, all'utilizzatore ed al paziente per folgorazione elettrica, per urti meccanici od altri rischi.
警告 (JA)	• このサービスマニュアルには英語版しかありません。 • サービスを担当される業者が英語以外の言語を要求される場合、翻訳作業はその業者の責任で行うものとさせていただきます。 • このサービスマニュアルを熟読し理解せずに、装置のサービスを行わないでください。 • この警告に従わない場合、サービスを担当される方、操作員あるいは患者さんが、感電や機械的又はその他の危険により負傷する可能性があります。
경고 (KO)	• 본 서비스 지침서는 영어로만 이용하실 수 있습니다 . • 고객의 서비스 제공자가 영어 이외의 언어를 요구할 경우 , 번역 서비스를 제공하는 것은 고객님의 책임입니다 . • 본 서비스 지침서를 참고했고 이해하지 않는 한은 해당 장비를 수리하려고 시도하지 마십시오 . • 이 경고에 유의하지 않으면 전기 쇼크 , 기계상의 혹은 다른 위험으로부터 서비스 제공자 , 운영자 혹은 환자에게 위험을 가할 수 있습니다 .
BRDINJUMS (LV)	• Šī apkalpes rokasgrāmata ir pieejama tikai angļu valodā. • Ja klienta apkalpes sniedzējam nepieciešama informācija citā valodā, nevis angļu, klienta pienākums ir nodrošināt tulkošanu. • Neveiciet aprīkojuma apkalpi bez apkalpes rokasgrāmatas izlasīšanas un saprašanas. • Šī brīdinājuma neievērošana var radīt elektriskās strāvas trieciena, mehānisku vai citu risku izraisītu traumu apkalpes sniedzējam, operatoram vai pacientam.

ĮSPĖJIMAS (LT)	• Šis eksploatavimo vadovas yra prieinamas tik anglų kalba. • Jei kliento paslaugų tiekėjas reikalauja vadovo kita kalba – ne anglų, numatyti vertimo paslaugas yra kliento atsakomybė. • Nemėginkite atlikti įrangos techninės priežiūros, nebent atsižvelgėte į šį eksploatavimo vadovą ir jį supratote. • Jei neatkreipsite dėmesio į šį perspėjimą, galimi sužalojimai dėl elektros šoko, mechaninių ar kitų pavojų paslaugų tiekėjui, operatoriui ar pacientui.
ADVARSEL (NO)	• Denne servicehåndboken finnes bare på engelsk. • Hvis kundens serviceleverandør trenger et annet språk, er det kundens ansvar å sørge for oversettelse. • Ikke forsøk å reparere utstyret uten at denne servicehåndboken er lest og forstått. • Manglende hensyn til denne advarselen kan føre til at serviceleverandøren, operatøren eller pasienten skades på grunn av elektrisk støt, mekaniske eller andre farer.
OSTRZEŻENIE (PL)	• Niniejszy podręcznik serwisowy dostępny jest jedynie w języku angielskim. • Jeśli dostawca usług klienta wymaga języka innego niż angielski, zapewnienie usługi tłumaczenia jest obowiązkiem klienta. • Nie próbować serwisować wyposażenia bez zapoznania się i zrozumienia niniejszego podręcznika serwisowego. • Niezastosowanie się do tego ostrzeżenia może spowodować urazy dostawcy usług, operatora lub pacjenta w wyniku porażenia elektrycznego, zagrożenia mechanicznego bądź innego.
ATENÇÃO (PT)	• Este manual de assistência técnica só se encontra disponível em inglês. • Se qualquer outro serviço de assistência técnica solicitar estes manuais noutro idioma, é da responsabilidade do cliente fornecer os serviços de tradução. • Não tente consertar o equipamento sem ter consultado e compreendido este manual de assistência técnica. • O não cumprimento deste aviso pode pôr em perigo a segurança do técnico, do operador ou do paciente devido a choques elétricos, mecânicos ou outros.
ATENȚIE (RO)	• Acest manual de service este disponibil numai în limba engleză. • Dacă un furnizor de servicii pentru clienți necesită o altă limbă decât cea engleză, este de datoria clientului să furnizeze o traducere. • Nu încercați să reparați echipamentul decât ulterior consultării și înțelegerii acestui manual de service. • Ignorarea acestui avertisment ar putea duce la rănirea depanatorului, operatorului sau pacientului în urma pericolelor de electrocutare, mecanice sau de altă natură.

ОСТОРОЖНО! (RU)	• Данное руководство по обслуживанию предлагается только на английском языке. • Если сервисному персоналу клиента необходимо руководство не на английском, а на каком-то другом языке, клиенту следует самостоятельно обеспечить перевод. • Перед обслуживанием оборудования обязательно обратитесь к данному руководству и поймите изложенные в нем сведения. • Несоблюдение требований данного предупреждения может привести к тому, что специалист по обслуживанию, оператор или пациент получат удар электрическим током, механическую травму или другое повреждение.
UPOZORNENIE (SK)	• Tento návod na obsluhu je k dispozícii len v angličtine. • Ak zákazníkovi poskytovateľ služieb vyžaduje iný jazyk ako angličtinu, poskytnutie prekladateľských služieb je zodpovednosťou zákazníka. • Nepokúšajte sa o obsluhu zariadenia skôr, ako si neprečítate návod na obsluhu a neporozumiete mu. • Zanedbanie tohto upozornenia môže vyústiť do zranenia poskytovateľa služieb, obsluhujúcej osoby alebo pacienta elektrickým prúdom, do mechanického alebo iného nebezpečenstva.
ATENCION (ES)	• Este manual de servicio sólo existe en inglés. • Si el encargado de mantenimiento de un cliente necesita un idioma que no sea el inglés, el cliente deberá encargarse de la traducción del manual. • No se deberá dar servicio técnico al equipo, sin haber consultado y comprendido este manual de servicio. • La no observancia del presente aviso puede dar lugar a que el proveedor de servicios, el operador o el paciente sufran lesiones provocadas por causas eléctricas, mecánicas o de otra naturaleza.
VARNING (SV)	• Den här servicehandboken finns bara tillgänglig på engelska. • Om en kunds servicetekniker har behov av ett annat språk än engelska ansvarar kunden för att tillhandahålla översättningstjänster. • Försök inte utföra service på utrustningen om du inte har läst och förstår den här servicehandboken. • Om du inte tar hänsyn till den här varningen kan det resultera i skador på serviceteknikern, operatören eller patienten till följd av elektriska stötar, mekaniska faror eller andra faror.

DIKKAT (TR)	• Bu servis kilavuzunun sadece ingilizcesi mevcuttur. • Eğer müşteri teknisyeni bu kilavuzu ingilizce dışında bir başka lisandan talep ederse, bunu tercüme ettirmek müşteriye düşer. • Servis kilavuzunu okuyup anlamadan ekipmanlara müdahale etmeyiniz. • Bu uyarıya uyulmaması, elektrik, mekanik veya diğer tehlikelerden dolayı teknisyen, operatör veya hastanın yaralanmasına yol açabilir.
-----------------------	---

DAMAGE IN TRANSPORTATION

All packages should be closely examined at time of delivery. If damage is apparent, have notation "damage in shipment" written on all copies of the freight or express bill before delivery is accepted or "signed for" by a General Electric representative or a hospital receiving agent. Whether noted or concealed, damage MUST be reported to the carrier immediately upon discovery, or in any event, within 14 days after receipt, and the contents and containers held for inspection by the carrier. A transportation company will not pay a claim for damage if an inspection is not requested within this 14 day period.

To file a report:

- Call 1-800-548-3366 and use option 8.
- Fill out a report on <http://us44hdd21/sctq/InstallFulfill/InstalFulfillment.htm>
- Contact your local service coordinator for more information on this process.

Rev. Jan. 5, 2005

CERTIFIED ELECTRICAL CONTRACTOR STATEMENT

All electrical Installations that are preliminary to positioning of the equipment at the site prepared for the equipment shall be performed by licensed electrical contractors. In addition, electrical feeds into the Power Distribution Unit shall be performed by licensed electrical contractors. Other connections between pieces of electrical equipment, calibrations and testing shall be performed by qualified GE Healthcare personnel. The products involved (and the accompanying electrical installations) are highly sophisticated, and special engineering competence is required. In performing all electrical work on these products, GE will use its own specially trained field engineers. All of GE's electrical work on these products will comply with the requirements of the applicable electrical codes.

The purchaser of GE equipment shall only utilize qualified personnel (i.e., GE's field engineers, personnel of third-party service companies with equivalent training, or licensed electricians) to perform electrical servicing on the equipment.

IMPORTANT...X-RAY PROTECTION

X-ray equipment if not properly used may cause injury. Accordingly, the instructions herein contained should be thoroughly read and understood by everyone who will use the equipment before you attempt to place this equipment in operation. The General Electric Company, Healthcare, will be glad to assist and cooperate in placing this equipment in use.

Although this apparatus incorporates a high degree of protection against x-radiation other than the useful beam, no practical design of equipment can provide complete protection. Nor can any practical design compel the operator to take adequate precautions to prevent the possibility of any persons carelessly exposing themselves or others to radiation.

It is important that anyone having anything to do with x-radiation be properly trained and fully acquainted with the recommendations of the National Council on Radiation Protection and Measurements as published in NCRP Reports available from NCRP Publications, 7910 Woodmont Avenue, Room 1016, Bethesda, Maryland 20814, and of the International Commission on Radiation Protection, and take adequate steps to protect against injury.

The equipment is sold with the understanding that the General Electric Company, Healthcare, its agents, and representatives have no responsibility for injury or damage which may result from improper use of the equipment.

Various protective materials and devices are available. It is urged that such materials or devices be used.

LITHIUM BATTERY CAUTIONARY STATEMENTS



CAUTION Risk of Explosion

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.



ATTENTION Danger d'Explosion

Il y a danger d'explosion s'il y a un remplacement incorrect de la batterie. Remplacer uniquement avec une batterie du même type ou d'un type recommandé par le constructeur. Mettre au rebut les batteries usagées conformément aux instructions du fabricant.

OMISSIONS & ERRORS

Customers, please contact your GE Sales or Service representatives.

GE personnel, please use the GE Healthcare PQR Process to report all omissions, errors, and defects in this publication.

Revision History

Revision	Date	Reason for change
6	04/21/08	Chapter 4: Updated 5182284-2 BOM, changed new Gear.
5	09/07/07	Chapter 4: Updated 2374681-4 BOM, added new Top and side Cover Chapter 5: Added Handle to the ship collector
4	04/24/07	Updated warning contents according to new language policy Chapter 4: Updated the 2374681-4 BOM, changed front and rear cover Chapter 5: Updated the ship collector BOM
3	02/23/06	Deleted the 46-194427P314 part from Chapter 5, Section 3.0 as EHS Issue (For PQR 13061187)
2	5/30/05	Added new sections for : JH4 Inverter with Shields JEDI H4 MPHVTank Inverter-Auxiliary Parts for CT
1	3/30/05	Initial release of Direction 5134004-100, to support RT GDAS M3 and RT MDAS legacy products. NOTE: This Direction (5134004-100) was formerly part of Direction 2349187-100, from Revisions 5 through 14.

Table of Contents

Chapter 1

Introduction	25
Section 1.0 — Page Layout, Including Finger Tabs	25
Section 2.0 — Manual Organization.....	26
Section 3.0 — Operator Console Parts Information	26

Chapter 2

Table	27
Cat Coll/H Power Table with Footswitch (2373155 BOM, rev 0).....	27
Section 1.0 — Table Assembly - H Power (2335179).....	28
Table Assembly - H Power (2335179, sheet 1, rev 2).....	28
Table Assembly - H Power (2335179, sheet 2, rev 2).....	29
Table Assembly - H Power (2335179 BOM, rev 9)	30
1.1 Side Panel Kit (2269167-2).....	33
Side Panel Kit for H2 LCC Cathay Table (2269167-2 BOM, rev 0).....	33
1.2 Cover Table Top - Left (2372371)	34
Cover Table Top - Left (2372371, sheet 1, rev 1)	34
Cover Table Top - Left (2372371 BOM, rev 1).....	35
1.3 Cover Table Top - Right (2372372)	36
Cover Table Top - Right (2372372, sheet 1, rev 1).....	36
Cover Table Top - Right (2372372 BOM, rev 1)	37
1.4 Metalless Cradle (2115992-5)	38
Metalless Cradle (2115992, sheet 1, rev 7)	38
Metalless Cradle (2115992-5 BOM, rev 1).....	39
1.5 Table Subassembly - H Power (2335178).....	40
Table Subassembly (2335178, sheet 1, rev 5).....	40
Table Subassembly (2335178, sheet 2, rev 2).....	41
Table Subassembly (2335178, sheet 3, rev 2).....	42
Table Subassembly (2335178, sheet 4, rev 1).....	43

Table Subassembly (2335178 BOM, rev 5)	44
1.5.1 – Carriage Assembly (2269168-2)	48
Carriage Assembly (2269168-2, sheet 2, rev1).....	48
Carriage Assembly (2269168-2 BOM, rev 1)	49
1.5.2 – Latch Assembly (2269177)	50
Latch Assembly (2269177, sheet 1, rev 0).....	50
Latch Assembly (2269177 BOM, rev 0)	51
1.5.3 – Cradle Drive Assembly (2339120)	52
Cradle Drive Assembly (2339120, sheet 1, rev 0).....	52
Cradle Drive Assembly (2339120, sheet 2, rev 0).....	53
Cradle Drive Assembly (2339120, sheet 3, rev 0).....	54
Cradle Drive Assembly (2339120 BOM, rev 3)	55
1.5.4 – Encoder Assembly, Elevation - H Power (2337217)	58
Encoder Assembly, Elevation - H Power (2337217, sheet 1, rev 1)	58
Encoder Assembly, Elevation - H Power (2337217 BOM, rev 2)	59
1.5.5 – Table Frame Assembly (2335177)	60
Table Frame Assembly (2335177, sheet 1, rev 1)	60
Table Frame Assembly (2335177, sheet 2, rev 0)	61
Table Frame Assembly (2335177, sheet 3, rev 1)	62
Table Frame Assembly (2335177, sheet 4, rev 0)	63
Table Frame Assembly (2335177, sheet 5, rev 0)	64
Table Frame Assembly (2335177 BOM, rev 3).....	65
Section 2.0 — Foot Switch Assembly (2330508)	70
Foot Switch Assembly (2330508, sheet 1, rev 2).....	70
Footswitch Assembly (2330508 BOM, rev 6)	71
 Chapter 3	
PDU.....	73
H Power PDU (B7816PD BOM, rev A).....	73
Section 1.0 — NGPDU (2326492).....	73
NGPDU (H4 Power Distribution Unit) (2326492 BOM, rev 5)	73

1.1	NGPDU Assembly (2348074)	74
	NGPDU Assembly 1 (2348074, sheet 1, rev 0).....	74
	NGPDU Assembly 1 (2348074, sheet 2, rev 3).....	75
	NGPDU Assembly 1 (2348074, sheet 3, rev 0).....	76
	NGPDU Assembly (2348074 BOM, Rev 20).....	77
	Section 2.0 — Major NGPDU Components	84
	Major Components	84
Chapter 4		
Gantry		87
	LightSpeed RT Gantry with Phantoms	87
	Section 1.0 — Stargate Gantry with Covers (2374681-2, -4)	88
	Stargate Gantry with Covers (2374681 Sheet 1, Rev 7)	88
	RT 4-Slice, MDAS, Gantry with Covers (2374681-2 BOM, rev 5).....	89
	RT 4-Slice, GDAS, ALUM, EMC ED2, ASTEC, Gantry w/Covers (2374681-4 BOM, Rev 7).....	90
1.1	Cover Assembly - Bottom (2381831)	92
	Cover Assy-Bottom-SG (2381831, sheet 1, rev 0).....	92
	Cover Assembly - Bottom (2381831 BOM, rev 1)	93
	1.1.1 – RH Cover Bottom Removable Assembly (2381230)	94
	RH Cover Bottom Removable Assembly (2381230, sheet 1, rev 0)	94
	RH Cover Bottom Removable Assembly (2381230 BOM, rev 0).....	95
	1.1.2 – LH Cover Bottom Removable Assembly (2381229)	96
	LH Cover Bottom Removable Assembly (2381229, sheet 1, rev 0).....	96
	LH Cover Bottom Removable Assembly (2381229 BOM, rev 0).....	97
1.2	Scan Window Assembly (5142849-5)	98
	Scan Window Assembly, SG Gantry (5142849-5, sheet 1, rev 2)	98
	Scan Window Assembly (5142849-5 BOM, rev 2)	99
1.3	Front Cover with Controls (2373933)	100
	Front Cover with Controls (2373933, sheet 1, rev 0)	100
	Front Cover with Controls (2373933 BOM, rev 1)	101
	1.3.1 – Front Cover Sub-Assembly (2373932)	102
	Front Cover Sub Assembly (2373932, sheet 1, rev 2)	102
	Front Cover Sub Assembly (2373932, sheet 2, rev 2)	103

	Front Cover Sub-Assembly (2373932 BOM, rev 3).....	104
	1.3.2 – P9213YX MIC Assembly (2111955)	106
	P9213YX MIC Assy (2111955 sheet 1, rev 0).....	106
	P9213YX MIC Assembly (2111955 BOM, rev 0)	107
1.4	Front Cover with Controls (2373933-2)	108
	Front Cover with Controls (2373933-2, sheet 1, rev 1)	108
	Front Cover with Controls (2373933-2 BOM, rev 1)	109
	1.4.1 – Front Cover Sub-Assembly (2373932-2)	110
	Front Cover Sub Assembly (2373932-2, sheet 1, rev 1)	110
	Front Cover Sub Assembly (2373932-2, sheet 2, rev 1)	111
	Front Cover Sub-Assembly (2373932-2 BOM, rev 1)	112
1.5	Rear Cover with Controls (2373936)	114
	Rear Cover with Controls (2373936 sheet 1, rev 0)	114
	Rear Cover with Controls (2373936 BOM, rev 1).....	115
	1.5.1 – Rear Cover Sub-Assembly (2373935)	116
	Rear Cover Sub Assembly (2373935 sheet 1, rev 2)	116
	Rear Cover Sub Assembly (2373935 sheet 2, rev 2)	117
	Rear Cover Sub-Assembly (2373935 BOM, rev 3)	118
1.6	Rear Cover with Controls (2373936-2).....	120
	Rear Cover with Controls (2373936-2 sheet 1, rev 1).....	120
	Rear Cover with Controls (2373936-2 BOM, rev 1)	121
	1.6.1 – Rear Cover Sub-Assembly (2373935-2).....	122
	Rear Cover Sub Assembly (2373935-2 sheet 1, rev 1).....	122
	Rear Cover Sub Assembly (2373935-2 sheet 2, rev 1).....	123
	Rear Cover Sub-Assembly (2373935-2 BOM, rev 1)	124
1.7	H-Power Top Cover Assembly (2357525).....	126
	Assy, Hpwr Top Cover (2357525 sheet 1, rev 2)	126
	H-Power Top Cover Assembly (2357525 BOM, rev 3).....	127
1.8	COVER ASM, HP Gantry TOP, PRESSURE FORMED (5116637).....	128
	Cover Asm, HP Gantry Top, Pressure Formed (5116637 sheet 1, rev 2).....	128
	Cover Asm, HP Gantry Top, Pressure Formed (5116637 BOM, rev 2)	129
1.9	Cover Assembly, Side Gantry Right (2276690)	130
	Cover Asm, Side Gantry Right (227690 sheet 1, rev 2)	130

	Cover Assembly, Side Gantry Right (2276690 BOM, rev 4)	131
1.10	COVER ASM, GANTRY RIGHT SIDE, PRESSURE-FORMED (5116639).....	132
	Cover Asm, Gantry Right Side, Pressure-Formed (5116639 sheet 1, rev 3)	132
	Cover Assembly, Gantry Right Side, Pressure-Formed (5116639 BOM, rev 3)	133
1.11	Cover Assembly, Side Gantry Left (2276691-7).....	134
	Cover Assembly, Side Gantry Left (2276691, sheet 1, rev 3)	134
	Cover Assembly, Side Gantry Left (2276691-7BOM, rev 0)	135
1.12	COVER ASM, GANTRY LEFT SIDE, PRESSURE-FORMED (5116638)	136
	Cover Assembly, Gantry Left Side, Pressure-Formed (5116638, sheet 1, rev 3)	136
	Cover Assembly, Gantry Left Side, Pressure-Formed (5116638BOM, rev 3).....	137
	Section 2.0 — SG Gantry Vertical Assembly (2374680-2, -4).....	138
	Stargate Gantry Vertical (2374680 Sheet 1, Rev 12)	138
	Stargate Gantry Vertical (2374680 Sheet 2, Rev 2).....	139
	Stargate Gantry Vertical (2374680 Sheet 3, Rev 3).....	140
	Stargate Gantry Vertical (2374680 Sheet 4, Rev 4).....	141
	Stargate Gantry Vertical (2374680 Sheet 5, Rev 2).....	142
	Stargate Gantry Vertical (2374680 Sheet 6, Rev 3).....	143
	Stargate Gantry Vertical (2374680 Sheet 7, Rev 1).....	144
	SG Gantry Vertical Assembly (4-Slice, MDAS) (2374680-2BOM, Rev 12).....	145
	RT 4-Slice, GDAS, ALUM, EMC ED2, ASTEC, Vertical ASM (2374680-4 BOM, Rev 21).....	152
2.1	S/R 120V Power & Intercom Board Assembly (2357521).....	160
	S/R 120V PWR & Intercom Board Assembly (2357521 Sheet 1, Rev 2).....	160
	S/R 120V Power & Intercom Board Assembly (2357521 BOM, rev 3).....	161
	Slipring 120V PS and Intercom PWA Asm, EMC ED2 (2357521-2 BOM, Rev 4).....	162
	2.1.1 – Transmitter/Receiver Power Supply (2354605)	164
	Transmitter/Receiver Power Supply (2354605 BOM, rev 0)	164
2.2	MDAS/Detector Plate Assembly (4-Slice) (2383616-2)	166
	DAS/Detector Plate Asm SG (2383616 sheet 1, rev 1).....	166
	DAS/Detector Plate Asm SG (2383616 sheet 2, rev 1).....	167
	MDAS/Detector Plate Assembly (4-Slice) (2383616-2 BOM, rev 1).....	168
	2.2.1 – MDAS Assembly - H3 (4 SLICE) (2272768-2)	170
	MDAS Assembly - H3 (4 Slice) (2272768-2 BOM, rev 6).....	170
	MDAS Backplane/Chassis, Left Assembly (2289343)	172
	MDAS Backplane/Chassis, LT. Asm (2289343 sheet 1, rev 0).....	172

	MDAS Backplane/Chassis, LT. Asm (2289343 BOM, rev 2).....	173
	MDAS Backplane/Chassis, Center Assembly (2289548).....	174
	MDAS Backplane/Chassis, Ctr Asm (2289548 sheet 1, rev 0)	174
	MDAS Backplane/Chassis, Ctr Asm (2289548 BOM, rev 2).....	175
	MDAS Backplane/Chassis, Right Assembly (2289460)	176
	MDAS Backplane/Chassis, RT. ASM (2289460 sheet 1, rev 0).....	176
	2.2.2 – Power Supply Assembly, +5VDC (2285697).....	178
	Power Supply Asm, +5VDC D-Case (RH) (2285697 sheet 1, rev 0)	178
	Power Supply Assembly, +5VDC (2285697 BOM, rev 0)	179
2.3	GDAS-Detector Plate Assembly SG (2383616-3, -4).....	180
	DAS/Detector Plate Asm SG (2383616 sheet 1, rev 1).....	180
	DAS/Detector Plate Asm SG (2383616 sheet 2, rev 1).....	181
	GDAS-DETECTOR PLATE ASM SG, 8-slice (2383616-3 BOM, Rev 1)	182
	GDAS-DETECTOR PLATE ASM SG, 4-Slice (2383616-4 BOM, Rev 1).....	182
2.4	Axial Dynamic Brake Module (2357524)	184
	Hpwr Axl Dyn Brake Mod with cvr Mnt HLS (2357524 sheet 1, rev 1).....	184
	Hpwr Axl Dyn Brake Mod with cvr Mnt HLS (2357524 sheet 2, rev 1).....	185
	Axial Dynamic Brake Module (2357524 BOM, rev 4).....	186
	2.4.1 – Step-Up Transformer (2354743)	187
	Step-Up Transformer (2354743 BOM, rev 1)	187
2.5	Series Windings with a Long Cable for RT (2217930-4).....	188
	Drive Assembly H-Power Axial (2217930 sheet 1, rev 6).....	188
	Series Windings with a Long Cable for RT (2217930-4 BOM, rev1)	189
	2.5.1 – Axial Motor w/Sprocket (2235342-2)	190
	Axial Motor w/Sprocket, H2 Gantry (2235342-2 sheet 1, rev 1).....	190
	Axial Motor w/Sprocket (2235342-2 BOM, rev 1).....	191
	2.5.2 – Brake Assembly, Axial Drive Motor (2277225)	192
	Brake Assy, H2 Ax Drive Motor (2277225 sheet 1, rev 0).....	192
	Brake Assembly, Axial Drive Motor (2277225 BOM, rev 0).....	193
	2.5.3 – Axial Drive Motor Controller (2233402)	194
	AX Drive Mtr Contrller w/Corers Assy (2233402 sheet 1, rev 2)	194
	AX Drive Mtr Contrller w/Corers Assy (2233402 sheet 2, rev 2)	195
	Axial Drive Motor Controller (2233402 BOM, rev 3).....	196

2.6	Encoder Assembly, Hub-Mounted Wheel (5182284-2)	198
	Encoder Assembly, Hub-Mounted Wheel (5182284 sheet 1, rev 2)	198
	Encoder Assembly, Hub-Mounted Wheel (5182284-2 BOM, rev 1).....	199
2.7	ORP Assembly (2358141-2)	200
	ORP Assembly (2358141 sheet 1, rev 2).....	200
	ORP Assembly (2358141-2 BOM, rev 2)	201
2.8	Stargate Slipping Assembly (2375134)	202
	Stargate Slipping Assembly (2375134 sheet 1, rev 0)	202
	Stargate Slipping Assembly (2375134 BOM, rev 0).....	203
	2.8.1 – Stargate-400MB Slipping Assembly (2364819)	204
	Hpower-400MB Slipping Assembly (2364819 sheet 1, rev 0).....	204
	Stargate-400MB Slipping Assembly (2364819 BOM, rev 1)	205
	<i>2.8.1.1 – Hpower-400 Receiver-Antenna (2333609-2)</i>	<i>206</i>
	Receiver-Antenna (2333609, sheet 1, rev 0)	206
	Hpower-400 Receiver-antenna Assembly (2333609-2 BOM, rev 0)	207
	<i>2.8.1.2 – Slipping Assembly For Hpower (2349587-2)</i>	<i>208</i>
	Slipping Assembly For H-power (2349587, sheet 1, rev 0).....	208
	Slipping Assembly for Hpower-400 (2349587-2 BOM, rev 0)	209
2.9	850 MB H-Power Slipping Assembly (2349589)	210
	850 MB H-Power Slipping Assembly (2349589 Sheet 1, Rev 0)	210
	850 MB H-Power Slipping Assembly (2349589 BOM, Rev 2).....	211
2.10	Slipping Cover Collector (2369443)	212
	Slipping Cover Collector (2369443 BOM, rev 0)	212
2.11	Tilt, Feedback Assembly (2356863, -2)	214
	Tilt, Feedback Assembly (2356863 sheet 1, rev 0)	214
	Tilt, Feedback Assembly (2356863 BOM, rev 1).....	215
	Gantry Tilt Feedback Assembly, EMC ED2 (2356863-2 BOM, Rev 2)	216
2.12	HP60 Gantry TGPU ED2 Assembly (5111425-2)	218
	HP60 Gantry TGPU ED2 Assembly (5111425-2 sheet 1, Rev 1)	218
	HP60 Gantry TGPU ED2 Assembly (5111425-2 BOM, rev 3)	219
2.13	Service Outlet/E-Stop Assembly (2349257)	220
	Service Outlet/Estop Assembly (2349257 sheet 1, rev 1).....	220
	Service Outlet/E-Stop Assembly (2349257 BOM, rev 1).....	221

2.14	Power Pan Assembly 550V (2387385)	222
	Power Pan Asm550V (2387385 sheet 1, rev 0)	222
	Power Pan Asm550V (2387385 sheet 2, rev 0)	223
	Power Pan Assembly 550V (2387385 BOM, rev 6)	224
2.15	120 V Power Pan Assembly (2380752, -2)	226
	120 V Power Pan Assembly (2380752 sheet 1, rev 0).....	226
	120 V Power Pan Assembly (2380752 BOM, rev 2)	227
	120 V Power Pan Assembly, RT, EMC ED2 (2380752-2 BOM, Rev 1).....	228
	Section 3.0 — Stargate Gantry Horizontal Assembly (2374679, -2)	230
	Stargate Horizontal Assembly (2374679 Sheet 1, Rev 0)	230
	Stargate Horizontal Assembly (2374679 Sheet 2, Rev 0).....	231
	Stargate Gantry Horizontal Assembly (2374679 BOM, rev 4).....	232
	RT, GDAS, ALUM, EMC ED2, ASTEC, Horizontal Assembly (2374679-2 BOM, Rev 2).....	235
3.1	Stargate Stationary Base Assembly (2374678)	238
	Stargate Stationary Base Assembly (2374678 sheet 1, rev 2).....	238
	Stargate Stationary Base Assembly (2374678 sheet 2, rev 2).....	239
	Stargate Stationary Base Assembly (2374678 BOM, rev 11)	240
	3.1.1 – Hydraulic Pan Assembly (2380751)	242
	Hydraulic Pan Assembly (2380751 sheet 1, rev 1)	242
	Hydraulic Pan Assembly (2380751 sheet 2, rev 0)	243
	Hydraulic Pan Assembly (2380751 sheet 3, rev 0)	244
	Hydraulic Pan Assembly (2380751 BOM, rev 0).....	245
3.2	Helios 4 Collimator (2214768-4)	246
	Helios 4 Collimator (2214768, sheet 4, rev 4)	246
	Helios 4 Collimator (2214768-4 BOM, rev 2)	247
	3.2.1 – Helios 4 Collimator (2120100-4)	248
	Helios Collimator (2120100, sheet 7, rev 8)	248
	Helios Collimator (2120100, sheet 8, rev 8)	249
	Helios 4 Collimator (2120100-4 BOM, rev 0)	250
	3.2.1.1 – Helios 3 Filter Assembly (2291958)	252
	Helios 3 Filter Assembly (2291958 sheet 1, rev 0).....	252
	Helios 3 Filter Assembly (2291958 BOM, rev 2)	253

	3.2.1.2 – H4 Collimator Base Assembly (2273645-3)	254
	Collimator Base Assembly (2273645, sheet 1, rev 2)	254
	H4 Collimator Base Asm (2273645-3 BOM, rev 1)	255
3.3	JEDI-HP Collector for LS RT (2219132-2)	256
	JEDI-HP Collector for LS RT (2219132-2 BOM, rev 2)	256
	3.3.1 – JH4 Inverter with Shields (2281950-3)	258
	JH4 Inverter with Shields (2281950-3 sheet 1, rev 1)	258
	JH4 Inverter with Shields (2281950-3 sheet 2, rev 1)	259
	JH4 Inverter with Shields (2281950-3 sheet 3, rev 1)	260
	JH4 Inverter with Shields (2281950-3 sheet 4, rev 1)	261
	JH4 Inverter with Shields (2281950-3 sheet 5, rev 1)	262
	JH4 Inverter with Shields (2281950-3 sheet 6, rev 1)	263
	JH4 Inverter with Shields (2281950-3 sheet 7, rev 1)	264
	JH4 Inverter with Shields (2281950-3 BOM , rev 3).....	265
	3.3.2 – JH4 Auxiliary Equipped V2 (2324118)	270
	JH4 Auxiliary Equipped V2 (2324118 sheet 2, rev 4).....	270
	JH4 Auxiliary Equipped V2 (2324118 sheet 3, rev 4).....	271
	JH4 Auxiliary Equipped V2 (2324118 sheet 4, rev 4).....	272
	JH4 Auxiliary Equipped V2 (2324118 BOM, rev 7)	273
	3.3.3 – JEDI H4 MPHVTANK with Shields (2266521-3)	276
	JEDI H4 MPHVTANK with Shields (2266521-3 sheet 1, rev 3).....	276
	JEDI H4 MPHVTANK with Shields (2266521-3 sheet 2, rev 3).....	277
	JEDI H4 MPHVTANK with Shields (2266521-3 sheet 3, rev 3).....	278
	JEDI H4 MPHVTANK with Shields (2266521-3 sheet 4, rev 3).....	279
	JEDI H4 MPHVTANK with Shields (2266521-3 sheet 5, rev 3).....	280
	JEDI H4 MPHVTANK with Shields (2266521-3 sheet 6, rev 3).....	281
	JEDI H4 MPHVTANK with Shields (2266521-3 sheet 7, rev 3).....	282
	JEDI H4 MPHVTANK with Shields (2266521-3 BOM, rev 3)	283
	3.3.4 – Inverter - Auxiliary Parts For CT(2368331-2).....	288
	Inverter - Auxiliary Parts For CT(2368331-2 BOM, rev 1)	288
3.4	DHCB / Fuse Box Assembly (2381086)	290
	DHCB / Fuse Box Assembly (2381086 BOM, rev 3).....	290
3.5	Internal, Left Laser Assemblby (2382216).....	292
	Internal, Left Laser Asm (2382216 sheet 1, rev 0)	292
	Internal, Left Laser Assemblby (2382216 BOM, rev 0)	293

3.6	Power Supply Assembly SG 5V (2391429)	294
	Power Supply Asm SG 5V (2391429 sheet 1, rev 0)	294
	Power Supply Assembly SG 5V (2391429 BOM, rev 1)	295
3.7	Power Supply 12VDC ASM, E-Case (2225217)	296
	Power Supply 12VDC Asm, E-Case (2225217 sheet 1, rev 0)	296
	Power Supply 12VDC ASM, E-Case (2225217 BOM, rev 2)	297
3.8	Power Supply Assembly, 24V F-Case (2225212-4)	298
	Power Supply Assembly, 24V F-Case (2225212-4 BOM, rev 1).....	298
3.9	Power Supply 5VDC ASM, F-Case (2225212-3)	300
	Power Supply 5VDC ASM, F-CASE (2225212-3 sheet 1, rev 1)	300
	Power Supply 5VDC ASM, F-Case (2225212-3 BOM, rev 1)	301
3.10	ASTEC Digital PS Assembly (5126615)	302
	ASTEC Digital PS Assembly (5126615, sheet 1, rev 4).....	302
	ASTEC Digital PS Assembly (5126615 BOM, rev 2)	303
3.11	ASTEC Analog PS Assembly (5126617)	304
	ASTEC Analog PS Assembly (5126617, sheet 1, rev 4).....	304
	ASTEC Analog PS Assembly (5126617 BOM, rev 2)	305
	Section 4.0 — Phantoms (2180544)	306
	Helios 1.0 Tested Phantoms - STA #5 (2180544 BOM, rev 0)	306

Chapter 5

Ship Collector	307
LightSpeed RT STARGATE SHIP COLLECTOR Ship Collector (2394003 BOM, rev 2).....	307
STARGATE SHIP COLLECTOR, Without short cable collector (5135132 BOM, rev 9).....	309
Section 1.0 — Collector-Base Cover-SG (2381848)	311
Collector-Base Cover-SG (2381848 BOM, rev 1)	311
Section 2.0 — Collector-Base Cover-RT (2381848-3)	312
Collector-Base Cover-SG (2381848-3 BOM, rev 1)	312
Section 3.0 — H-Power Fuse Kit (2218570-2)	313
H-Power Fuse Kit (2218570-2 BOM, rev 2)	313

Section 4.0 — Installation Support Kit, Stargate (2319891-4)	314
Installation Support Kit, Stargate (2319891-4 BOM, rev 4)	314
Section 5.0 — Balance Kit, Field, H-Power (2376682-2)	316
Balance Kit, Field, H-Power (2376682-2 BOM, rev 1)	316
Section 6.0 — Short Cable Collector (2281840-5)	317
Short Cable Collector (2281840-5 BOM, rev 0)	317
Section 7.0 — Long Cable Collector (2281840-4)	317
Long Cable Collector (2281840-4 BOM, rev 0)	317

Chapter 1

Introduction

Section 1.0 — Page Layout, Including Finger Tabs

Headers and footers in this publication are designed to allow you to quickly identify your location. The document's part number, revision number and title appear in the header on every page. All page footers display the current page number, at left (when viewed landscape). Odd numbered page footers include a reversed "finger tab" to help the user quickly flip through this manual. These tabs include chapter number and name, plus the name of the current major (level one) section heading. Where applicable, even page footers will show the current minor (level two) section number and name (e.g., 1.1 Side Panel Kit (2269167-2)) - otherwise, they repeat the current major (level one) section heading and name (e.g., Section 1.0 — Page Layout, Including Finger Tabs).

Section 2.0 — Manual Organization

This document is organized according to product structure. That is, the order in which the contents appear is based on the BOMs (Bills of Material) used herein. This means that the user may be required to “dig down” through the product structure in order to find the part they are looking for. [For pdf users, hyperlinks are provided for quick navigation downward (the “back” arrow may be used to move back up)].

WHAT IS A BOM?

A BOM is a Bill (list) Of Materials (parts) used to produce an item. The Parent Item is the thing that is made from the parts listed on the BOM. Because BOMs describe the materials required for a specific manufacturing process, they may not necessarily list every single item used to produce the parent item. The parts on a BOM themselves may be the result of a separate process, and thus have their own BOMs, listing the secondary items required to produce these primary parts.

Section 3.0 — Operator Console Parts Information

The LightSpeed 5.X RT Scanner may be equipped with either of two GRE Xtream Operator Consoles: GOC3 or GOC4 (Global Operator Console versions 3 and 4, respectively). For parts information on these consoles, please refer to the following publications:

- 2394950-100, GOC3 Illustrated Parts List (PDF available on CD-ROMs 5193853-200 and 2378259-200)
- 5134893-100, GOC4 Illustrated Parts List (PDF available on CD-ROMs 5193853-200 and 5134894-200)