

GE Healthcare

LightSpeed 5.X Pro16

Illustrated Parts List

OPERATING DOCUMENTATION



2349187-100
Rev 18

The information contained in this manual applies only to the following LightSpeed 5.X Systems:

- LightSpeed Pro16 (100kW)
- LightSpeed Pro16 (80kW)

For parts information relating to other LightSpeed 5.X systems, please refer to the following Directions:

- 5134004-100 - LightSpeed 5.X RT Illustrated Parts List
- 5134194-100 - LightSpeed 5.X 16, Ultra, Plus Illustrated Parts List

Revision History

Revision	Date	Reason for change
0	06/13/03	New Product Introduction (LightSpeed 5.X).
1	06/24/03	Additions to Chapter 7 - GOC3 (GRE Xstream Console).
2	7/25/03	Comprehensive Update
3	09/05/03	Added: Chapter 5 - Gantry (LS 16, Ultra, Plus)
4	10/10/03	Updated: Chapter 5 - Gantry (LS 16, Ultra, Plus)
5	11/03/03	Added: Chapter 6 - Gantry (RT)
6	11/14/03	Updated: Chapter 5 - Gantry (LS 16, Ultra, Plus)
7	12/10/03	General Updates throughout manual Chapter 4: Added HP80 (Pro16 80kW) info Added: Chapter 8 - Miscellaneous Items (shipping collectors for Pro16 and RT)
8	01/30/04	Chapter 4: Updated BOM 2357737-3 Chapter 8: Added Section 1.4.2 Long Cable Collector (2281840-4) Updated: Chapter 5 - Gantry (LS 16, Ultra, Plus)
9	03/22/04	Chapter 4: Added "Used On" notes to Table 4-42 (Horizontal Assembly BOM) Updated: Chapter 5 - Gantry (LS16, Ultra, Plus)
10	06/23/04	PQR 13022682: Removed confusing Mark Numbers from 2357737/2357737-3 BOM. PQR 13022684: Added Drawings for 2374679, 2374680 & 2374681. Chapter 4: Removed N/A Detector. Updated: Chapter 5 - Gantry (LS16, Ultra, Plus) Split book into two volumes.
11	06/31/04	PQR 13013201 (added fuses to Table 4-64 JH4_INVERTER (2281950 BOM, rev 6)) GDAS updates.
12	09/24/04	PQR 13010697: Added list of Major Components to Chapter 3. Chapter 4: Corrections to GDAS info. Chapter 5: Added Parts for GDAS.

Revision	Date	Reason for change
13	10/22/04	Updates for EMC Ed2. Chapter 7 (GOC3): Added new LCD monitor (19")
14	12/15/04	PQR 13023875 PQR 13026919 PQR 13026143
15	4/7/05	Removed the following Chapters: • RT Gantry - replaced by Direction 5134004-100 • HP60 Gantry - replaced by Direction 5134194-100 • GOC3 - refer to Direction 2394950-100 Removed RT info from Chapter 5 - Miscellaneous Items (formerly Chapter 8 - Miscellaneous Items)
16	7/25/05	Chapter 3 (NGPDU): Updated BOM (new FRUs) Chapter 4 (Gantry): Added Section 1.2 S/R 120V Power and Intercom Board Assembly (2357521, -2)
17	10/22/06	Updated for "Limited Access" systems.
18	3/28/08	PQR 13037774 Corrected P/N 274104 to 2274104; Corrected P/N 2202215-2 to 2388230 PQR 13130498 Chapter 4, added Section 1.1: Assy, Service Switch Board HPWR (2358124)

IMPORTANT PRECAUTIONS

LANGUAGE

WARNING

(EN)

- This Service Manual is available in English only.
- If a customer's service provider requires a language other than English, it is the customer's responsibility to provide translation services.
- Do not attempt to service the equipment unless this service manual has been consulted and is understood.
- Failure to heed this warning may result in injury to the service provider, operator, or patient, from electric shock or from mechanical or other hazards.

Предупреждение

(BG)

- ТОВА УПЪТВАНЕ ЗА РАБОТА Е НАЛИЧНО САМО НА АНГЛИЙСКИ ЕЗИК.
- АКО ДОСТАВЧИКЪТ НА УСЛУГАТА НА КЛИЕНТА ИЗИСКА ЕЗИК, РАЗЛИЧЕН ОТ АНГЛИЙСКИ, ЗАДЪЛЖЕНИЕ НА КЛИЕНТА Е ДА ОСИГУРИ ПРЕВОД.
- НЕ ИЗПОЛЗВАЙТЕ ОБОРУДВАНЕТО ПРЕДИ ДА СТЕ СЕ КОНСУЛТИРАЛИ И РАЗБРАЛИ УПЪТВАНЕТО ЗА РАБОТА.
- НЕСПАЗВАНЕТО НА ТОВА ПРЕДУПРЕЖДЕНИЕ МОЖЕ ДА ДОВЕДЕ ДО НАРАНЯВАНЕ НА ДОСТАВЧИКА НА УСЛУГАТА, ОПЕРАТОРА ИЛИ ПАЦИЕНТ В РЕЗУЛТАТ НА ТОКОВ УДАР ИЛИ МЕХАНИЧНА ИЛИ ДРУГА ОПАСНОСТ.

警告

(ZH-CN)

- 本维修手册仅提供英文版本。
- 如果维修服务提供商需要非英文版本，客户需自行提供翻译服务。
- 未详细阅读和完全理解本维修手册之前，不得进行维修。
- 忽略本警告可能对维修人员，操作员或患者造成触电、机械伤害或其他形式的伤害。

VÝSTRAHA

(CS)

- Tento provozní návod existuje pouze v anglickém jazyce.
- V případě, že externí služba zákazníkům potřebuje návod v jiném jazyce, je zajištění překladu do odpovídajícího jazyka úkolem zákazníka.
- Nesnažte se o údržbu tohoto zařízení, aniž byste si přečetli tento provozní návod a pochopili jeho obsah.
- V případě nedodržování této výstrahy může dojít k poranění pracovníka prodejního servisu, obslužného personálu nebo pacientů vlivem elektrického proudu, respektive vlivem mechanických či jiných rizik.

ADVARSEL

(DA)

- Denne servicemanual findes kun på engelsk.
- Hvis en kundes tekniker har brug for et andet sprog end engelsk, er det kundens ansvar at sørge for oversættelse.
- Forsøg ikke at servicere udstyret medmindre denne servicemanual har været konsulteret og er forstået.
- Manglende overholdelse af denne advarsel kan medføre skade på grund af elektrisk, mekanisk eller anden fare for teknikeren, operatøren eller patienten.

WAARSCHUWING

(NL)

- Deze onderhoudshandleiding is enkel in het Engels verkrijgbaar.
- Als het onderhoudspersoneel een andere taal vereist, dan is de klant verantwoordelijk voor de vertaling ervan.
- Probeer de apparatuur niet te onderhouden voordat deze onderhoudshandleiding werd geraadpleegd en begrepen is.
- Indien deze waarschuwing niet wordt opgevolgd, zou het onderhoudspersoneel, de operator of een patiënt gewond kunnen raken als gevolg van een elektrische schok, mechanische of andere gevaren.

HOIATUS

(ET)

- Käesolev teenindusjuhend on saadaval ainult inglise keeles.
- Kui klienditeeninduse osutaja nõuab juhendit inglise keelest erinevas keeles, vastutab klient tõlketeenuse osutamise eest.
- Ärge üritage seadmeid teenindada enne eelnevalt käesoleva teenindusjuhendiga tutvumist ja sellest aru saamist.
- Käesoleva hoiatuse eiramine võib põhjustada teenuseosutaja, operaatori või patsiendi vigastamist elektrilöögi, mehaanilise või muu ohu tagajärjel.

VAROITUS

(FI)

- Tämä huolto-ohje on saatavilla vain englanniksi.
- Jos asiakkaan huoltohenkilöstö vaatii muuta kuin englanninkielistä materiaalia, tarvittavan käännöksen hankkiminen on asiakkaan vastuulla.
- Älä yritä korjata laitteistoa ennen kuin olet varmasti lukenut ja ymmärtänyt tämän huolto-ohjeen.
- Mikäli tätä varoitusta ei noudateta, seurauksena voi olla huoltohenkilöstön, laitteiston käyttäjän tai potilaan vahingoittuminen sähköiskun, mekaanisen vian tai muun vaaratilanteen vuoksi.

ATTENTION

(FR)

- Ce manuel de service n'est disponible qu'en anglais.
- Si le technicien du client a besoin de ce manuel dans une autre langue que l'anglais, c'est au client qu'il incombe de le faire traduire.
- Ne pas tenter d'intervenir sur les équipements tant que le manuel service n'a pas été consulté et compris.
- Le non-respect de cet avertissement peut entraîner chez le technicien, l'opérateur ou le patient des blessures dues à des dangers électriques, mécaniques ou autres.

WARNUNG

(DE)

- Diese Serviceanleitung existiert nur in Englischer Sprache.
- Falls ein fremder Kundendienst eine andere Sprache benötigt, ist es aufgabe des Kunden für eine Entsprechende Übersetzung zu sorgen.
- Versuchen Sie nicht diese Anlage zu warten, ohne diese Serviceanleitung gelesen und verstanden zu haben.
- Wird diese Warnung nicht beachtet, so kann es zu Verletzungen des Kundendiensttechnikers, des Bedieners oder des Patienten durch Stromschläge, Mechanische oder Sonstige Gefahren kommen.

ΠΡΟΕΙΔΟΠΟΙΗΣΗ

(EL)

- Το παρόν εγχειρίδιο σέρβις διατίθεται στα αγγλικά μόνο.
- Εάν το άτομο παροχής σέρβις ενός πελάτη απαιτεί το παρόν εγχειρίδιο σε γλώσσα εκτός των αγγλικών, αποτελεί ευθύνη του πελάτη να παρέχει υπηρεσίες μετάφρασης.
- Μην επιχειρήσετε την εκτέλεση εργασιών σέρβις στον εξοπλισμό εκτός εάν έχετε συμβουλευτεί και έχετε κατανοήσει το παρόν εγχειρίδιο σέρβις.
- Εάν δε λάβετε υπόψη την προειδοποίηση αυτή, ενδέχεται να προκληθεί τραυματισμός στο άτομο παροχής σέρβις, στο χειριστή ή στον ασθενή από ηλεκτροπληξία, μηχανικούς ή άλλους κινδύνους.

FIGYELMEZTETÉS

(HU)

- Ezen karbantartási kézikönyv kizárólag angol nyelven érhető el.
- Ha a vevő szolgáltatója angoltól eltérő nyelvre tart igényt, akkor a vevő felelőssége a fordítás elkészítése.
- Ne próbálja elkezdni használni a berendezést, amíg a karbantartási kézikönyvben leírtakat nem értelmezték.
- Ezen figyelmeztetés figyelmen kívül hagyása a szolgáltató, működtető vagy a beteg áramütés, mechanikai vagy egyéb veszélyhelyzet miatti sérülését eredményezheti.

AÐVÖRUN

(IS)

- Þessi þjónustuhandbók er eingöngu fáanleg á ensku.
- Ef að þjónustuveitandi viðskiptamanns þarfnast annas tungumáls en ensku, er það skylda viðskiptamanns að skaffa tungumálþjónustu.
- Reynið ekki að afgreiða tækið nema að þessi þjónustuhandbók hefur verið skoðuð og skilin.
- Brot á sinna þessari aðvörun getur leitt til meiðsla á þjónustuveitanda, stjórnanda eða sjúklings frá raflosti, vélrænu eða öðrum áhættum.

AVVERTENZA

(IT)

- Il presente manuale di manutenzione è disponibile soltanto in inglese.
- Se un addetto alla manutenzione richiede il manuale in una lingua diversa, il cliente è tenuto a provvedere direttamente alla traduzione.
- Si proceda alla manutenzione dell'apparecchiatura solo dopo aver consultato il presente manuale ed averne compreso il contenuto
- Il non rispetto della presente avvertenza potrebbe far compiere operazioni da cui derivino lesioni all'addetto, alla manutenzione, all'utilizzatore ed al paziente per folgorazione elettrica, per urti meccanici od altri rischi.

警告

(JA)

- このサービスマニュアルには英語版しかありません。
- サービスを担当される業者が英語以外の言語を要求される場合、翻訳作業はその業者の責任で行うものとさせていただきます。
- このサービスマニュアルを熟読し理解せずに、装置のサービスを行わないでください。
- この警告に従わない場合、サービスを担当される方、操作員あるいは患者さんが、感電や機械的又はその他の危険により負傷する可能性があります。

경고

(KO)

- 본 서비스 지침서는 영어로만 이용하실 수 있습니다 .
- 고객의 서비스 제공자가 영어 이외의 언어를 요구할 경우 , 번역 서비스를 제공하는 것은 고객의 책임입니다 .
- 본 서비스 지침서를 참고했고 이해하지 않는 한은 해당 장비를 수리하려고 시도하지 마십시오 .
- 이 경고에 유의하지 않으면 전기 쇼크 , 기계상의 혹은 다른 위험으로부터 서비스 제공자 , 운영자 혹은 환자에게 위해를 가할 수 있습니다 .

BRDINJUMS

(LV)

- Šī apkalpes rokasgrāmata ir pieejama tikai angļu valodā.
- Ja klienta apkalpes sniedzējam nepieciešama informācija citā valodā, nevis angļu, klienta pienākums ir nodrošināt tulkošanu.
- Neveiciet aprīkojuma apkalpi bez apkalpes rokasgrāmatas izlasīšanas un saprašanas.
- Šī brīdinājuma neievērošana var radīt elektriskās strāvas trieciena, mehānisku vai citu risku izraisītu traumu apkalpes sniedzējam, operatoram vai pacientam.

ISPĒJIMAS

(LT)

- Šis eksploatavimo vadovas yra prieinamas tik anglų kalba.
- Jei kliento paslaugų tiekėjas reikalauja vadovo kita kalba – ne anglų, numatyti vertimo paslaugas yra kliento atsakomybė.
- Nemėginkite atlikti įrangos techninės priežiūros, nebent atsižvelgėte į šį eksploatavimo vadovą ir jį supratote.
- Jei neatkreipsite dėmesio į šį perspėjimą, galimi sužalojimai dėl elektros šoko, mechaninių ar kitų pavojų paslaugų tiekėjui, operatoriui ar pacientui.

ADVARSEL

(NO)

- Denne servicehåndboken finnes bare på engelsk.
- Hvis kundens serviceleverandør trenger et annet språk, er det kundens ansvar å sørge for oversettelse.
- Ikke forsøk å reparere utstyret uten at denne servicehåndboken er lest og forstått.
- Manglende hensyn til denne advarselen kan føre til at serviceleverandøren, operatøren eller pasienten skades på grunn av elektrisk støt, mekaniske eller andre farer.

OSTRZEŻENIE

(PL)

- Niniejszy podręcznik serwisowy dostępny jest jedynie w języku angielskim.
- Jeśli dostawca usług klienta wymaga języka innego niż angielski, zapewnienie usługi tłumaczenia jest obowiązkiem klienta.
- Nie próbować serwisować wyposażenia bez zapoznania się i zrozumienia niniejszego podręcznika serwisowego.
- Niezastosowanie się do tego ostrzeżenia może spowodować urazy dostawcy usług, operatora lub pacjenta w wyniku porażenia elektrycznego, zagrożenia mechanicznego bądź innego.

ATENÇÃO

(PT)

- Este manual de assistência técnica só se encontra disponível em inglês.
- Se qualquer outro serviço de assistência técnica solicitar estes manuais noutro idioma, é da responsabilidade do cliente fornecer os serviços de tradução.
- Não tente consertar o equipamento sem ter consultado e compreendido este manual de assistência técnica.
- O não cumprimento deste aviso pode pôr em perigo a segurança do técnico, do operador ou do paciente devido a choques elétricos, mecânicos ou outros.

ATENȚIE

(RO)

- Acest manual de service este disponibil numai în limba engleză.
- Dacă un furnizor de servicii pentru clienți necesită o altă limbă decât cea engleză, este de datoria clientului să furnizeze o traducere.
- Nu încercați să reparați echipamentul decât ulterior consultării și înțelegerii acestui manual de service.
- Ignorarea acestui avertisment ar putea duce la rănirea depanatorului, operatorului sau pacientului în urma pericolelor de electrocutare, mecanice sau de altă natură.

ОСТОРОЖНО!

(RU)

- Данное руководство по обслуживанию предлагается только на английском языке.
- Если сервисному персоналу клиента необходимо руководство не на английском, а на каком-то другом языке, клиенту следует самостоятельно обеспечить перевод.
- Перед обслуживанием оборудования обязательно обратитесь к данному руководству и поймите изложенные в нем сведения.
- Несоблюдение требований данного предупреждения может привести к тому, что специалист по обслуживанию, оператор или пациент получат удар электрическим током, механическую травму или другое повреждение.

UPOZORNENIE

(SK)

- Tento návod na obsluhu je k dispozícii len v angličtine.
- Ak zákazníkovi poskytovateľ služieb vyžaduje iný jazyk ako angličtinu, poskytnutie prekladateľských služieb je zodpovednosťou zákazníka.
- Nepokúšajte sa o obsluhu zariadenia skôr, ako si neprečítate návod na obsluhu a neporozumiete mu.
- Zanedbanie tohto upozornenia môže vyústiť do zranenia poskytovateľa služieb, obsluhujúcej osoby alebo pacienta elektrickým prúdom, do mechanického alebo iného nebezpečenstva.

ATENCION

(ES)

- Este manual de servicio sólo existe en inglés.
- Si el encargado de mantenimiento de un cliente necesita un idioma que no sea el inglés, el cliente deberá encargarse de la traducción del manual.
- No se deberá dar servicio técnico al equipo, sin haber consultado y comprendido este manual de servicio.
- La no observancia del presente aviso puede dar lugar a que el proveedor de servicios, el operador o el paciente sufran lesiones provocadas por causas eléctricas, mecánicas o de otra naturaleza.

VARNING

(SV)

- Den här servicehandboken finns bara tillgänglig på engelska.
- Om en kunds servicetekniker har behov av ett annat språk än engelska ansvarar kunden för att tillhandahålla översättningstjänster.
- Försök inte utföra service på utrustningen om du inte har läst och förstår den här servicehandboken.
- Om du inte tar hänsyn till den här varningen kan det resultera i skador på serviceteknikern, operatören eller patienten till följd av elektriska stötar, mekaniska faror eller andra faror.

DIKKAT

(TR)

- Bu servis kılavuzunun sadece ingilizcesi mevcuttur.
- Eğer müşteri teknisyen bu kılavuzu ingilizce dışında bir başka lisandan talep ederse, bunu tercüme ettirmek müşteriye düşer.
- Servis kılavuzunu okuyup anlamadan ekipmanlara müdahale etmeyiniz.
- Bu uyarıya uyulmaması, elektrik, mekanik veya diğer tehlikelerden dolayı teknisyen, operatör veya hastanın yaralanmasına yol açabilir.

DAMAGE IN TRANSPORTATION

All packages should be closely examined at time of delivery. If damage is apparent, have notation "damage in shipment" written on all copies of the freight or express bill before delivery is accepted or "signed for" by a General Electric representative or a hospital receiving agent. Whether noted or concealed, damage MUST be reported to the carrier immediately upon discovery, or in any event, within 14 days after receipt, and the contents and containers held for inspection by the carrier. A transportation company will not pay a claim for damage if an inspection is not requested within this 14 day period.

To file a report:

- Call 1-800-548-3366 and use option 8.
- Fill out a report on <http://egems.med.ge.com/edq/home.jsp>
- Contact your local service coordinator for more information on this process.

Rev. Jan. 5, 2005

CERTIFIED ELECTRICAL CONTRACTOR STATEMENT

All electrical Installations that are preliminary to positioning of the equipment at the site prepared for the equipment shall be performed by licensed electrical contractors. In addition, electrical feeds into the Power Distribution Unit shall be performed by licensed electrical contractors. Other connections between pieces of electrical equipment, calibrations and testing shall be performed by qualified GE Medical personnel. The products involved (and the accompanying electrical installations) are highly sophisticated, and special engineering competence is required. In performing all electrical work on these products, GE will use its own specially trained field engineers. All of GE's electrical work on these products will comply with the requirements of the applicable electrical codes.

The purchaser of GE equipment shall only utilize qualified personnel (i.e., GE's field engineers, personnel of third-party service companies with equivalent training, or licensed electricians) to perform electrical servicing on the equipment.

IMPORTANT...X-RAY PROTECTION

X-ray equipment if not properly used may cause injury. Accordingly, the instructions herein contained should be thoroughly read and understood by everyone who will use the equipment before you attempt to place this equipment in operation. The General Electric Company, Medical Systems Group, will be glad to assist and cooperate in placing this equipment in use.

Although this apparatus incorporates a high degree of protection against x-radiation other than the useful beam, no practical design of equipment can provide complete protection. Nor can any practical design compel the operator to take adequate precautions to prevent the possibility of any persons carelessly exposing themselves or others to radiation.

It is important that anyone having anything to do with x-radiation be properly trained and fully acquainted with the recommendations of the National Council on Radiation Protection and Measurements as published in NCRP Reports available from NCRP Publications, 7910 Woodmont Avenue, Room 1016, Bethesda, Maryland 20814, and of the International Commission on Radiation Protection, and take adequate steps to protect against injury.

The equipment is sold with the understanding that the General Electric Company, Medical Systems Group, its agents, and representatives have no responsibility for injury or damage which may result from improper use of the equipment.

Various protective materials and devices are available. It is urged that such materials or devices be used.

LITHIUM BATTERY CAUTIONARY STATEMENT

CAUTION



Risk of Explosion.

Danger of explosion if battery is incorrectly replaced.

Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

ATTENTION



Danger d'Explosion

Il y a danger d'explosion s'il y a remplacement incorrect de la batterie.

Remplacer uniquement avec une batterie du même type ou d'un type recommandé par le constructeur. Mettre au rebut les batteries usagées conformément aux instructions du fabricant.

OMISSIONS & ERRORS

Customers, please contact your GE Sales or Service representatives.

GE personnel, please use the GE Healthcare PQR Process to report all omissions, errors, and defects in this publication.

Table of Contents

Chapter 1

Introduction	25
Section 1.0 — Page Layout, Including Finger Tabs	25
Section 2.0 — Manual Organization.....	25
Section 3.0 — Operator Console Parts Information	26
Section 4.0 — LightSpeed RT, 16, Ultra or Plus Gantry Parts Information	26

Chapter 2

Table	29
Cat Coll/H Power Table with Footswitch (2373155 BOM, rev 0).....	29
Section 1.0 — Table Assembly - H Power (2335179).....	30
Table Assembly - H Power (2335179, sheet 1, rev 0).....	30
Table Assembly - H Power (2335179, sheet 2, rev 0).....	31
Table Assembly - H Power (2335179 BOM, rev 4)	32
1.1 Side Panel Kit (2269167-2).....	36
Side Panel Kit for H2 LCC Cathay Table (2269167-2 BOM, rev 0).....	36
1.2 Cover Table Top - Left (2372371)	38
Cover Table Top - Left (2372371, sheet 1, rev 1)	38
Cover Table Top - Left (2372371 BOM, rev 01).....	39
1.3 Cover Table Top - Right (2372372)	40
Cover Table Top - Right (2372372, sheet 1, rev 1).....	40
Cover Table Top - Right (2372372 BOM, rev 1)	41
1.4 860-941208 Metalless Cradle (2115992-2)	42
Metalless Cradle (2115992, sheet 1, rev 6)	42
Metalless Cradle (2115992-2 BOM, rev 0).....	43
1.5 Table Subassembly - H Power (2335178).....	44
Table Subassembly (2335178, sheet 1, rev 2).....	44
Table Subassembly (2335178, sheet 2, rev 0).....	45
Table Subassembly (2335178, sheet 3, rev 2).....	46

Table Subassembly (2335178, sheet 4, rev 0).....	47
Table Subassembly (2335178 BOM, rev 5)	48
1.5.1 – Carriage Assembly (2269168-2)	52
Carriage Assembly (2269168-2, sheet 2, rev1).....	52
Carriage Assembly (2269168-2 BOM, rev 1)	53
1.5.2 – Latch Assembly (2269177)	54
Latch Assembly (2269177, sheet 1, rev 0).....	54
Latch Assembly (2269177 BOM, rev 0)	55
1.5.3 – Cradle Drive Assembly (2339120)	56
Cradle Drive Assembly (2339120, sheet 1, rev 0).....	56
Cradle Drive Assembly (2339120, sheet 2, rev 0).....	57
Cradle Drive Assembly (2339120, sheet 3, rev 0).....	58
Cradle Drive Assembly (2339120 BOM, rev 3)	59
1.5.4 – Encoder Assembly, Elevation - H Power (2337217)	62
Encoder Assembly, Elevation - H Power (2337217, sheet 1, rev 1)	62
Encoder Assembly, Elevation - H Power (2337217 BOM, rev 2)	63
1.5.5 – Table Frame Assembly (2335177)	64
Table Frame Assembly (2335177, sheet 1, rev 1)	64
Table Frame Assembly (2335177, sheet 2, rev 0)	65
Table Frame Assembly (2335177, sheet 3, rev 1)	66
Table Frame Assembly (2335177, sheet 4, rev 0)	67
Table Frame Assembly (2335177, sheet 5, rev 0)	68
Table Frame Assembly (2335177 BOM, rev 3).....	69
Section 2.0 — Foot Switch Assembly (2330508)	74
Foot Switch Assembly (2330508, sheet 1, rev 2).....	74
Foot Switch Assembly (2330508 BOM, rev 5)	75

Chapter 3

PDU.....	77
H Power PDU (B7816PD BOM, rev A).....	77
Section 1.0 — NGPDU (2326492).....	78
NGPDU (H4 Power Distribution Unit) (2326492 BOM, rev 3)	78
1.1 NGPDU Assembly (2348074)	80
NGPDU Assembly 1 (2348074, sheet 1, rev 0).....	80

NGPDU Assembly 1 (2348074, sheet 2, rev 1).....	81
NGPDU Assembly 1 (2348074, sheet 3, rev 0).....	82
NGPDU Assembly (2348074 BOM, Rev 16).....	83

Section 2.0 — Major NGPDU Components.....	90
Major Components	90

Chapter 4

Gantry.....	97
--------------------	-----------

LightSpeed Pro16 Gantry with Phantoms	97
H-Power Cover Assembly (2357739, sheet 1, rev 0)	98
Pro16 (100kW) Gantry w/MDAS (2357739 BOM, rev 5)	99
Pro16 (80kW) Gantry w/MDAS (2357739-3 BOM, rev 2)	99
Pro16 (100kW) Gantry w/GDAS (2357739-4 BOM, rev 3)	100

Section 1.0 — Vertical Assembly (2357738-8, -10)	102
---	------------

Vertical Assembly (2357738, sheet 1, rev 8).....	102
Vertical Assembly (2357738, sheet 2, rev 4).....	103
Vertical Assembly (2357738, sheet 3, rev 2).....	104
Vertical Assembly (2357738, sheet 4, rev 4).....	105
Vertical Assembly (2357738, sheet 5, rev 2).....	106
Vertical Assembly (2357738, sheet 6, rev 2).....	107
Vertical Assembly (2357738, sheet 7, rev 1).....	108
Vertical Assembly (2357738, sheet 8, rev 1).....	109
Vertical Assembly (2357738, sheet 9, rev 2).....	110
Vertical Assembly (2357738, sheet 10, rev 2).....	111
Vertical Assembly (2357738-8 BOM, rev 10)	112
Vertical Assembly (2357738-10 BOM, rev 3)	119

1.1 Assy, Service Switch Board HPWR (2358124).....	128
---	------------

Assy, Service Switch Board HPWR (2358124)	128
Assy, Service Switch Board HPWR (2358124 BOM, rev 2)	129

1.2 S/R 120V Power and Intercom Board Assembly (2357521, -2).....	130
--	------------

S/R 120V PWR & Intercom Board Assembly (2357521 Sheet 1, Rev 1).....	130
S/R 120V Power & Intercom Board Assembly (2357521 BOM, rev 3).....	131
Slipring 120V PS and Intercom PWA Asm, EMC ED2 (2357521-2 BOM, Rev 4).....	131

	1.2.1 – Transmitter/Receiver Power Supply (2354605)	133
	Transmitter/Receiver Power Supply (2354605 BOM, rev 0)	133
1.3	DAS-Detector Plate Assembly (2358133-4)	134
	DAS-Detector Plate Assembly (2358133-4 sheet 1, rev 3)	134
	DAS-DET PLATE ASM, 9.88 STEEL, GDAS, EMC Ed. 2 (2358133-4 BOM, rev 2)	135
	1.3.1 – GDAS EMC Collector Asm (2358139-3)	136
	GDAS EMC Collector Asm (2358139-3 sheet 1, rev 1)	136
	GDAS EMC Collector Asm (2358139-3 BOM, rev 6)	137
	1.3.2 – Watson16 Det Assembly with Diode (2354053)	138
	Watson16 Det Assembly with Diode (2354053, sheet 1, rev 0)	138
	Watson16 Detector Assembly w/Diode Upgrade (2354035 BOM, rev 2)	139
	1.3.3 – DAS Duct Fan Assembly (2333651)	142
	DAS Duct Fan Assembly (2333651, sheet 1, rev 1)	142
	DAS Duct Fan Assembly (2333651 BOM, rev 1)	143
1.4	Drive Assy Hpower Axial (2217930-3)	144
	Drive Assembly H-Power Axial (2217930, sheet 1, rev 4)	144
	Drive Assembly H-Power Axial (2217930, sheet 3, rev 5)	145
	Drive Assy, Hpower Axial (2217930-3 BOM, rev 0)	146
	1.4.1 – Axial Motor with Sprocket (2235342-3)	148
	Axial Motor w/Sprocket, Hpower (2235342-3 sheet 1, rev 0)	148
	Axial Motor w/Sprocket, Hpower (2235342-3 BOM, rev 0)	149
	1.4.2 – Brake Assy, H2 AX Drive (2277225)	150
	Brake Assy, H2 AX Drive (2277225, sheet 1, rev 0)	150
	Brake Assembly, Axial Drive Motor (2277225 BOM, rev 0)	151
	1.4.3 – AX Drive Motor Controller (2233402)	152
	AX Drive Motor Controller (2233402, sheet 1, rev 2)	152
	AX Drive Motor Controller (2233402, sheet 2, rev 2)	153
	Axial Drive Motor Controller (2233402 BOM, rev 3)	154
1.5	ORP Assembly (2358141, -2)	156
	ORP Assembly (2358141, sheet 1, rev 1)	156
	ORP Assembly (2358141 BOM, rev 4)	157
	ORP Assembly (2358141-2 BOM, rev 2)	157
1.6	850 MB H-Power Slipring (2349589)	158
	850 MB H-Power Slipring (2349589, sheet 1, rev 0)	158

	850 MB H-Power Slipring Assembly (2349589 BOM, Rev 2).....	159
	1.6.1 – 850 MB Platter HSDCD Slip (2320265).....	160
	850 MB Platter HSDCD Slip (2320265, sheet 1, rev 0).....	160
	850 MB Platter HSDCD Slip (2320265 BOM, rev 0)	161
	<i>1.6.1.1 – 850 MB Receiver-Antenna (2333609).....</i>	<i>162</i>
	850 MB Receiver-Antenna (2333609, sheet 1, rev 0)	162
	850 MB Receiver-Antenna (2333609 BOM, rev 0).....	163
	<i>1.6.1.2 – Brushblock Assembly For H-power (2349598).....</i>	<i>164</i>
	Brushblock Assembly For H-power (2349598, sheet 1, rev 0)	164
	Brushblock Assembly For H-power (2349598 BOM, rev 0).....	165
	<i>Power Brush Tip Collector (2349603)</i>	<i>165</i>
	Power Brush Tip Collector (2349603 BOM, rev 0)	165
	<i>Signal Brush Tip Collector (2349604)</i>	<i>165</i>
	Signal Brush Tip Collector (2349604 BOM, rev 0)	165
	<i>1.6.1.3 – Slipring Assembly For H-power (2349587)</i>	<i>166</i>
	Slipring Assembly For H-power (2349587, sheet 1, rev 0).....	166
	Slipring Assembly For H-power (2349587 BOM, rev 0)	167
1.7	Gantry Tilt Feedback ASM, EMC ED2 (2356863-2)	168
	Gantry Tilt Feedback Assembly (2356863-2 sheet 1, rev 0)	168
	Gantry Tilt Feedback ASM, EMC ED2 (2356863-2 BOM, rev 2).....	169
1.8	TGPU ED2 Assembly (5111425-2).....	170
	TGPU ED2 Assembly (5111425-2, sheet 1, rev 1)	170
	TGPU ED2 Assembly (5111425-2 BOM, rev 4)	171
1.9	Service Outlet/EStop Assembly (2349257)	172
	Service Outlet/EStop Assembly (2349257, sheet 1, rev 1)	172
	Service Outlet/E-Stop Assembly (2349257 BOM, rev 1).....	173
1.10	Power Pan Assembly 550V (2387385)	174
	Power Pan Asm550V (2387385 sheet 1, rev 0)	174
	Power Pan Asm550V (2387385 sheet 2, rev 0)	175
	Power Pan Assembly 550V (2387385 BOM, rev 6)	176
1.11	Power Pan Assembly - 120V (2334726, -2).....	178
	Power Pan Assembly - 120V (2334726, sheet 1, rev 1)	178
	Power Pan Assembly - 120V (2334726 BOM, rev 1)	179
	POWER PAN ASM, 120V, EMC ED2 (2334726-2 BOM, rev 3).....	179

1.12	GDAS-16 Main Harness, With ASTEC PS's (2394982-5)	182
	GDAS-16 Main Harness, with ASTEC PS's (2394982-5 sheet 1, rev 3)	182
	GDAS-16 Main Harness, With ASTEC PS's (2394982-5 BOM, rev 3)	183
Section 2.0	— Vertical Assembly (2357738, -3, -4)	184
	H-power Vertical Assembly (2357738, sheet 1, rev 0)	184
	H-power Vertical Assembly (2357738, sheet 2, rev 0)	185
	H-power Vertical Assembly (2357738, sheet 3, rev 0)	186
	H-power Vertical Assembly (2357738, sheet 4, rev 0)	187
	H-power Vertical Assembly (2357738, sheet 5, rev 0)	188
	H-power Vertical Assembly (2357738, sheet 6, rev 0)	189
	H-power Vertical Assembly (2357738, sheet 7, rev 0)	190
	H-power Vertical Assembly (2357738, sheet 8, rev 0)	191
	H-power Vertical Assembly (2357738, sheet 9, rev 0)	192
	Pro16 (100kW) Vertical Assembly w/MDAS (2357738 BOM, rev 14)	193
	Pro16 (80kW) Vertical Assembly w/MDAS (2357738-3 BOM, rev 5)	200
	Pro16 (100) Vertical Assembly w/GDAS (2357738-4 BOM, rev 8)	207
2.1	Detector Plate Assembly (2358133, -2, -3)	216
	Detector Plate Assembly (2358133, sheet 1, rev 0)	216
	Detector Plate Assembly - MDAS (2358133 BOM, rev 0; 2358133-3 BOM, rev 0)	217
	Detector Plate Assembly - GDAS (2358133-2 BOM, rev 1)	217
	2.1.1 – DAS Collector Assembly (2358139, -2)	220
	DAS Collector Assembly (2358139, sheet 1, rev 1)	220
	DAS Collector Assembly (2358139 BOM, rev 2)	221
	DAS Collector Assembly - GDAS (2358139-2 BOM, rev 2)	221
	2.1.1.1 – BP/Chassis LT Assembly - H4 (2371625)	224
	BP/Chassis LT Assembly - H4 (2371625, sheet 1, rev 0)	224
	BP/Chassis LT Assembly - H4 (2371625 BOM, rev 1)	225
	Chassis LT Assembly - H4 (2371628)	226
	Chassis LT Assembly - H4 (2371628, sheet 1, rev 1)	226
	Chassis LT Assembly - H4 (2371628 BOM, rev 0)	227
	2.1.1.2 – BP/Chassis CTR Assembly - H4 (2371626)	228
	BP/Chassis CTR Assembly - H4 (2371626, sheet 1, rev 0)	228
	BP/Chassis CTR Assembly - H4 (2371626 BOM, rev 1)	229
	Chassis CTR Assembly - H4 (2371630)	230
	Chassis CTR Assembly - H4 (2371630, sheet 1, rev 1)	230

	Chassis CTR Assembly - H4 (2371630 BOM, rev 0)	231
	2.1.1.3 – BP/Chassis RT Assembly - H4 (2371627)	232
	BP/Chassis RT Assembly - H4 (2371627, sheet 1, rev 0)	232
	BP/Chassis RT Assembly - H4 (2371627 BOM, rev 1)	233
	Chassis RT Assembly - H4 (2371631)	234
	Chassis RT Assembly - H4 (2371631, sheet 1, rev 2)	234
	Chassis RT Assembly - H4 (2371631 BOM, rev 1)	235
2.2	H-Power Axial Dynamic Brake Module (2357524)	236
	H-Power Axial Dynamic Brake Module (2357524, sheet 1, rev 1)	236
	H-Power Axial Dynamic Brake Module (2357524, sheet 2, rev 1)	237
	Axial Dynamic Brake Module (2357524 BOM, rev 4)	238
	2.2.1 – Step Up Transformer (2354743)	239
	Step Up Transformer (2354743 BOM, rev 1)	239
2.3	Encoder Assembly (2369747)	240
	Encoder Assembly (2369747, sheet 1, rev 0)	240
	Encoder Assembly, Hub-Mounted Wheel (2369747 BOM, rev 0)	241
2.4	Power Supply ASM, 5V Logic (2334458)	242
	Power Supply ASM, 5V Logic (2334458, sheet 1, rev 0)	242
	Power Supply ASM, 5V Logic (2334458 BOM, rev 0)	243
2.5	Tilt, Feedback Assembly (2356863)	244
	Tilt, Feedback Assembly (2356863, sheet 1, rev 0)	244
	Tilt, Feedback Assembly (2356863 BOM, rev 1)	245
2.6	MSUB/TGP Assembly (2349209)	246
	MSUB/TGP Assembly (2349209, sheet 1, rev 1)	246
	MSUB_TGP Assembly (2349209 BOM, rev 6)	247
	2.6.1 – MSUB/TGP Power Supply Assembly (2349205)	248
	MSUB/TGP Power Supply Assembly (2349205, sheet 1, rev 0)	248
	MSUB/TGP Power Supply Assembly (2349205 BOM, rev 1)	249
2.7	Harness, GDAS DET/ORP/P.S./DHCB/ (2394982)	250
	GDAS Harness - DET/ORP/PS/DHCB/ (2394982 BOM, rev 2)	250
	Section 3.0 — Horizontal Assembly (2357737-8, -10)	252
	Horizontal Assembly (2357737 sheet 1, rev 9)	252
	Horizontal Assembly (2357737 sheet 2, rev 3)	253
	Horizontal Assembly (2357737 sheet 3, rev 3)	254

	Horizontal Assembly (2357737 sheet 4, rev 3)	255
	Horizontal Assembly (2357737 sheet 5, rev 3)	256
	Horizontal Assembly (2357737 sheet 6, rev 2)	257
	HP100, GDAS, STL, EMC ED2, ASTEC, HORIZONTAL ASM (2357737-8 BOM, rev 10)	258
	HP100, GDAS16, EMC2, ASTEC, HORIZONTAL ASM, GREEN XRT (2357737-10 BOM, rev 2)	261
3.1	H-power Gantry High Level (2357736)	266
	H-power Gantry High Level (2357736, sheet 1, rev 2)	266
	H-power Gantry High Level (2357736, sheet 2, rev 2)	267
	H-Power Gantry High Level Buy (2357736 BOM, rev 2)	268
	3.1.1 – Hydraulic Tilt Motor Assembly (2334727)	270
	Hydraulic Tilt Motor Assembly (2334727, sheet 1, rev 1)	270
	Hydraulic Tilt Motor Assembly (2334727, sheet 2, rev 0)	271
	Hydraulic Tilt Motor Assembly (2334727, sheet 3, rev 0)	272
	Hydraulic Tilt Motor Assembly (2334727 BOM, rev 1)	273
3.2	Helios 4 collimator with notched filler bar and rating plate (5140001-4)	274
	Collimator Assembly (5140001 sheet 4, rev 1)	274
	Helios 4 collimator with notched filler bar and rating plate (5140001-4 BOM, rev 4)	275
	3.2.1 – Helios 4 collimator with notched filler bar (5140000-4)	276
	Helios 4 Collimator (5140000 sheet 7, rev 1)	276
	Helios 4 Collimator (5140000 sheet 8, rev 2)	277
	helios 4 collimator with notched filler bar (5140000-4 BOM, rev 3)	278
	3.2.1.1 – H4 Collimator Base Assembly (2273645-3)	280
	Collimator Base Assembly (2273645, sheet 1, rev 2)	280
	H4 Collimator Base Asm (2273645-3 BOM, rev 1)	281
3.3	Jedi-HP Collector For CT (2219132)	282
	Jedi-HP Collector For CT (2219132 BOM, rev 0)	282
	3.3.1 – JH4_Inverter (2281950)	284
	JH4_Inverter (2281950, sheet 2, rev 3)	284
	JH4/Inverter (2281950 sheet 3, rev 3)	285
	JH4/Inverter (2281950 sheet 4, rev 3)	286
	JH4/Inverter (2281950 sheet 5, rev 3)	287
	JH4/Inverter (2281950 sheet 6, rev 3)	288
	JH4/Inverter (2281950 sheet 7, rev 3)	289
	JH4_INVERTER (2281950 BOM, rev 6)	290

3.3.2 – Jedi H4 MPHV Tank (2266521)	294
Jedi H4 MPHV Tank (2266521 sheet 2, rev 3)	294
Jedi H4 MPHV Tank (2266521 sheet 3, rev 3)	295
Jedi H4 MPHV Tank (2266521 sheet 4, rev 3)	296
Jedi H4 MPHV Tank (2266521 sheet 5, rev 3)	297
Jedi H4 MPHV Tank (2266521 sheet 6, rev 3)	298
Jedi H4 MPHV Tank (2266521 sheet 7, rev 3)	299
Jedi H4 MPHV Tank (2266521 BOM, rev 6)	300
3.3.3 – Inverter/auxiliary Parts (2368331)	304
Inverter/auxiliary Parts (2368331 sheet 1, rev 3)	304
Inverter/Auxiliary Parts for CT (2368331 BOM, rev 3)	305
3.4 Hercules 2 Fan Heat Exchanger (2334365)	306
Hercules 2 Fan Heat Exchanger (2334365, sheet 1, rev 7)	306
Hercules 2 Fan Heat Exchanger Asm. (2334365 BOM, rev 22)	307
3.4.1 – Hercules H-Power Heat Exchanger Assembly (5125371)	308
Hercules H-Power Heat Exchanger Assembly (5125371 sheet 1, rev 1)	308
Hercules H-Power Heat Exchanger Assembly (5125371 sheet 2, rev 1)	309
Hercules H-Power Heat Exchanger Assembly (5125371 sheet 3, rev 1)	310
Hercules H-Power Heat Exchanger Assembly (5125371 sheet 4, rev 1)	311
Hercules H-Power Heat Exchanger Assembly (5125371)	312
3.5 Home Flag, PWB MTG, H4 Gantry (2227383-2)	316
Home Flag, PWB MTG, H4 Gantry (2227383, sheet 1, rev 2)	316
Home Flag, PWB MTG, H4 Gantry (2227383-2 BOM, rev 0)	317
Section 4.0 — Horizontal Assembly (2357737, -3, -4)	318
HP100 Horizontal Assembly (2357737, sheet 1, rev 0)	318
HP100 Horizontal Assembly (2357737, sheet 2, rev 0)	319
HP100 Horizontal Assembly (2357737, sheet 3, rev 0)	320
HP100 W/MDAS/STL Horizontal Assembly (2357737 BOM, rev 4)	321
HP80 W/MDAS/ALUM Horizontal Asm (2357737-3 BOM, rev 4)	324
Pro16 (100) Horizontal Assembly w/GDAS (2357737-4 BOM, rev 6)	327
4.1 Helios 4 Collimator (2214768-4)	330
Helios 4 Collimator (2214768, sheet 4, rev 4)	330
Helios 4 Collimator (2214768-4 BOM, rev 0)	331
4.1.1 – Helios 4 Collimator (2120100-4)	332
Helios Collimator (2120100, sheet 7, rev 8)	332

	Helios Collimator (2120100, sheet 8, rev 8)	333
	Helios 4 Collimator (2120100-4 BOM, rev 0)	334
4.2	Power Supply Assembly, 24V DC (2334457).....	336
	Power Supply Assembly, 24V Dc (2334457, sheet 1, rev 0).....	336
	Power Supply Assembly, 24V Dc (2334457 BOM, rev 0)	337
4.3	Fuse Box Assy - H4 (2331963-2)	338
	Fuse Box Assy - H4 (2331963-2, sheet 1, rev 2)	338
	Fuse Box Assy - H4 (2331963-2, sheet 2, rev 0)	339
	Fuse Box Assembly - H4 (2331963-2 BOM, rev 2)	340
	4.3.1 – Harness, FSEBX/ORP/DAS/INV (2361658)	342
	Harness, FSEBX/ORP/DAS/INV (2361658, sheet 1, rev 2).....	342
	Harness, FSEBX/ORP/DAS/INV (2361658 BOM, rev 2)	343
4.4	Power Supply Assembly, 12V DC Parallel (2334459).....	344
	Power Supply Assembly, 12V Dc Parallel (2334459, sheet 1, rev 0).....	344
	Pwr Sply Asm, 12V Dc Para (2334459 BOM, rev 0)	345
	Section 5.0 — Cover Assembly, Front Gantry (2361872).....	346
	Cover Assembly, Front Gantry (2361872, sheet 1, rev 0).....	346
	Cover Assembly, Front Gantry (2361872 BOM, rev 1)	347
5.1	Cover Sub-assembly, Front Gantry (2361871).....	348
	Cover Sub-assembly, Front Gantry (2361871, sheet 1, rev 1).....	348
	Cover Sub-assembly, Front Gantry (2361871, sheet 2, rev 1).....	349
	Cover Sub-assembly, Front Gantry (2361871 BOM, rev 2)	350
5.2	P9213YX MIC Assembly (2111955)	352
	P9213YX MIC Assembly (2111955, sheet 1, rev 0).....	352
	P9213YX MIC Assembly (2111955 BOM, rev 0)	353
	Section 6.0 — Cover Assembly, Rear Gantry (2361874)	354
	Cover Assembly, Rear Gantry (2361874, sheet 1, rev 0)	354
	Cover Assembly, Rear Gantry (2361874 BOM, rev 0)	355
6.1	Cover Sub-Assembly, Rear Gant (2361873).....	356
	Cover Sub-Assembly, Rear Gant (2361873, sheet 1, rev 1).....	356
	Cover Sub-Assembly, Rear Gant (2361873, sheet 2, rev 0).....	357
	Cover Sub-Assembly, Rear Gant (2361873 BOM, rev 1)	358

Section 7.0 — Assembly, H Power Top Cover (2357525).....	360
Assembly, H Power Top Cover (2357525, sheet 1, rev 1)	360
Assembly, H Power Top Cover (2357525 BOM, rev 1).....	361
Section 8.0 — Cover Asm, Side Gantry Right (2276690, -5)	362
Cover Assembly, Side Gantry Right (2276690, sheet 1, rev 2).....	362
Cover Assembly, Side Gantry Right (2276690 BOM, rev 3)	363
Cover Assembly, Side Gantry Right (2276690-5 BOM, rev 0)	363
Section 9.0 — Cover Asm, Side Gantry Left (2276691-7).....	364
Cover Assembly, Side Gantry Left, H-Power (2276691, sheet 1, rev 3)	364
Cover Assembly, Side Gantry Left, H-Power (2276691-7 BOM, rev 0).....	365
Section 10.0 — Cover Asm, Side Gantry Left (2276691-5).....	366
Cover Assembly, Side Gantry Left (2276691-5 BOM, rev 0)	366

Chapter 5

Miscellaneous Items 367

Section 1.0 — Pro16 Ship Collector.....	368
Pro16 Ship Collector (Non-Mobile) (2373160 BOM, rev 4)	368
1.1 Base Cover Collector H4 (2366670)	369
Base Cover Collector H4 (2366670 BOM, rev 0)	369
1.2 H-Power Fuse Kit (2218570-2)	370
H-Power Fuse Kit (2218570-2 BOM, rev 1)	370
1.3 Balance Kit, Field, H-Power (2376682)	371
Balance Kit, Field, H-Power (2376682 BOM, rev 0).....	371
1.4 P2030BD Ship C HP-100/60 Common (2385413)	372
P2030BD Ship C HP-100/60 Common (2385413 BOM, rev 1).....	372
1.4.1 – Short Cable Collector (2281840-5)	374
Short Cable Collector (2281840-5 BOM, rev 0)	374
1.4.2 – Long Cable Collector (2281840-4).....	374
Long Cable Collector (2281840-4 BOM, rev 0)	374
Section 2.0 — Small Room Catalog (5191743).....	375
Small Room Catalog (5191743 BOM rev 1).....	375

2.1	Dolly, Pivoting, Small Room, RH (5179183)	376
	Dolly, Pivoting, Small Room (5179183 sheet 1, rev 3)	376
	Dolly, Pivoting, Small Room, RH (5179183 BOM, rev 2)	377
2.2	Dolly, Pivoting, Small Room, LH (5179183-2)	378
	Dolly, Pivoting, Small Room (5179183 sheet 1, rev 3)	378
	Dolly, pivoting, small room, LH (5179183-2 BOM, rev 2)	379

End of TOC.

Chapter 1

Introduction

Section 1.0 — Page Layout, Including Finger Tabs

Headers and footers in this publication are designed to allow you to quickly identify your location. The document's part number, revision number and title appear in the header on every page. All page footers display the current page number, at left (when viewed landscape). Odd numbered page footers include a reversed "finger tab" to help the user quickly flip through this manual. These tabs include chapter number and name, plus the name of the current major (level one) section heading. Where applicable, even page footers will show the current minor (level two) section number and name (e.g., 1.1 Side Panel Kit (2269167-2)) - otherwise, they repeat the current major (level one) section heading and name (e.g., Section 1.0 — Page Layout, Including Finger Tabs).

Section 2.0 — Manual Organization

This document is organized according to product structure. That is, the order in which the contents appear is based on the BOMs (Bills of Material) used herein. This means that the user may be required to "dig down" through the product structure in order to find the part they are looking for. [For pdf users, hyperlinks are provided for quick navigation downward (the "back" arrow may be used to move back up)].

WHAT IS A BOM?

A BOM is a Bill (list) Of Materials (parts) used to produce an item. The Parent Item is the thing that is made from the parts listed on the BOM. Because BOMs describe the materials required for a specific manufacturing process, they may not necessarily list every single item used to produce the parent item. The parts on a BOM themselves may be the result of a separate process, and thus have their own BOMs, listing the secondary items required to produce these primary parts.

Section 3.0 — Operator Console Parts Information

Note: Earlier revisions of 2349187-100 contained parts information for the GOC3. This chapter has been removed. Parts information for the GOC3 may continue to be found in Direction 2394950-100.

The LightSpeed 5.X Pro16 Scanner may be equipped with either of two GRE Xstream Operator Consoles: GOC3 or GOC4 (Global Operator Console versions 3 and 4, respectively). For parts information on these consoles, please refer to the following publications:

- 2394950-100, GOC3 Illustrated Parts List (PDF available on CD-ROMs 5113143-200 and 2378259-200)
- 5134893-100, GOC4 Illustrated Parts List (PDF available on CD-ROMs 5113143-200 and 5134894-200)

Section 4.0 — LightSpeed RT, 16, Ultra or Plus Gantry Parts Information

Earlier revisions of 2349187-100 included parts information for the LightSpeed RT and LightSpeed 16, Ultra, Plus (a.k.a. "HP60") gantries. In an effort to make this publication more manageable for the user, these two chapters have been removed. To find parts information for the gantries of either of these other LightSpeed 5.X variants, please refer to the appropriate one of the two following publications:

- 5134004-100 - LightSpeed 5.X RT Illustrated Parts List
- 5134194-100 - LightSpeed 5.X 16, Ultra, Plus Illustrated Parts List

Table of Contents - Chapter 2 (Table)

Section 1.0	GT 2000 Table (5121647)	23
1.1	Table Assembly (5127787)	24
1.1.1	Elevation Assembly (5127773)	36
1.1.2	Top Frame Assembly (5127782)	42
1.1.3	Foot Switch Assembly (5126796)	52
1.1.4	Side Panel-Front-Left-Assy, Positioning, GT (5130814)	56
1.1.5	Side-Panel-Rear-Left-Assy, Positioning, GT (5130815)	58
1.1.6	Side-Panel-Front-Right-Assy, Positioning, GT (5130816)	60
1.1.7	Side-Panel-Rear-Right-Assy, Positioning, GT (5130817)	62
1.2	Table Ship Collector (5129558)	64
1.2.1	Metalless Compatible Phantom Holder (2331933)	66
Section 2.0	GT 1700 Table (B77172GT)	70
2.1	Table Assy Mid Positioning GT (5134845)	72
2.1.1	Top Frame-1700 Assy Positioning GT (5133502)	84
2.2	Ship Collector GT Table 1700 (5138509)	94

End of TOC.