

GE Healthcare

LightSpeed RT¹⁶ and Xtra

Illustrated Parts List

OPERATING DOCUMENTATION



5173646-100

Rev 7

© 2006-2008, General Electric Company
All Right Reserved

Effectivity

The information in this manual applies to the following LightSpeed RT CT Systems:

- LightSpeed RT w/GDAS (16-Slices)
- LightSpeed Xtra (16-Slices)

IMPORTANT PRECAUTIONS

LANGUAGE

ПРЕДУПРЕЖДЕНИЕ (BG)	• Това упътване за работа е налично само на английски език. • Ако доставчикът на услугата на клиента изиска друг език, задължение на клиента е да осигури превод. • Не използвайте оборудването, преди да сте се консултирали и разбрали упътването за работа. • Неспазването на това предупреждение може да доведе до нараняване на доставчика на услугата, оператора или пациент в резултат на токов удар или механична или друга опасност.
警告 (ZH-CN)	• 本维修手册仅提供英文版本。 • 如果维修服务提供商需要非英文版本，客户需自行提供翻译服务。 • 未详细阅读和完全理解本维修手册之前，不得进行维修。 • 忽略本警告可能对维修人员，操作员或患者造成触电、机械伤害或其他形式的伤害。
VÝSTRAHA (CS)	• Tento provozní návod existuje pouze v anglickém jazyce. • V případě, že externí služba zákazníkům potřebuje návod v jiném jazyce, je zajištění překladu do odpovídajícího jazyka úkolem zákazníka. • Nesnažte se o údržbu tohoto zařízení, aniž byste si přečetli tento provozní návod a pochopili jeho obsah. • V případě nedodržování této výstrahy může dojít k poranění pracovníka prodejního servisu, obslužného personálu nebo pacientů vlivem elektrického proudu, respektive vlivem mechanických či jiných rizik.
ADVARSEL (DA)	• Denne servicemanual findes kun på engelsk. • Hvis en kundes tekniker har brug for et andet sprog end engelsk, er det kundens ansvar at sørge for oversættelse. • Forsøg ikke at servicere udstyret medmindre denne servicemanual har været konsulteret og er forstået. • Manglende overholdelse af denne advarsel kan medføre skade på grund af elektrisk, mekanisk eller anden fare for teknikeren, operatøren eller patienten.

WAARSCHUWING (NL)	• Deze onderhoudshandleiding is enkel in het Engels verkrijgbaar. • Als het onderhoudspersoneel een andere taal vereist, dan is de klant verantwoordelijk voor de vertaling ervan. • Probeer de apparatuur niet te onderhouden voordat deze onderhoudshandleiding werd geraadpleegd en begrepen is. • Indien deze waarschuwing niet wordt opgevolgd, zou het onderhoudspersoneel, de operator of een patiënt gewond kunnen raken als gevolg van een elektrische schok, mechanische of andere gevaren.
WARNING (EN)	• This Service Manual is available in English only. • If a customer's service provider requires a language other than English, it is the customer's responsibility to provide translation services. • Do not attempt to service the equipment unless this service manual has been consulted and is understood. • Failure to heed this warning may result in injury to the service provider, operator, or patient, from electric shock or from mechanical or other hazards.
HOIATUS (ET)	• Käesolev teenindusjuhend on saadaval ainult inglise keeles. • Kui klienditeeninduse osutaja nõuab juhendit inglise keelest erinevas keeles, vastutab klient tõlketeenuse osutamise eest. • Ärge üritage seadmeid teenindada enne eelnevalt käesoleva teenindusjuhendiga tutvumist ja sellest aru saamist. • Käesoleva hoiatuse eiramine võib põhjustada teenuseosutaja, operaatori või patsiendi vigastamist elektrilöögi, mehaanilise või muu ohu tagajärjel.
VAROITUS (FI)	• Tämä huolto-ohje on saatavilla vain englanniksi. • Jos asiakkaan huoltohenkilöstö vaatii muuta kuin englanninkielistä materiaalia, tarvittavan käännöksen hankkiminen on asiakkaan vastuulla. • Älä yritä korjata laitteistoa ennen kuin olet varmasti lukenut ja ymmärtänyt tämän huolto-ohjeen. • Mikäli tätä varoitusta ei noudateta, seurauksena voi olla huoltohenkilöstön, laitteiston käyttäjän tai potilaan vahingoittuminen sähköiskun, mekaanisen vian tai muun vaaratilanteen vuoksi.

ATTENTION (FR)	• Ce manuel de service n'est disponible qu'en anglais. • Si le technicien du client a besoin de ce manuel dans une autre langue que l'anglais, c'est au client qu'il incombe de le faire traduire. • Ne pas tenter d'intervenir sur les équipements tant que le manuel service n'a pas été consulté et compris • Le non-respect de cet avertissement peut entraîner chez le technicien, l'opérateur ou le patient des blessures dues à des dangers électriques, mécaniques ou autres.
WARNUNG (DE)	• Diese Serviceanleitung existiert nur in Englischer Sprache. • Falls ein fremder Kundendienst eine andere Sprache benötigt, ist es aufgabe des Kunden für eine Entsprechende Übersetzung zu sorgen. • Versuchen Sie nicht diese Anlage zu warten, ohne diese Serviceanleitung gelesen und verstanden zu haben. • Wird diese Warnung nicht beachtet, so kann es zu Verletzungen des Kundendiensttechnikers, des Bedieners oder des Patienten durch Stromschläge, Mechanische oder Sonstige Gefahren kommen.
ΠΡΟΕΙΔΟΠΟΙΗΣΗ (EL)	• Το παρόν εγχειρίδιο σέρβις διατίθεται στα αγγλικά μόνο. • Εάν το άτομο παροχής σέρβις ενός πελάτη απαιτεί το παρόν εγχειρίδιο σε γλώσσα εκτός των αγγλικών, αποτελεί ευθύνη του πελάτη να παρέχει υπηρεσίες μετάφρασης. • Μην επιχειρήσετε την εκτέλεση εργασιών σέρβις στον εξοπλισμό εκτός εάν έχετε συμβουλευτεί και έχετε κατανοήσει το παρόν εγχειρίδιο σέρβις. • Εάν δε λάβετε υπόψη την προειδοποίηση αυτή, ενδέχεται να προκληθεί τραυματισμός στο άτομο παροχής σέρβις, στο χειριστή ή στον ασθενή από ηλεκτροπληξία, μηχανικούς ή άλλους κινδύνους.
FIGYELMEZTETÉS (HU)	• Ezen karbantartási kézikönyv kizárólag angol nyelven érhető el. • Ha a vevő szolgáltatója angoltól eltérő nyelvre tart igényt, akkor a vevő felelőssége a fordítás elkészíttetése. • Ne próbálja elkezdni használni a berendezést, amíg a karbantartási kézikönyvben leírtakat nem értelmezték. • Ezen figyelmeztetés figyelmen kívül hagyása a szolgáltató, működtető vagy a beteg áramütés, mechanikai vagy egyéb veszélyhelyzet miatti sérülését eredményezheti.

AÐVÖRUN (IS)	• Þessi þjónustuhandbók er eingöngu fáanleg á ensku. • Ef að þjónustuveitandi viðskiptamanns þarfnast annas tungumáls en ensku, er það skylda viðskiptamanns að skaffa tungumálþjónustu. • Reynið ekki að afgreiða tækið nema að þessi þjónustuhandbók hefur verið skoðuð og skilin. • Brot á sinna þessari aðvörun getur leitt til meiðsla á þjónustuveitanda, stjórnanda eða sjúklings frá raflosti, vélrænu eða öðrum áhættum.
AVVERTENZA (IT)	• Il presente manuale di manutenzione è disponibile soltanto in inglese. • Se un addetto alla manutenzione richiede il manuale in una lingua diversa, il cliente è tenuto a provvedere direttamente alla traduzione. • Si proceda alla manutenzione dell'apparecchiatura solo dopo aver consultato il presente manuale ed averne compreso il contenuto • Il non rispetto della presente avvertenza potrebbe far compiere operazioni da cui derivino lesioni all'addetto, alla manutenzione, all'utilizzatore ed al paziente per folgorazione elettrica, per urti meccanici od altri rischi.
警告 (JA)	• このサービスマニュアルには英語版しかありません。 • サービスを担当される業者が英語以外の言語を要求される場合、翻訳作業はその業者の責任で行うものとさせていただきます。 • このサービスマニュアルを熟読し理解せずに、装置のサービスを行わないでください。 • この警告に従わない場合、サービスを担当される方、操作員あるいは患者さんが、感電や機械的又はその他の危険により負傷する可能性があります。
경고 (KO)	• 본 서비스 지침서는 영어로만 이용하실 수 있습니다 . • 고객의 서비스 제공자가 영어 이외의 언어를 요구할 경우 , 번역 서비스를 제공하는 것은 고객님의 책임입니다 . • 본 서비스 지침서를 참고했고 이해하지 않는 한은 해당 장비를 수리하려고 시도하지 마십시오 . • 이 경고에 유의하지 않으면 전기 쇼크 , 기계상의 혹은 다른 위험으로부터 서비스 제공자 , 운영자 혹은 환자에게 위해를 가할 수 있습니다 .
BRDINJUMS (LV)	• Šī apkāpes rokasgrāmata ir pieejama tikai angļu valodā. • Ja klienta apkāpes sniedzējam nepieciešama informācija citā valodā, nevis angļu, klienta pienākums ir nodrošināt tulkošanu. • Neveiciet aprīkojuma apkalpi bez apkāpes rokasgrāmatas izlasīšanas un saprašanas. • Šī brīdinājuma neievērošana var radīt elektriskās strāvas trieciena, mehānisku vai citu risku izraisītu traumu apkāpes sniedzējam, operatoram vai pacientam.

ĮSPĖJIMAS (LT)	• Šis eksploatavimo vadovas yra prieinamas tik anglų kalba. • Jei kliento paslaugų tiekėjas reikalauja vadovo kita kalba – ne anglų, numatyti vertimo paslaugas yra kliento atsakomybė. • Nemėginkite atlikti įrangos techninės priežiūros, nebent atsižvelgėte į šį eksploatavimo vadovą ir jį supratote. • Jei neatkreipsite dėmesio į šį perspėjimą, galimi sužalojimai dėl elektros šoko, mechaninių ar kitų pavojų paslaugų tiekėjui, operatoriui ar pacientui.
ADVARSEL (NO)	• Denne servicehåndboken finnes bare på engelsk. • Hvis kundens serviceleverandør trenger et annet språk, er det kundens ansvar å sørge for oversettelse. • Ikke forsøk å reparere utstyret uten at denne servicehåndboken er lest og forstått. • Manglende hensyn til denne advarselen kan føre til at serviceleverandøren, operatøren eller pasienten skades på grunn av elektrisk støt, mekaniske eller andre farer.
OSTRZEŻENIE (PL)	• Niniejszy podręcznik serwisowy dostępny jest jedynie w języku angielskim. • Jeśli dostawca usług klienta wymaga języka innego niż angielski, zapewnienie usługi tłumaczenia jest obowiązkiem klienta. • Nie próbować serwisować wyposażenia bez zapoznania się i zrozumienia niniejszego podręcznika serwisowego. • Niezastosowanie się do tego ostrzeżenia może spowodować urazy dostawcy usług, operatora lub pacjenta w wyniku porażenia elektrycznego, zagrożenia mechanicznego bądź innego.
ATENÇÃO (PT-BR)	• Este manual de assistência técnica só se encontra disponível em inglês. • Se qualquer outro serviço de assistência técnica, que não a gems, solicitar estes manuais noutro idioma, é da responsabilidade do cliente fornecer os serviços de tradução. • Não tente reparar o equipamento sem ter consultado e compreendido este manual de assistência técnica. • O não cumprimento deste aviso pode por em perigo a segurança do técnico, operador ou paciente devido a choques elétricos, mecânicos ou outros.
ATENÇÃO (PT-PT)	• Este manual de assistência técnica só se encontra disponível em inglês. • Se qualquer outro serviço de assistência técnica, que não a gems, solicitar estes manuais noutro idioma, é da responsabilidade do cliente fornecer os serviços de tradução. • Não tente reparar o equipamento sem ter consultado e compreendido este manual de assistência técnica. • O não cumprimento deste aviso pode colocar em perigo a segurança do técnico, do operador ou do paciente devido a choques eléctricos, mecânicos ou outros.

ATENȚIE (RO)	• Acest manual de service este disponibil numai în limba engleză. • Dacă un furnizor de servicii pentru clienți necesită o altă limbă decât cea engleză, este de datoria clientului să furnizeze o traducere. • Nu încercați să reparați echipamentul decât ulterior consultării și înțelegerii acestui manual de service. • Ignorarea acestui avertisment ar putea duce la rănirea depanatorului, operatorului sau pacientului în urma pericolelor de electrocutare, mecanice sau de altă natură.
ОСТОРОЖНО! (RU)	• Данное руководство по обслуживанию предлагается только на английском языке. • Если сервисному персоналу клиента необходимо руководство не на английском, а на каком-то другом языке, клиенту следует самостоятельно обеспечить перевод. • Перед обслуживанием оборудования обязательно обратитесь к данному руководству и поймите изложенные в нем сведения. • Несоблюдение требований данного предупреждения может привести к тому, что специалист по обслуживанию, оператор или пациент получат удар электрическим током, механическую травму или другое повреждение.
UPOZORENJE (SR)	• Ovo servisno uputstvo je dostupno samo na engleskom jeziku. • Ako klijentov serviser zahteva neki drugi jezik, klijent je dužan da obezbedi prevodilacke usluge. • Ne pokušavajte da opravite uređaj ako niste procitali i razumeli ovo servisno uputstvo. • Zanimarivanje ovog upozorenja može dovesti do povređivanja serviser, rukovaoca ili pacijenta usled strujnog udara ili mehanickih i drugih opasnosti.
UPOZORNENIE (SK)	• Tento návod na obsluhu je k dispozícii len v angličtine. • Ak zákazník poskytovateľ služieb vyžaduje iný jazyk ako angličtinu, poskytnutie prekladateľských služieb je zodpovednosťou zákazníka. • Nepokúšajte sa o obsluhu zariadenia skôr, ako si neprečítate návod na obsluhu a neporozumiete mu. • Zanedbanie tohto upozornenia môže vyústiť do zranenia poskytovateľa služieb, obsluhujúcej osoby alebo pacienta elektrickým prúdom, do mechanického alebo iného nebezpečenstva.
ATENCION (ES)	• Este manual de servicio sólo existe en inglés. • Si el encargado de mantenimiento de un cliente necesita un idioma que no sea el inglés, el cliente deberá encargarse de la traducción del manual. • No se deberá dar servicio técnico al equipo, sin haber consultado y comprendido este manual de servicio. • La no observancia del presente aviso puede dar lugar a que el proveedor de servicios, el operador o el paciente sufran lesiones provocadas por causas eléctricas, mecánicas o de otra naturaleza.

VARNING (SV)	• Den här servicehandboken finns bara tillgänglig på engelska. • Om en kunds servicetekniker har behov av ett annat språk än engelska ansvarar kunden för att tillhandahålla översättningstjänster. • Försök inte utföra service på utrustningen om du inte har läst och förstår den här servicehandboken. • Om du inte tar hänsyn till den här varningen kan det resultera i skador på serviceteknikern, operatören eller patienten till följd av elektriska stötar, mekaniska faror eller andra faror.
DIKKAT (TR)	• Bu servis kilavuzunun sadece ingilizcesi mevcuttur. • Eğer müşteri teknisyeni bu kilavuzu ingilizce dışında bir başka lisandan talep ederse, bunu tercüme ettirmek müşteriye düşer. • Servis kilavuzunu okuyup anlamadan ekipmanlara müdahale etmeyiniz. • Bu uyarıya uyulmaması, elektrik, mekanik veya diğer tehlikelerden dolayı teknisyen, operatör veya hastanın yaralanmasına yol açabilir.

DAMAGE IN TRANSPORTATION

All packages should be closely examined at time of delivery. If damage is apparent, have notation "damage in shipment" written on all copies of the freight or express bill before delivery is accepted or "signed for" by a General Electric representative or a hospital receiving agent. Whether noted or concealed, damage MUST be reported to the carrier immediately upon discovery, or in any event, within 14 days after receipt, and the contents and containers held for inspection by the carrier. A transportation company will not pay a claim for damage if an inspection is not requested within this 14 day period.

To file a report:

- Call 1-800-548-3366 and use option 8.
- Fill out a report on <http://egems.med.ge.com/edq/home.jsp>
- Contact your local service coordinator for more information on this process.

Rev. June. 13, 2006

CERTIFIED ELECTRICAL CONTRACTOR STATEMENT

All electrical Installations that are preliminary to positioning of the equipment at the site prepared for the equipment shall be performed by licensed electrical contractors. In addition, electrical feeds into the Power Distribution Unit shall be performed by licensed electrical contractors. Other connections between pieces of electrical equipment, calibrations and testing shall be performed by qualified GE Healthcare personnel. The products involved (and the accompanying electrical installations) are highly sophisticated, and special engineering competence is required. In performing all electrical work on these products, GE will use its own specially trained field engineers. All of GE's electrical work on these products will comply with the requirements of the applicable electrical codes.

The purchaser of GE equipment shall only utilize qualified personnel (i.e., GE's field engineers, personnel of third-party service companies with equivalent training, or licensed electricians) to perform electrical servicing on the equipment.

IMPORTANT...X-RAY PROTECTION

X-ray equipment if not properly used may cause injury. Accordingly, the instructions herein contained should be thoroughly read and understood by everyone who will use the equipment before you attempt to place this equipment in operation. The General Electric Company, Healthcare, will be glad to assist and cooperate in placing this equipment in use.

Although this apparatus incorporates a high degree of protection against x-radiation other than the useful beam, no practical design of equipment can provide complete protection. Nor can any practical design compel the operator to take adequate precautions to prevent the possibility of any persons carelessly exposing themselves or others to radiation.

It is important that anyone having anything to do with x-radiation be properly trained and fully acquainted with the recommendations of the National Council on Radiation Protection and Measurements as published in NCRP Reports available from NCRP Publications, 7910 Woodmont Avenue, Room 1016, Bethesda, Maryland 20814, and of the International Commission on Radiation Protection, and take adequate steps to protect against injury.

The equipment is sold with the understanding that the General Electric Company, Healthcare, its agents, and representatives have no responsibility for injury or damage which may result from improper use of the equipment.

Various protective materials and devices are available. It is urged that such materials or devices be used.

LITHIUM BATTERY CAUTIONARY STATEMENTS



CAUTION Risk of Explosion

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.



ATTENTION Danger d'Explosion

Il y a danger d'explosion s'il y a un remplacement incorrect de la batterie. Remplacer uniquement avec une batterie du même type ou d'un type recommandé par le constructeur. Mettre au rebut les batteries usagées conformément aux instructions du fabricant.

OMISSIONS & ERRORS

Customers, please contact your GE Sales or Service representatives.

GE personnel, please use the GE Healthcare PQR Process to report all omissions, errors, and defects in this publication.

Revision History

Revision	Date	Reason for change
7	11/20/08	Chapter 2: Added GT650lbs contents into the Table Chapter Chapter 4: Added new power pan into the Gantry BOM Chapter 6: Changed the shipping collector from 5155150 to 5323140, replaced the old base cover
6	06/16/08	Chapter 4: Section 2.0: Added new Axial Drive Feedback encoder Assembly 5182284-2 Section 2.2.1: Added new section for GDAS EMC collector Asm 2358139-3 Chapter 6: Removed Collector Base Cover - RT 2381848-3 Section 3.0: Updated Balance Kit 2376682-2
5	11/30/07	Chapter 4: Added tube D3193T; D3194T is set as spare part for Service Changed FRU spec of the capacitor 2286419 from No to Yes
4	08/13/07	Chapter 2: Updated GT Table contents Chapter 4: Removed Extra Part from 2374680-6 BOM Added New Top and Side Cover into 2374681-6 BOM Chapter 5: New Host Computers with an Nvidia FX1500 graphics card phase in New IG phase in. Chapter 6: Added Handle into Shipping Collector

Revision	Date	Reason for change
3	03/27/07	Added langugae according to language policy Chapter 4: Updated Gantry BOM Chapter 5: Added Jarrell OC contents Chapter 6: Updated Shipping Collector
2	10/13/06	Updated Chapter 2 - GT Table Chapter 4 Gantry - Updated 2374682-6BOM.
1	7/28/06	Initial release.

Table of Contents

Chapter 1

Introduction	29
Section 1.0 — Page Layout, Including Finger Tabs	29
Section 2.0 — Manual Organization.....	30

Chapter 2

GT Table	31
Section 1.0 — GT 2000 Table (5121647)	32
Positioning GT LONG TABLE ASSY (5121647ADW, sheet 1, rev 8)	32
Positioning GT LONG TABLE ASSY (5121647 BOM, Rev 23).....	33
1.1 Table Assembly (5127787).....	34
Table Assembly (5127787ADW, sheet 2, rev 12)	34
Table Assembly (5127787ADW, sheet 3, rev 12)	35
Table Assembly (5127787ADW, sheet 4, rev 12)	36
Table Assembly (5127787ADW, sheet 5, rev 12)	37
Table Assembly (5127787ADW, sheet 6, rev 12)	38
Table Assembly (5127787ADW, sheet 7, rev 12)	39
Table Assembly (5127787ADW, sheet 8, rev 12)	40
Table Assembly (5127787ADW, sheet 9, rev 12)	41
Table Assembly (5127787ADW, sheet 10, rev 12)	42
Table Assembly (5127787ADW, sheet 11, rev 12)	43
Table Assembly (5127787 BOM, Rev 39).....	44
1.1.1 – Elevation Assembly (5127773)	52
Elevation Assembly (5127773ADW, sheet 2, rev 11)	52
Elevation Assembly (5127773ADW, sheet 3, rev 11)	53
Elevation Assembly (5127773ADW, sheet 4, rev 11)	54
Elevation Assembly (5127773ADW, sheet 5, rev 11)	55
Elevation Assembly (5127773ADW, sheet 6, rev 11)	56
ELAVATION ASSY (5127773 BOM, Rev 29).....	57

1.1.2 – TOP FRAME ASSY (5127782)	62
Top Frame Assembly (5127782ADW, sheet 1, rev 9).....	62
Top Frame Assembly (5127782ADW2, sheet 2, rev 9).....	63
Top Frame Assembly (5127782ADW, sheet 3, rev 9).....	64
Top Frame Assembly (5127782ADW, sheet 4, rev 9).....	65
Top Frame Assembly (5127782ADW, sheet 5, rev 9).....	66
Top Frame Assembly (5127782ADW, sheet 6, rev 9).....	67
Top Frame Assembly (5127782ADW, sheet 7, rev 9).....	68
Top Frame Assembly (5127782ADW, sheet 8, rev 9).....	69
Top Frame Assembly (5127782ADW, sheet 9, rev 9).....	70
Top Frame Assembly (5127782ADW, sheet 10, rev 9).....	71
Top Frame Assembly (5127782ADW, sheet 11, rev 9).....	72
Top Frame Assembly (5127782ADW, sheet 12, rev 9).....	73
Top Frame Assembly (5127782ADW, sheet 13, rev 9).....	74
Top Frame Assembly (5127782ADW, sheet 14, rev 9).....	75
Top Frame Assembly (5127782ADW, sheet 15, rev 9).....	76
Top Frame Assembly (5127782ADW, sheet 16, rev 9).....	77
Top Frame Assembly (5127782ADW, sheet 17, rev 9).....	78
Top Frame Assembly (5127782ADW, sheet 18, rev 9).....	79
Top Frame Assembly (5127782ADW, sheet 19, rev 9).....	80
TOP FRAME ASSY (5127782 BOM, Rev 26).....	81
1.1.2.1 – CRADLE STEEPING MOTOR CLUTCH ASSY Positioning GT (5127493)	86
CRADLE STEEPING MOTOR CLUTCH ASSY Positioning GT (5127493ADW, sheet 1, rev 4)	86
CRADLE STEEPING MOTOR CLUTCH 2000 ASSY Positioning GT (5127493 BOM, Rev 5).....	87
1.1.3 – FOOT SW ASSY (5126796, 5126796-2)	88
Foot Switch Assembly (5126796ADW, sheet 1, rev 2)	88
Foot Switch Assembly (5126796ADW, sheet 2, rev 2)	89
FOOT SW ASSY (5126796-2 BOM, Rev 4).....	90
1.1.4 – RIM TOP COVER FRONT ASSY positioning GT (5127465-3)	92
RIM TOP COVER FRONT ASSY positioning GT (5127465-2ADW, sheet 1, rev 4).....	92
RIM TOP COVER FRONT ASSY positioning GT (5127465-3 BOM, Rev 3)	93
1.1.5 – TOP COVER REAR ASSY (5154872)	94
TOP COVER REAR ASSY (5127466ADW, sheet 1, rev 5)	94
TOP COVER REAR ASSY (5154872 BOM, Rev 2).....	95

1.1.6 – TOP COVER SIDE L ASSY (5127467-2)	96
TOP COVER SIDE L ASSY (5127467-2ADW, sheet 1, rev2)	96
TOP COVER SIDE L ASSY Positioning GT (5127467-2 BOM, Rev 2)	97
1.1.7 – TOP COVER SIDE R ASSY (5127468-2)	98
TOP COVER SIDE R ASSY (5127468-2ADW, sheet 1, rev 2)	98
TOP COVER SIDE R ASSY Positioning GT (5127468-2 BOM, Rev 2)	99
1.1.8 – SIDE-PANEL-FRONT-LEFT-ASSY, Positioning, GT (5130814)	100
Side Panel, Front Left Assembly (5130814ADW, sheet 1, rev 3)	100
SIDE-PANEL-FRONT-LEFT-ASSY, Positioning, GT (5130814 BOM, Rev 3)	101
1.1.9 – SIDE-PANEL-REAR-LEFT-ASSY, Positioning, GT (5130815)	102
Side Panel, Rear Left Assembly (5130815ADW, sheet 1, rev 3)	102
SIDE-PANEL-REAR-LEFT-ASSY, Positioning, GT (5130815 BOM, Rev 3)	103
1.1.10 – SIDE-PANEL-FRONT-RIGHT-ASSY, Positioning, GT (5130816)	104
Side Panel, Front Right Assembly (5130816ADW, sheet 1, rev 3)	104
SIDE-PANEL-FRONT-RIGHT-ASSY, Positioning, GT (5130816 BOM, Rev 3)	105
1.1.11 – SIDE-PANEL-REAR-RIGHT-ASSY, Positioning, GT (5130817)	106
Side Panel, Right Rear Assembly (5130817ADW, sheet 1, rev 3)	106
SIDE-PANEL-REAR-RIGHT-ASSY, Positioning, GT (5130817 BOM, Rev 3)	107
1.1.12 – IMS COVER SIDE LH ASSY (5127463-3)	108
IMS COVER SIDE LH ASSY (5127463-3ADW, sheet 1, rev 2)	108
IMS COVER SIDE LH ASSY (5127463-3 BOM, Rev 4)	109
1.1.13 – IMS COVER SIDE RH ASSY (5127464-3)	110
IMS COVER SIDE RH ASSY (5127464-3ADW, sheet 1, rev 2)	110
IMS COVER SIDE RH ASSY (5127464-3 BOM, Rev 3)	111
1.1.14 – IMS COVER CTR UPPER ASSY (5127462-2)	112
IMS COVER CTR UPPER ASSY (5127462-2ADW, sheet 1, rev 2)	112
IMS COVER CTR UPPER ASSY (5127462-2 BOM, Rev 6)	113
1.2 Table Ship Collector (5129558)	114
Table Ship Collector (5129558 BOM, Rev 8)	114
Section 2.0 — GT 1700 Table (5122080)	115
Positioning GT MIDDLE TABLE ASSY (5122080 BOM, Rev 20)	115
2.1 TABLE ASSY MID positioning GT (5134845)	116
Table Assembly (5127787ADW, sheet 2, rev 12)	116

Table Assembly (5127787ADW, sheet 3, rev 12)	117
Table Assembly (5127787ADW, sheet 4, rev 12)	118
Table Assembly (5127787ADW, sheet 5, rev 12)	119
Table Assembly (5127787ADW, sheet 6, rev 12)	120
Table Assembly (5127787ADW, sheet 7, rev 12)	121
Table Assembly (5127787ADW, sheet 9, rev 12)	122
Table Assembly (5127787ADW, sheet 10, rev 12)	123
Table Assembly (5127787ADW, sheet 12, rev 12)	124
Table Assembly (5127787ADW, sheet 18, rev 12)	125
TABLE ASSY MID positioning GT (5134845 BOM, Rev 35).....	126
2.1.1 – Elavation Assembly (5127773)	134
2.1.2 – Foot Switch Assembly (5126796-2)	134
2.1.3 – RIM Top Cover Assembly Positioning GT (5127465-3)	134
2.1.4 – Side-Panel-Front-Left-Assembly Positioning GT (5130814).....	134
2.1.5 – Side-Panel-Rear-Left-Assembly Positioning GT (5130815)	134
2.1.6 – Side-Panel-Front-Right-Assembly Positioning GT (5130816)	134
2.1.7 – Side-Panel-Rear-Right-Assembly Positioning GT (5130817)	134
2.1.8 – IMS COVER SIDE LH ASSY (5127463-3).....	134
2.1.9 – IMS COVER SIDE RH ASSY (5127464-3)	134
2.1.10 – TOP FRAME-1700 ASSY Positioning GT (5133502)	136
TOP FRAME-1700 ASSY Positioning GT (5133502 BOM, Rev 17)	136
<i>2.1.10.1 – CRADLE STEEPING MOTOR CLUTCH ASSY (5135265).....</i>	<i>141</i>
CRADLE STEEPING MOTOR CLUTCH ASSY (5135265ADW, sheet 1, rev 3).....	141
CRADLE STEEPING MOTOR CLUTCH 1700 ASSY Positioning GT (5135265 BOM, Rev 2).....	142
2.1.11 – TOP COVER REAR-1700 ASSY positioning GT (5133505)	144
TOP COVER REAR-1700 ASSY positioning GT (5133505ADW, sheet 1, rev 5).....	144
TOP COVER REAR-1700 ASSY positioning GT (5133505 BOM, Rev 4)	145
2.1.12 – TOP SIDE COVER L-1700 ASSY positioning GT (5133507-2).....	146
TOP SIDE COVER L-1700 ASSY positioning GT (5133507-2ADW, sheet 1, rev 2)	146
TOP SIDE COVER L 1700 ASSY Positioning GT (5133507-2 BOM, Rev 2).....	147
2.1.13 – TOP SIDE COVER R-1700 ASSY positioning GT (5133506-2)	148
TOP SIDE COVER R-1700 ASSY positioning GT (5133506-2ADW, sheet 1, rev 2).....	148
TOP SIDE COVER R 1700 ASSY Positioning GT (5133506-2 BOM, Rev 2).....	149

2.2	SHIP COLLECTOR GT TABLE 1700 (5138509)	150
	SHIP COLLECTOR GT TABLE 1700 (5138509 BOM, rev 5)	150
	Section 3.0 — High Capacity Table (5272966)	151
	HIGH CAPACITY TABLE ASSY (5272966ADW, sheet 1, rev 1).....	151
	HIGH CAPACITY TABLE ASSY (5272966 BOM, Rev 2)	152
3.1	HIGH CAPACITY Table Assembly (5127787-3)	154
	Table assy for Heavy patient table (5127787-3ADW, sheet 1, rev 2)	154
	Table assy for Heavy patient table (5127787-3ADW, sheet 2, rev 1)	155
	Table assy for Heavy patient table (5127787-3ADW, sheet 3, rev 1)	156
	Table assy for Heavy patient table (5127787-3ADW, sheet 4, rev 1)	157
	Table assy for Heavy patient table (5127787-3ADW, sheet 5, rev 1)	158
	Table assy for Heavy patient table (5127787-3ADW, sheet 6, rev 1)	159
	Table assy for Heavy patient table (5127787-3ADW, sheet 7, rev 1)	160
	Table assy for Heavy patient table (5127787-3ADW, sheet 8, rev 1)	161
	Table assy for Heavy patient table (5127787-3ADW, sheet 9, rev 1)	162
	Table assy for Heavy patient table (5127787-3ADW, sheet 10, rev 1)	163
	Table assy for Heavy patient table (5127787-3ADW, sheet 11, rev 1)	164
	Table assy for Heavy patient table (5127787-3ADW, sheet 12, rev 1)	165
	Table assy for Heavy patient table (5127787-3ADW, sheet 13, rev 1)	166
	Table assy for Heavy patient table (5127787-3ADW, sheet 14, rev 1)	167
	Table assy for Heavy patient table (5127787-3ADW, sheet 15, rev 1)	168
	Table Assembly (5127787-3 BOM, Rev 3).....	169
	3.1.1 – Stronger cradle for Heavy Patient Table	176
	Strong cradle for Heavy Patient Table (5173098-2ADW, sheet 1, rev 1).....	176
	Strong cradle for Heavy Patient Table (5173098-2 BOM, Rev 1)	177
3.2	HIGH CAPACITY Table Ship Collector (5129558-3)	178
	High Capacity Table Ship Collector (5129558-3 BOM, Rev 1).....	178

Chapter 3

PDU	179
H Power PDU (B7816PD BOM, rev A).....	179
Section 1.0 — NGPDU (2326492)	179
NGPDU (H4 Power Distribution Unit) (2326492 BOM, rev 5)	179

1.1	NGPDU Assembly (2348074)	180
	NGPDU Assembly 1 (2348074, sheet 1, rev 0).....	180
	NGPDU Assembly 1 (2348074, sheet 2, rev 3).....	181
	NGPDU Assembly 1 (2348074, sheet 3, rev 0).....	182
	NGPDU Assembly (2348074 BOM, Rev 19).....	183
	Section 2.0 — Major NGPDU Components	190
	Major Components	190

Chapter 4

Gantry	193
LightSpeed RT16 SLICE, GDAS, STEEL, EMC ED2, ASTEC, PHANTOMS (2374682-6BOM, Rev 12)	193
Section 1.0 — RT 16-Slice Gantry with Covers (2374681-6)	194
RT 16-Slice Gantry with Covers (2374681 Sheet 1, Rev 7)	194
RT 16-SLICE, GDAS, STEEL, EMC ED2, ASTEC, Gantry w/Covers (2374681-6 BOM, rev 13)	195
1.1 Cover Assembly - Bottom (2381831)	197
Cover Assy-Bottom-SG (2381831, sheet 1, rev 0).....	197
Cover Assembly - Bottom (2381831 BOM, rev 1)	198
1.1.1 – RH Cover Bottom Removable Assembly (2381230)	199
RH Cover Bottom Removable Assembly (2381230, sheet 1, rev 0)	199
RH Cover Bottom Removable Assembly (2381230 BOM, rev 0)	200
1.1.2 – LH Cover Bottom Removable Assembly (2381229)	201
LH Cover Bottom Removable Assembly (2381229, sheet 1, rev 0).....	201
LH Cover Bottom Removable Assembly (2381229 BOM, rev 0).....	202
1.2 Scan Window Assembly (5142849-5)	203
Scan Window Assembly, FG Gantry (5142849-5, sheet 1, rev 2).....	203
Scan Window Assembly (5142849-5 BOM, rev 2)	204
1.3 Front Cover with Controls (2373933-2)	205
Front Cover with Controls (2373933-2, sheet 1, rev 1)	205
Front Cover with Controls (2373933-2 BOM, rev 1)	206
1.3.1 – Front Cover Sub-Assembly (2373932-2)	207
Front Cover Sub Assembly (2373932-2, sheet 1, rev 1)	207
Front Cover Sub Assembly (2373932-2, sheet 2, rev 2)	208

	Front Cover Sub-Assembly (2373932-2 BOM, rev 2)	209
	1.3.2 – P9213YX MIC Assembly (2111955)	211
	P9213YX MIC Assy (2111955 sheet 1, rev 0).....	211
	P9213YX MIC Assembly (2111955 BOM, rev 0)	212
1.4	Rear Cover with Controls (2373936-2).....	213
	Rear Cover with Controls (2373936-2 sheet 1, rev 1).....	213
	Rear Cover with Controls (2373936-2 BOM, rev 1)	214
	1.4.1 – Rear Cover Sub-Assembly (2373935-2).....	215
	Rear Cover Sub Assembly (2373935-2 sheet 1, rev 2).....	215
	Rear Cover Sub Assembly (2373935-2 sheet 2, rev 2).....	216
	Rear Cover Sub-Assembly (2373935-2 BOM, rev 2)	217
1.5	COVER ASM, HP Gantry TOP, PRESSURE FORMED (5116637).....	219
	Cover Asm, HP Gantry Top, Pressure Formed (5116637 sheet 1, rev 5).....	219
	Cover Asm, HP Gantry Top, Pressure Formed (5116637 BOM, rev 7)	220
1.6	COVER ASM, GANTRY RIGHT SIDE, PRESSURE-FORMED (5116639).....	221
	Cover Asm, Gantry Right Side, Pressure-Formed (5116639 sheet 1, rev 6)	221
	Cover Assembly, Gantry Right Side, Pressure-Formed (5116639 BOM, rev 5)	222
1.7	COVER ASM, GANTRY LEFT SIDE, PRESSURE-FORMED (5116638)	223
	Cover Assembly, Gantry Left Side, Pressure-Formed (5116638, sheet 1, rev 6)	223
	Cover Assembly, Gantry Left Side, Pressure-Formed (5116638BOM, rev 5).....	224
	Section 2.0 — RT-16 Slice GDAS Gantry Vertical Assembly (2374680-6)	226
	RT-16 Slice GDAS Gantry Vertical (2374680 Sheet 1, Rev 16)	226
	RT-16 Slice GDAS Gantry Vertical (2374680 Sheet 2, Rev 2)	227
	RT-16 Slice GDAS Gantry Vertical (2374680 Sheet 3, Rev 4)	228
	RT-16 Slice GDAS Gantry Vertical (2374680 Sheet 4, Rev 5)	229
	RT-16 Slice GDAS Gantry Vertical (2374680 Sheet 5, Rev 4)	230
	RT-16 Slice GDAS Gantry Vertical (2374680 Sheet 6, Rev 3)	231
	RT-16 Slice GDAS Gantry Vertical (2374680 Sheet 7, Rev 1)	232
	RT 16-SLICE, GDAS, STEEL, EMC ED2, ASTEC, VERTICAL ASM (2374680-6 BOM, Rev 26).....	233
2.1	S/R 120V Power & Intercom Board Assembly (2357521-2).....	241
	S/R 120V PWR & Intercom Board Assembly (2357521-2 refer to 2357521 Sheet 1, Rev 2)	241
	Slipring 120V PS and Intercom PWA Asm, EMC ED2 (2357521-2 BOM, rev 5)	242
	2.1.1 – Power Supply Assembly, 12V (5122164).....	243
	Power Supply Asm, 12V (5122164 sheet 1, rev 2)	243

	Power Supply Assembly, 12V (5122164 BOM, rev 3).....	244
2.2	GDAS-Detector Plate Assembly SG (2383616-6).....	245
	DAS/Detector Plate Asm SG (2383616 sheet 1, rev 2).....	245
	DAS/Detector Plate Asm SG (2383616 sheet 2, rev 1).....	246
	GDAS-DETECTOR PLATE ASM SG, 16-slice (2383616-6 BOM, Rev 3)	247
	2.2.1 – GDAS EMC COLLECTOR ASM (2358139-3)	248
	GDAS EMC Collector Asm (2358139-3 sheet 1, rev 1)	248
	GDAS EMC Collector ASM (2358139-3 BOM, rev 6).....	249
2.3	Axial Dynamic Brake Module (5118577-2).....	250
	axial dynamic brake asm, H-power (5118577 sheet 1, rev 3)	250
	axial dynamic brake asm, H-power (5118577 sheet 2, rev 1)	251
	Axial Dynamic Brake Module (2357524 BOM, rev 4).....	252
	2.3.1 – Step-Up Transformer (2354743)	253
	Step-Up Transformer (2354743 BOM, rev 1)	253
2.4	Series Windings with a Long Cable for RT (2217930-4).....	254
	Drive Assembly H-Power Axial (2217930 sheet 1, rev 6).....	254
	Series Windings with a Long Cable for RT (2217930-4 BOM, rev1)	255
	2.4.1 – Axial Motor w/Sprocket (2235342-2)	256
	Axial Motor w/Sprocket, H2 Gantry (2235342-2 sheet 1, rev 1).....	256
	Axial Motor w/Sprocket (2235342-2 BOM, rev 1).....	257
	2.4.2 – Brake Assembly, Axial Drive Motor (2277225)	258
	Brake Assy, H2 Ax Drive Motor (2277225 sheet 1, rev 0).....	258
	Brake Assembly, Axial Drive Motor (2277225 BOM, rev 0).....	259
	2.4.3 – Axial Drive Motor Controller (2233402)	260
	AX Drive Mtr Contrller w/Corers Assy (2233402 sheet 1, rev 2)	260
	AX Drive Mtr Contrller w/Corers Assy (2233402 sheet 2, rev 2)	261
	Axial Drive Motor Controller (2233402 BOM, rev 3).....	262
2.5	Encoder Assembly, Hub-Mounted Wheel (5182284-2).....	263
	Encoder Assembly, Hub-Mounted Wheel (5182284 sheet 1, rev 2)	263
	Encoder Assembly, Hub-Mounted Wheel (5182284-2 BOM, rev 1).....	264
2.6	ORP Assembly (2358141-2)	265
	ORP Assembly (2358141 sheet 1, rev 2)	265
	ORP Assembly (2358141-2 BOM, rev 2)	266

2.7	Stargate Slipring Assembly (2375134)	267
	Stargate Slipring Assembly (2375134 sheet 1, rev 0)	267
	Stargate Slipring Assembly (2375134 BOM, rev 0)	268
	2.7.1 – Stargate-400MB Slipring Assembly (2364819)	269
	Hpower-400MB Slipring Assembly (2364819 sheet 1, rev 0)	269
	Stargate-400MB Slipring Assembly (2364819 BOM, rev 1)	270
	<i>2.7.1.1 – Hpower-400 Receiver-Antenna (2333609-2)</i>	<i>271</i>
	Receiver-Antenna (2333609, sheet 1, rev 0)	271
	Hpower-400 Receiver-antenna Assembly (2333609-2 BOM, rev 0)	272
	<i>2.7.1.2 – Slipring Assembly For Hpower (2349587-2)</i>	<i>274</i>
	Slipring Assembly For H-power (2349587, sheet 1, rev 0)	274
	Slipring Assembly for Hpower-400 (2349587-2 BOM, rev 0)	275
2.8	850 MB H-Power Slipring Assembly (2349589-2)	276
	850 MB H-Power Slipring Assembly (2349589 Sheet 1, Rev 2)	276
	850 MB H-Power Slipring Assembly (2349589-2 BOM, Rev 1)	277
2.9	Slip Ring Collector, Super Shield, RT16 (5269400-3)	278
	Slip Ring Collector, Super Shield, RT16 (5269400-3 BOM, rev 2)	278
2.10	Tilt, Feedback Assembly (2356863, -2)	279
	Tilt, Feedback Assembly (2356863 sheet 1, rev 0)	279
	Tilt, Feedback Assembly (2356863 BOM, rev 1)	280
	Gantry Tilt Feedback Assembly, EMC ED2 (2356863-2 BOM, Rev 2)	281
2.11	HP60 Gantry TGPU ED2 Assembly (5111425-2)	282
	HP60 Gantry TGPU ED2 Assembly (5111425-2 sheet 1, Rev 1)	282
	HP60 Gantry TGPU ED2 Assembly (5111425-2 BOM, rev 3)	283
2.12	Service Outlet/E-Stop Assembly (2349257)	284
	Service Outlet/Estop Assembly (2349257 sheet 1, rev 1)	284
	Service Outlet/E-Stop Assembly (2349257 BOM, rev 1)	285
2.13	Power Pan Assembly 550V (2387385)	286
	Power Pan Asm 550V (2387385 sheet 1, rev 0)	286
	Power Pan Asm550V (2387385 sheet 2, rev 0)	287
	Power Pan Assembly 550V (2387385 BOM, rev 6)	288
2.14	120 V Power Pan Assembly (5269061)	290
	120 V Power Pan Assembly (5269061 sheet 1, rev 1)	290
	120 V Power Pan Assembly (5269061 BOM, rev 1)	291

Section 3.0 — RT16, GDAS, Steel EMC ED2, Astec, Horizontal ASM (2374679-4)	294
RT16 GDAS Horizontal Assembly (2374679 Sheet 1, Rev 4)	294
RT16 GDAS Horizontal Assembly (2374679 Sheet 2, Rev 2)	295
RT16 GDAS Horizontal Assembly (2374679 Sheet 3, Rev 3)	296
RT16 GDAS Horizontal Assembly (2374679 Sheet 4, Rev 3)	297
RT16, GDAS, STEEL, EMC ED2, ASTEC, HORIZONTAL ASM (2374679-4 BOM, Rev 10)	298
3.1 Stargate Stationary Base Assembly (2374678)	302
Stargate Stationary Base Assembly (2374678 sheet 1, rev 4)	302
Stargate Stationary Base Assembly (2374678 sheet 2, rev 2)	303
Stargate Stationary Base Assembly (2374678 BOM, rev 14)	304
3.1.1 – Hydraulic Pan Assembly (2380751)	306
Hydraulic Pan Assembly (2380751 sheet 1, rev 3)	306
Hydraulic Pan Assembly (2380751 sheet 2, rev 2)	307
Hydraulic Pan Assembly (2380751 sheet 3, rev 0)	308
Hydraulic Pan Assembly (2380751 BOM, rev 3)	309
3.2 Helios 4 Collimator (2214768-4)	310
Helios 4 Collimator (2214768, sheet 4, rev 6)	310
Helios 4 Collimator (2214768-4 BOM, rev 2)	311
3.2.1 – Helios 4 Collimator (2120100-4)	312
Helios Collimator (2120100, sheet 7, rev 9)	312
Helios Collimator (2120100, sheet 8, rev 8)	313
Helios 4 Collimator (2120100-4 BOM, rev 8)	314
3.2.1.1 – Helios 3 Filter Assembly (2291958)	316
Helios 3 Filter Assembly (2291958 sheet 1, rev 0)	316
Helios 3 Filter Assembly (2291958 BOM, rev 3)	317
3.2.1.2 – H4 Collimator Base Assembly (2273645-3)	318
Collimator Base Assembly (2273645, sheet 1, rev 2)	318
H4 Collimator Base Asm (2273645-3 BOM, rev 1)	319
3.3 JEDI-HP Collector for LS RT (2219132-2)	320
JEDI-HP Collector for LS RT (2219132-2 BOM, rev 6)	320
3.3.1 – JH4 Inverter with Shields (2281950-4)	321
JH4 Inverter with Shields (2281950-4 sheet 1, rev 3)	321
JH4 Inverter with Shields (2281950-4 sheet 2, rev 3)	322
JH4 Inverter with Shields (2281950-4 sheet 3, rev 3)	323

	JH4 Inverter with Shields (2281950-4 sheet 4, rev 3)	324
	JH4 Inverter with Shields (2281950-4 sheet 5, rev 3)	325
	JH4 Inverter with Shields (2281950-4 sheet 6, rev 3)	326
	JH4 Inverter with Shields (2281950-4 sheet 7, rev 3)	327
	JH4 Inverter with Shields (2281950-3 BOM , rev 3).....	328
	3.3.2 – JH4 Auxiliary Equipped V2 (2324118)	332
	JH4 Auxiliary Equipped V2 (2324118 sheet 2, rev 4).....	332
	JH4 Auxiliary Equipped V2 (2324118 sheet 3, rev 4).....	333
	JH4 Auxiliary Equipped V2 (2324118 sheet 4, rev 4).....	334
	JH4 Auxiliary Equipped V2 (2324118 BOM, rev 7)	335
	3.3.3 – JEDI H4 MPHVTANK with Shields (2266521-3).....	337
	JEDI H4 MPHVTANK with Shields (2266521-3 sheet 1, rev 3).....	337
	JEDI H4 MPHVTANK with Shields (2266521-3 sheet 2, rev 3).....	338
	JEDI H4 MPHVTANK with Shields (2266521-3 sheet 3, rev 3).....	339
	JEDI H4 MPHVTANK with Shields (2266521-3 sheet 4, rev 3).....	340
	JEDI H4 MPHVTANK with Shields (2266521-3 sheet 5, rev 3).....	341
	JEDI H4 MPHVTANK with Shields (2266521-3 sheet 6, rev 3).....	342
	JEDI H4 MPHVTANK with Shields (2266521-3 sheet 7, rev 3).....	343
	JEDI H4 MPHVTANK with Shields (2266521-3 BOM, rev 3)	344
	3.3.4 – Inverter - Auxiliary Parts For CT(2368331-2).....	348
	Inverter - Auxiliary Parts For CT(2368331-2 BOM, rev 1)	348
3.4	DHCB / Fuse Box Assembly (2381086)	349
	DHCB / Fuse Box Assembly (2381086 BOM, rev 3).....	349
3.5	Internal, Left Laser Assembly (2382216).....	351
	Internal, Left Laser Asm (2382216 sheet 1, rev 0)	351
	Internal, Left Laser Assembly (2382216 BOM, rev 0)	352
3.6	Power Supply Assembly SG 5V (2391429).....	353
	Power Supply Asm SG 5V (2391429 sheet 1, rev 0)	353
	Power Supply Assembly SG 5V (2391429 BOM, rev 1)	354
3.7	Power Supply 12VDC ASM, E-Case (2225217)	355
	Power Supply 12VDC Asm, E-Case (2225217 sheet 1, rev 0)	355
	Power Supply 12VDC ASM, E-Case (2225217 BOM, rev 2)	356
3.8	Power Supply Assembly, 24V F-Case (2225212-4).....	357
	Power Supply Assembly, 24V F-Case (2225212-4 BOM, rev 1).....	357

3.9	Power Supply 5VDC ASM, F-Case (2225212-3)	358
	Power Supply 5VDC ASM, F-CASE (2225212-3 sheet 1, rev 1)	358
	Power Supply 5VDC ASM, F-Case (2225212-3 BOM, rev 1)	359
3.10	ASTEC Digital PS Assembly (5126615)	360
	ASTEC Digital PS Assembly (5126615, sheet 1, rev 4)	360
	ASTEC Digital PS Assembly (5126615 BOM, rev 2)	361
3.11	ASTEC Analog PS Assembly (5126617)	362
	ASTEC Analog PS Assembly (5126617, sheet 1, rev 4)	362
	ASTEC Analog PS Assembly (5126617 BOM, rev 2)	363
	Section 4.0 — Phantoms (2180544)	364
	Helios 1.0 Tested Phantoms - STA #5 (2180544 BOM, rev 0)	364

Chapter 5

CONSOLE 369

	Section 1.0 — GRE CONSOLE,16slice GDAS with XW8200, 1IG and Ethernet Switch (2377708-56)	370
	ASSY,GRE CONSOLE,16slice GDAS for GOC4 with XW8200, 1IG and Ethernet Switch (2377708-56 BOM Rev2)	370
1.1	GOC4 w/xw8200 (2378862-56)	371
	GOC4 (2378862-56, sheet 1, rev 1)	371
	GOC4 (2378862-56, sheet 2, rev 1)	372
	GOC4 (2378862-56, sheet 3, rev 1)	373
	GOC4 (2378862-56, sheet 4, rev 1)	374
	Assy, GOC4 - 16 SLICE MDAS and GDAS with XW8200, 1IG and Ethernet Switch (2378862-56 BOM, Rev 8)	375
1.2	New GOC4 Chassis (5162580)	377
	New GOC4 Chassis (5162580 Sheet 1, Rev 1)	377
	New GOC4 Chassis (5162580 BOM, Rev 2)	378
1.3	Console Intercom Prescribed-Tilt Hub (2404320)	380
	Console Intercom Prescribed-Tilt Hub (2404320 Sheet 1, Rev 12)	380
	Console Intercom Prescribed-Tilt Hub (2404320 BOM, Rev 15)	381
1.4	Cover Assy - Console Front (5128181)	382
	Cover Assy - Console Front (5128181 Sheet 1, Rev 1)	382
	Cover Assy - Console Front (5128181 BOM, Rev 1)	383

1.5	Side Covers GOC (2337534)	384
	Side Covers GOC (2337534 BOM, Rev 0).....	384
Section 2.0 — GRE CONSOLE,16slice MDAS and GDAS with XW8200 and 1IG, JARRELL (2377708-556).....		386
	GRE CONSOLE,16slice MDAS and GDAS with XW8200 and 1IG, JARRELL (2377708-556, sheet 1, rev 1)	386
	GRE CONSOLE,16slice MDAS and GDAS with XW8200 and 1IG, JARRELL (2377708-556, sheet 2, rev 1)	387
	GRE CONSOLE,16slice MDAS and GDAS with XW8200 and 1IG, JARRELL (2377708-556, sheet 3, rev 1)	388
	GRE CONSOLE,16slice MDAS and GDAS with XW8200 and 1IG, JARRELL (2377708-556, sheet 4, rev 1)	389
	GRE CONSOLE, 16 slice MDAS and GDAS with XW8200 and 1IG, JARRELL(2377708-556 BOM, Rev 5)	390
2.1	Console Intercom Prescribed-Tilt Hub (2404320-2)	392
	Console Intercom Prescribed-Tilt Hub (2404320 Sheet 1, Rev 12)	392
	Console Intercom Prescribed-Tilt Hub (2404320-2 BOM, Rev 2)	393
Section 3.0 — Associated Items.....		394
3.1	Monitors	395
	Monitor Selection Flowchart	395
	3.1.1 – LCD Monitor - 19 Inch (B71292CA/B7858LC)	396
	LCD Monitor & Cable (B71292CA BOM, rev 2)	396
	LCD Monitor & Cable (B7858LC BOM, rev 3).....	396
3.2	Keyboard w/SCIM, Collectors	397
	Keyboard & SCIM Assembly (Rev 11/15/00)	397
	3.2.1 – Keyboard w/SCIM Collector - English (2275758)	398
	Keyboard w/SCIM Collector - English (2275758 BOM, rev 5).....	398
	3.2.1.1 – SCIM Collector - English (2275752)	398
	SCIM Collector - English (2275752 BOM, rev 2).....	398
	3.2.2 – Chinese (5167383)	398
	Keyboard w/SCIM Collector - French (5167383 BOM, rev 1)	398
	3.2.2.1 – SCIM Collector - Chinese (2275758-10)	398
	3.2.3 – French (2275758-2)	399
	Keyboard w/SCIM Collector - French (2275758-2 BOM, rev 3)	399
	3.2.3.1 – SCIM Collector - French (2275752-2)	399
	3.2.4 – German (2275758-3)	400
	Keyboard w/SCIM Collector - German (2275758-3 BOM, rev 3)	400
	3.2.4.1 – SCIM Collector - German (2275752-3)	400
	SCIM Collector - German (2275752-3 BOM, rev 1)	400

3.2.5 – Swedish (2275758-4)	400
Keyboard w/SCIM Collector - Swedish (2275758-4 BOM, rev 3).....	400
3.2.6 – International (2275758-5)	401
Keyboard w/SCIM Collector - International (2275758-5 BOM, rev 3).....	401
3.2.6.1 – SCIM Collector - International (2275752-4).....	401
SCIM Collector - International (2275752-4 BOM, rev 2)	401
3.3 Console Slide Service Kit (2379135).....	402
Console Slide Service Kit (2379135 BOM, rev 0)	402
3.4 Power Switch & Cables (2379134)	402
Power Switch & Cables (2379134 BOM, rev 0)	402
3.5 Modem Kit (B7700MG)	402
GLOBAL MODEM FOR XTREAM W/ GRE (B7700MG BOM, rev 0).....	402
Section 4.0 — Options.....	404
4.1 Video Upgrade For Linux Console (B7868ME)	405
Video Upgrade For Linux Console (B7868ME BOM, rev 0)	405
4.1.1 – Video Upgrade (5115182).....	405
Video Upgrade (5115182 BOM, rev 6).....	405
4.2 LCD & SUSP (Boom In Room) LNX (B7710LN).....	407
LCD & SUSP (Boom In Room) LNX (B7710LN BOM, rev 1)	407
4.2.1 – Boom-in-a-Room for Linux (5115174-2)	407
Boom-in-a-Room for Linux (5115174-2 BOM, Rev 2)	407

Chapter 6

Ship Collector (5323140)	409
LightSpeed RT16 Vision SHIP COLLECTOR (5323140 BOM, rev 1).....	409
Section 1.0 — H-Power Fuse Kit (2218570-2).....	411
H-Power Fuse Kit (2218570-2 BOM, rev 3)	411
Section 2.0 — Installation Support Kit - LightSpeed RT16 (2319891-5)	412
Installation Support Kit for RT16 (2319891-5 BOM, rev 3).....	412

Section 3.0 — BALANCE KIT, FIELD, H-POWER (2376682-2)	414
Balance Kit, Field, H-Power (2376682-2 BOM, rev 2)	414
Section 4.0 — CABLE COLLECTORS	415
4.1 Short Cable Collector (2281840-5)	415
Short Cable Collector (2281840-5 BOM, rev 0)	415
4.2 Long Cable Collector (2281840-4)	415
Long Cable Collector (2281840-4 BOM, rev 0)	415

Chapter 1

Introduction

Section 1.0 — Page Layout, Including Finger Tabs

Headers and footers in this publication are designed to allow you to quickly identify your location. The document's part number, revision number and title appear in the header on every page. All page footers display the current page number, at left (when viewed landscape). Odd numbered page footers include a reversed "finger tab" to help the user quickly flip through this manual. These tabs include chapter number and name, plus the name of the current major (level one) section heading. Where applicable, even page footers will show the current minor (level two) section number and name (e.g., 1.1 Side Panel Kit (2269167-2)) - otherwise, they repeat the current major (level one) section heading and name (e.g., Section 1.0 — Page Layout, Including Finger Tabs).

Section 2.0 — Manual Organization

This document is organized according to product structure. That is, the order in which the contents appear is based on the BOMs (Bills of Material) used herein. This means that the user may be required to “dig down” through the product structure in order to find the part they are looking for. [For pdf users, hyperlinks are provided for quick navigation downward (the “back” arrow may be used to move back up)].

WHAT IS A BOM?

A BOM is a Bill (list) Of Materials (parts) used to produce an item. The Parent Item is the thing that is made from the parts listed on the BOM. Because BOMs describe the materials required for a specific manufacturing process, they may not necessarily list every single item used to produce the parent item. The parts on a BOM themselves may be the result of a separate process, and thus have their own BOMs, listing the secondary items required to produce these primary parts.